

VIDEO MAIN SIGNAL PATH IN REC MODE

VIDEO MAIN SIGNAL PATH PLAYBACK MODE

TO LUMINANCE & CHROMINANCE/
AUDIO SECTION (PS302F-E2)

TO LUMINANCE & CHROMINANCE/
AUDIO SECTION (PS301E-E2)

A

B

C

D

E

F

G

NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKETS() ON THIS DIAGRAM IS RECORD MODE
WITH PAL COLOUR SIGNAL (SP MODE)

THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE
WITH PAL COLOUR SIGNAL (SP MODE)

NV-HS880EG/B/EC/EE
TBC/DNR PACK SCHEMATIC DIAGRAM

