




(I)	FRONT AUDIO(R)		→	■	→	(B1)
(I)	FRONT AUDIO(L)		→	■	→	(B2)
(R)	TUNER AUDIO(R)		→	■	→	(B3)
(I)	AUDIO IN1(R)		→	■	→	(B4)
(I)	AUDIO IN2(R)		→	■	→	(B5)
(R)	TUNER AUDIO(L)		→	■	→	(B6)
(I)	AUDIO IN1(L)		→	■	→	(B7)
(I)	AUDIO IN2(L)		→	■	→	(B8)
(V)	AUDIO HEAD COM		→	◀■▶		(B9)
(V)	AUDIO HEAD R		→	◻	⇒	(B10)
(V)	AUDIO HEAD L		→	◻	⇒	(B11)
(S)	A HEAD SW		→			(B12)
(S)	ABS NORMAL (H)		→			(B13)



NOTE:DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.