

INPUT CONDITION							OUTPUT RESULT					
POWER	AV2 SELECT	TV/ VTR	EE/ VV	OSD ON(H)	INPUT CH	AV2 PB(H)	AV1 OUT	AV2 OUT	AV1 PB(H)	RGB SW	VCR IN	VCR OUT
P.OFF	---	---	---	---	---	L	AV2 IN	AV1 IN	L	OFF	TUN	TUN
VPS STAND BY	EXT	---	---	L	NORMAL TUN	H	AV2 IN	AV1 IN	H	ON	TUN	TUN
						L	AV2 IN	AV1 IN	L	OFF	TUN	TUN
						H	AV2 IN	AV1 IN	H	ON	TUN	TUN
					C+ TUNER	L	AV2 IN	AV1 IN	L	OFF	TUN	TUN
						H	AV2 IN	AV1 IN	H	ON	TUN	TUN
					AV1	L	AV2 IN	AV1 IN	L	OFF	AV1	AV1
						H	AV2 IN	AV1 IN	H	ON	AV1	AV1
					AV2	L	AV2 IN	AV1 IN	L	OFF	AV2	AV2
						H	AV2 IN	AV1 IN	H	ON	AV2	AV2
					AV3	L	AV2 IN	AV1 IN	L	OFF	AV3	AV3
						H	AV2 IN	AV1 IN	H	ON	AV3	AV3
					SAT.NOR TUN	L	AV2 IN	AV1 IN	L	OFF	SAT.TUN	SAT.TUN
						H	AV2 IN	AV1 IN	H	ON	SAT.TUN	SAT.TUN
					SAT.C+ TUN	L	AV2 IN	AV1 IN	L	OFF	SAT.TUN	SAT.TUN
						H	AV2 IN	AV1 IN	H	ON	SAT.TUN	SAT.TUN
				H	NORMAL TUN	L	VTR OUT	AV1 IN	H	OFF	TUN	TUN
						H	VTR OUT	AV1 IN	H	OFF	TUN	TUN
					C+ TUNER	L	VTR OUT	AV1 IN	H	OFF	TUN	TUN
						H	VTR OUT	AV1 IN	H	OFF	TUN	TUN
					AV1	L	VTR OUT	AV1 IN	H	OFF	AV1	AV1
						H	VTR OUT	AV1 IN	H	OFF	AV1	AV1
					AV2	L	VTR OUT	AV1 IN	H	ON	AV2	AV2
						H	VTR OUT	AV1 IN	H	ON	AV2	AV2
					AV3	L	VTR OUT	AV1 IN	H	OFF	AV3	AV3
						H	VTR OUT	AV1 IN	H	OFF	AV3	AV3
					SAT.NOR TUN	L	VTR OUT	AV1 IN	H	OFF	SAT.TUN	SAT.TUN
						H	VTR OUT	AV1 IN	H	OFF	SAT.TUN	SAT.TUN
					SAT.C+ TUN	L	VTR OUT	AV1 IN	H	OFF	SAT.TUN	SAT.TUN
						H	VTR OUT	AV1 IN	H	OFF	SAT.TUN	SAT.TUN
	DECODER	---	---	L	NORMAL TUN	L	AV2 IN	AV1 IN	L	OFF	TUN	TUN
						H	AV2 IN	AV1 IN	H	ON	TUN	TUN
					C+ TUNER	L	AV2 IN	AV1 IN	L	OFF	TUN	TUN
						H	AV2 IN	AV1 IN	H	ON	TUN	TUN
					AV1	L	AV2 IN	AV1 IN	L	OFF	AV1	AV1
						H	AV2 IN	AV1 IN	H	ON	AV2	AV2
					AV2	L	AV2 IN	AV1 IN	L	OFF	AV2	AV2
						H	AV2 IN	AV1 IN	H	ON	AV2	AV2
					AV3	L	AV2 IN	AV1 IN	L	OFF	AV3	AV3
						H	AV2 IN	AV1 IN	H	ON	AV3	AV3
					SAT.NOR TUN	L	AV2 IN	AV1 IN	L	OFF	SAT.TUN	SAT.TUN
						H	AV2 IN	AV1 IN	H	ON	SAT.TUN	SAT.TUN
					SAT.C+ TUN	L	AV2 IN	AV1 IN	L	OFF	SAT.TUN	SAT.TUN
						H	AV2 IN	AV1 IN	H	ON	SAT.TUN	SAT.TUN
				H	NORMAL TUN	L	VTR OUT	AV1 IN	H	OFF	TUN	TUN
						H	VTR OUT	AV1 IN	H	OFF	TUN	TUN
					C+ TUNER	L	VTR OUT	AV1 IN	H	OFF	TUN	TUN
						H	VTR OUT	AV1 IN	H	OFF	TUN	TUN
					AV1	L	VTR OUT	AV1 IN	H	OFF	AV1	AV1
						H	VTR OUT	AV1 IN	H	ON	AV2	AV2
					AV2	L	VTR OUT	AV1 IN	H	ON	AV2	AV2
						H	VTR OUT	AV1 IN	H	ON	AV2	AV2
					AV3	L	VTR OUT	AV1 IN	H	OFF	AV3	AV3
						H	VTR OUT	AV1 IN	H	OFF	AV3	AV3
					SAT.NOR TUN	L	VTR OUT	AV1 IN	H	OFF	SAT.TUN	SAT.TUN
						H	VTR OUT	AV1 IN	H	OFF	SAT.TUN	SAT.TUN
					SAT.C+ TUN	L	VTR OUT	AV1 IN	H	OFF	SAT.TUN	SAT.TUN
						H	VTR OUT	AV1 IN	H	OFF	SAT.TUN	SAT.TUN