

➡ VIDEO MAIN SIGNAL PATH IN REC MODE

➡ AUDIO MAIN SIGNAL PATH IN REC MODE

C

B




A

TO TIMER SECTION
P7502(B-10)

P6501		
P7502-6	SAT IR	1
P7502-5	UNREG 14V	2
P7502-4		3
P7502-3	FRONT VIDEO	4
P7502-2	GND (A)	5
P7502-1	FRONT AUDIO	6

C6503
0.1
BOTTOM
GND

JK6501
VJJ0575



NOTE:DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.

1

2

3