






(P) POWER SUPPLY/RF SECTION
(S) TO SYSTEM CONTROL & SERVO SECTION
(V) TO LUMINANCE & CHROMINANCE/AUDIO SECTION
(T) TO TIMER SECTION



VIDEO MAIN SIGNAL PATH IN REC MODE
VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE

AUDIO MAIN SIGNAL PATH IN REC MODE
AUDIO MAIN SIGNAL PATH IN PLAYBACK MODE



AV1 (TV)	
1	AUDIO OUT
2	AUDIO IN
3	AUDIO OUT
4	GND (A)
5	GND
6	AUDIO IN
7	BLUE
8	PB +12V
9	GND
10	CONTROL
11	GREEN
12	GND
13	GND
14	RED
15	BLANKING
16	GND
17	GND
18	GND
19	VIDEO OUT
20	VIDEO IN
21	GND

AV2 (DECODER/EXT)	
1	AUDIO OUT
2	AUDIO IN
3	AUDIO OUT
4	GND (A)
5	GND
6	AUDIO IN
7	BLUE
8	PB +12V
9	GND
10	IIC CLOCK
11	GREEN
12	IIC DATA
13	GND
14	GND
15	RED
16	BLANKING
17	GND
18	GND
19	VIDEO OUT
20	VIDEO IN
21	GND

NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKETS ON THIS DIAGRAM IS RECORD MODE WITH SECAM COLOUR (SP MODE)
THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE WITH SECAM COLOUR SIGNAL (SP MODE)

NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.