

INPUT CONDITION							OUTPUT RESULT								
POWER	AV2 SELECT	TV/ VTR	EE/ VV	OSD ON(H)	INPUT CH	AV2 PB(H)	AV1 OUT	AV2 OUT	AV1 PB(H)	RGB SW	VCR IN	VCR OUT			
P.ON	DECODER	TV	EE	H	AV3	L	VTR OUT	AV1 IN	H	OFF	AV3	AV3			
						H	VTR OUT	AV1 IN	H	OFF	AV3	AV3			
					SAT.NOR TUN	L	VTR OUT	AV1 IN	H	OFF	SAT.TUN	SAT.TUN			
						H	VTR OUT	AV1 IN	H	OFF	SAT.TUN	SAT.TUN			
						SAT.C+ TUN	L	VTR OUT	SAT IN	H	OFF	SAT.TUN	SAT.TUN		
							H	VTR OUT	SAT IN	H	ON	AV2	AV2		
					VTR	EE	L	NORMAL TUN	L	VTR OUT	AV1 IN	H	OFF	TUN	TUN
									H	VTR OUT	AV1 IN	H	OFF	TUN	TUN
								C+ TUNER	L	VTR OUT	TUN IN	H	OFF	TUN	TUN
									H	VTR OUT	TUN IN	H	ON	AV2	AV2
		AV1	L	VTR OUT				AV1 IN	H	OFF	AV1	AV1			
			H	VTR OUT				AV1 IN	H	ON	AV2	AV2			
		AV2	L	VTR OUT				AV1 IN	H	ON	AV2	AV2			
			H	VTR OUT				AV1 IN	H	ON	AV2	AV2			
		AV 3	L	VTR OUT				AV1 IN	H	OFF	AV3	AV3			
			H	VTR OUT				AV1 IN	H	OFF	AV3	AV3			
		SAT.NOR TUN	L	VTR OUT			AV1 IN	H	OFF	SAT.TUN	SAT.TUN				
			H	VTR OUT			AV1 IN	H	OFF	SAT.TUN	SAT.TUN				
		SAT.C+ TUN	L	VTR OUT			SAT IN	H	OFF	SAT.TUN	SAT.TUN				
			H	VTR OUT			SAT IN	H	ON	AV2	AV2				
		H	NORMAL TUN	L			VTR OUT	AV1 IN	H	OFF	TUN	TUN			
				H			VTR OUT	AV1 IN	H	OFF	TUN	TUN			
			C+ TUNER	L			VTR OUT	TUN IN	H	OFF	TUN	TUN			
				H			VTR OUT	TUN IN	H	ON	AV2	AV2			
			AV1	L			VTR OUT	AV1 IN	H	OFF	AV1	AV1			
				H			VTR OUT	AV1 IN	H	ON	AV2	AV2			
			AV2	L			VTR OUT	AV1 IN	H	ON	AV2	AV2			
				H			VTR OUT	AV1 IN	H	ON	AV2	AV2			
			AV3	L			VTR OUT	AV1 IN	H	OFF	AV3	AV3			
				H			VTR OUT	AV1 IN	H	OFF	AV3	AV3			
		SAT.NOR TUN	L	VTR OUT			AV1 IN	H	OFF	SAT.TUN	SAT.TUN				
			H	VTR OUT			AV1 IN	H	OFF	SAT.TUN	SAT.TUN				
		SAT.C+ TUN	L	VTR OUT			SAT IN	H	OFF	SAT.TUN	SAT.TUN				
			H	VTR OUT			SAT IN	H	ON	AV2	AV2				
		VV	---	NORMAL TUN			L	VTR OUT	AV1 IN	H	OFF	TUN	PB		
							H	VTR OUT	AV1 IN	H	OFF	TUN	PB		
					C+ TUNER	L	VTR OUT	TUN IN	H	OFF	TUN	PB			
						H	VTR OUT	TUN IN	H	OFF	AV2	PB			
					AV1	L	VTR OUT	AV1 IN	H	OFF	AV1	PB			
						H	VTR OUT	AV1 IN	H	OFF	AV2	PB			
					AV2	L	VTR OUT	AV1 IN	H	OFF	AV2	PB			
						H	VTR OUT	AV1 IN	H	OFF	AV2	PB			
AV3	L				VTR OUT	AV1 IN	H	OFF	AV3	PB					
	H				VTR OUT	AV1 IN	H	OFF	AV3	PB					
SAT.NOR TUN	L			VTR OUT	AV1 IN	H	OFF	SAT.TUN	PB						
	H			VTR OUT	AV1 IN	H	OFF	SAT.TUN	PB						
SAT.C+ TUN	L			VTR OUT	SAT IN	H	OFF	SAT.TUN	PB						
	H			VTR OUT	SAT IN	H	OFF	AV2	PB						