

| INPUT CONDITION | | | | | VIDEO OUTPUT RESULT | | | | | | | | | AUDIO OUTPUT RESULT | | | | | | |
|-----------------|---|------------|-----------|--------------|---------------------|--------------|------------|------------|--------------|--------------|-----------|-----------|------------|---------------------|------------|--------|---------------------|---------------------|--------|--------|
| POWER | AV2 SELECT | TV/ VTR | EE/ VV | OSD ON(H) | INPUT CH | AV2 PB(H) | AV1 OUT | AV2 OUT | AV1 PB(H) | AV2 PB(H) | RGB SW | VCR IN | VCR OUT | AV1 Out | AV2 Out | RF (C) | AV1 Out Selector | AV2 Out Selector | | |
| P.ON | EXT or TIMER1 or TIMER2 | TV | EE | L | NO.TU | --- | VCR out | VCR out | L | L | OFF | TUN | TUN | TUN | TUN | TUN | TUN | TUN | INSEL | |
| | | | | | C+.TU | --- | VCR out | VCR out | L | L | OFF | TUN | TUN | TUN | TUN | TUN | TUN | TUN | INSEL | |
| | | | | | AV1 | --- | VCR out | VCR out | L | L | OFF | AV1 | AV1 | AV1 In | AV1 In | AV1 In | AV1 In | INSEL | | |
| | | | | | AV2 | --- | VCR out | VCR out | L | L | ON | AV2 | AV2 | AV2 In | AV2 In | AV2 In | AV2 In | INSEL | | |
| | | | | | AV3 | --- | VCR out | VCR out | L | L | OFF | AV3 | AV3 | AV3 In | AV3 In | AV3 In | AV3 In | INSEL | | |
| | | | | SAT.NO | --- | VCR out | VCR out | L | L | OFF | SAT | SAT | SAT | SAT | SAT | SAT | SAT | INSEL | | |
| | | | | SAT.C+ | --- | VCR out | VCR out | L | L | OFF | SAT | SAT | SAT | SAT | SAT | SAT | SAT | INSEL | | |
| | | | | H | NO.TU | --- | VCR out | VCR out | H | H | OFF | TUN | TUN | TUN | TUN | TUN | TUN | TUN | TUN | INSEL |
| | | | | | C+.TU | --- | VCR out | VCR out | H | H | OFF | TUN | TUN | TUN | TUN | TUN | TUN | TUN | TUN | INSEL |
| | | | | | AV1 | --- | VCR out | VCR out | H | H | OFF | AV1 | AV1 | AV1 In | AV1 In | AV1 In | AV1 In | INSEL | | |
| | | AV2 | --- | | VCR out | VCR out | H | H | OFF | AV2 | AV2 | AV2 In | AV2 In | AV2 In | AV2 In | INSEL | | | | |
| | | AV3 | --- | | VCR out | VCR out | H | H | OFF | AV3 | AV3 | AV3 In | AV3 In | AV3 In | AV3 In | INSEL | | | | |
| | | SAT.NO | --- | VCR out | VCR out | H | H | OFF | SAT | SAT | SAT | SAT | SAT | SAT | SAT | INSEL | | | | |
| | | SAT.C+ | --- | VCR out | VCR out | H | H | OFF | SAT | SAT | SAT | SAT | SAT | SAT | SAT | INSEL | | | | |
| | | VTR | EE | L | NO.TU | --- | VCR out | VCR out | H | H | OFF | TUN | TUN | TUN | TUN | TUN | TUN | TUN | TUN | INSEL |
| | | | | | C+.TU | --- | VCR out | VCR out | H | H | OFF | TUN | TUN | TUN | TUN | TUN | TUN | TUN | INSEL | |
| | | | | | AV1 | --- | VCR out | VCR out | H | H | OFF | AV1 | AV1 | AV1 In | AV1 In | AV1 In | AV1 In | INSEL | | |
| | | | | | AV2 | L | VCR out | VCR out | H | H | ON | AV2 | AV2 | AV2 In | AV2 In | AV2 In | AV2 In | INSEL | | |
| | | | | M/H | VCR out | VCR out | M/H | M/H | ON | AV2 | AV2 | AV2 In | AV2 In | AV2 In | AV2 In | INSEL | | | | |
| | AV3 | | | --- | VCR out | VCR out | H | H | OFF | AV3 | AV3 | AV3 In | AV3 In | AV3 In | AV3 In | INSEL | | | | |
| | SAT.NO | | | --- | VCR out | VCR out | H | H | OFF | SAT | SAT | SAT | SAT | SAT | SAT | SAT | INSEL | | | |
| | SAT.C+ | | | --- | VCR out | VCR out | H | H | OFF | SAT | SAT | SAT | SAT | SAT | SAT | SAT | INSEL | | | |
| | H | NO.TU | --- | VCR out | VCR out | H | H | OFF | TUN | TUN | TUN | TUN | TUN | TUN | TUN | TUN | TUN | INSEL | | |
| | | C+.TU | --- | VCR out | VCR out | H | H | OFF | TUN | TUN | TUN | TUN | TUN | TUN | TUN | TUN | INSEL | | | |
| EXT | VTR | EE | H | AV1 | --- | VCR out | VCR out | H | H | OFF | AV1 | AV1 | AV1 In | AV1 In | AV1 In | AV1 In | AV1 In | INSEL | | |
| | | | | AV2 | --- | VCR out | VCR out | H | H | OFF | AV2 | AV2 | AV2 In | AV2 In | AV2 In | AV2 In | INSEL | | | |
| | | | | AV3 | --- | VCR out | VCR out | H | H | OFF | AV3 | AV3 | AV3 In | AV3 In | AV3 In | AV3 In | INSEL | | | |
| | | | | SAT.NO | --- | VCR out | VCR out | H | H | OFF | SAT | SAT | SAT | SAT | SAT | SAT | INSEL | | | |
| | | | | SAT.C+ | --- | VCR out | VCR out | H | H | OFF | SAT | SAT | SAT | SAT | SAT | SAT | INSEL | | | |
| | | | VV | --- | NO.TU | --- | VCR out | VCR out | M/H | M/H | OFF | TUN | PB | PB | PB | PB | PB | TUN | INSEL | |
| | | | | | C+.TU | --- | VCR out | VCR out | M/H | M/H | OFF | TUN | PB | PB | PB | PB | PB | TUN | INSEL | |
| | | | | | AV1 | --- | VCR out | VCR out | M/H | M/H | OFF | AV1 | PB | PB | PB | PB | PB | AV1 In | INSEL | |
| | | AV2 | --- | VCR out | VCR out | M/H | M/H | OFF | AV2 | PB | PB | PB | PB | PB | PB | AV2 In | INSEL | | | |
| | | AV3 | --- | VCR out | VCR out | M/H | M/H | OFF | AV3 | PB | PB | PB | PB | PB | PB | AV3 In | INSEL | | | |
| | | SAT.NO | --- | VCR out | VCR out | M/H | M/H | OFF | SAT | PB | PB | PB | PB | PB | PB | SAT | INSEL | | | |
| | | SAT.C+ | --- | VCR out | VCR out | M/H | M/H | OFF | SAT | PB | PB | PB | PB | PB | PB | SAT | INSEL | | | |
| | | DECODER | TV | EE | L | NO.TU | L | VCR out | AV1 In | L | L | OFF | TUN | TUN | TUN | AV1 In | TUN | TUN | TUN | AV1 In |
| | | | | | | | M/H | AV2 In | AV1 In | M/H | L | ON | TUN | TUN | AV2 In | AV1 In | TUN | AV2 In | AV1 In | |
| | | | | | | C+.TU | L | VCR out | TUN IN | L | L | OFF | TUN | TUN | TUN | TUN | TUN | TUN | TUN | |
| | | | | | | | M/H | VCR out | TUN IN | L | L | OFF | AV2 | AV2 | AV2 In | TUN | AV2 In | AV2 In | TUN | |
| AV1 | L | | | | | VCR out | AV1 In | L | L | OFF | AV1 | AV1 | AV1 In | AV1 In | AV1 In | AV1 In | AV1 In | | | |
| | M/H | | | | | AV2 In | AV1 In | M/H | L | ON | AV2 | AV2 | AV2 In | AV1 In | AV2 In | AV2 In | AV1 In | | | |
| AV2 | L | | | | | VCR out | AV1 In | L | L | ON | AV2 | AV2 | AV2 In | AV1 In | AV2 In | AV2 In | AV1 In | | | |
| | M/H | | | | | AV2 In | AV1 In | M/H | L | ON | AV2 | AV2 | AV2 In | AV1 In | AV2 In | AV2 In | AV1 In | | | |
| AV3 | L | VCR out | AV1 In | L | | L | OFF | AV3 | AV3 | AV3 In | AV1 In | AV3 In | AV3 In | AV1 In | | | | | | |
| | M/H | AV2 In | AV1 In | M/H | | L | ON | AV3 | AV3 | AV2 In | AV1 In | AV3 In | AV2 In | AV1 In | | | | | | |
| SAT.NO | L | VCR out | AV1 In | L | | L | OFF | SAT | SAT | SAT | AV1 In | SAT | SAT | AV1 In | | | | | | |
| | M/H | AV2 In | AV1 In | M/H | | L | ON | SAT | SAT | AV2 In | AV1 In | SAT | AV2 In | AV1 In | | | | | | |
| SAT.C+ | L | VCR out | SAT IN | L | | L | OFF | SAT | SAT | SAT | SAT | SAT | SAT | TUN | | | | | | |
| | M/H | VCR out | SAT IN | L | | L | OFF | AV2 | AV2 | AV2 In | SAT | AV2 In | AV2 In | TUN | | | | | | |
| H | NO.TU | L | VCR out | AV1 In | H | L | OFF | TUN | TUN | TUN | AV1 In | TUN | TUN | TUN | TUN | AV1 In | | | | |
| | | M/H | VCR out | AV1 In | H | L | OFF | TUN | TUN | TUN | AV1 In | TUN | TUN | TUN | AV1 In | | | | | |
| | C+.TU | L | VCR out | TUN IN | H | L | OFF | TUN | TUN | TUN | TUN | TUN | TUN | TUN | TUN | | | | | |
| | | M/H | VCR out | TUN IN | H | L | OFF | AV2 | AV2 | AV2 In | TUN | AV2 In | AV2 In | TUN | | | | | | |
| | AV1 | L | VCR out | AV1 In | H | L | OFF | AV1 | AV1 | AV1 In | AV1 In | AV1 In | AV1 In | AV1 In | | | | | | |
| | | M/H | VCR out | AV1 In | H | L | OFF | AV2 | AV2 | AV2 In | AV1 In | AV2 In | AV2 In | AV1 In | | | | | | |
| | AV2 | L | VCR out | AV1 In | H | L | OFF | AV2 | AV2 | AV2 In | AV1 In | AV2 In | AV2 In | AV1 In | | | | | | |
| | | M/H | VCR out | AV1 In | H | L | OFF | AV2 | AV2 | AV2 In | AV1 In | AV2 In | AV2 In | AV1 In | | | | | | |
| | AV3 | L | VCR out | AV1 In | H | L | OFF | AV3 | AV3 | AV3 In | AV1 In | AV3 In | AV3 In | AV1 In | | | | | | |
| | | M/H | VCR out | AV1 In | H | L | OFF | AV3 | AV3 | AV3 In | AV1 In | AV3 In | AV3 In | AV1 In | | | | | | |
| | SAT.NO | L | VCR out | AV1 In | H | L | OFF | SAT | SAT | SAT | AV1 In | SAT | SAT | AV1 In | | | | | | |
| | | M/H | VCR out | AV1 In | H | L | OFF | SAT | SAT | SAT | AV1 In | SAT | SAT | AV1 In | | | | | | |
| SAT.C+ | L | VCR out | SAT IN | H | L | OFF | SAT | SAT | SAT | SAT | SAT | SAT | SAT | | | | | | | |
| | M/H | VCR out | SAT IN | H | L | ON | AV2 | AV2 | AV2 In | SAT | AV2 In | AV2 In | SAT | | | | | | | |