

IC6001 KEY MATRIX			
OUT IN	SCAN 1 PIN 93	SCAN 2 PIN 94	
DATA 8 PIN 40	—	REW /REV	
DATA 9 PIN 41	—	PLAY	
DATA 10 PIN 43	—	STOP /EJECT	
DATA 11 PIN 44	POWER	CH DOWN	
DATA 12 PIN 45	CH UP	TV/VCR	
DATA 13 PIN 46	REC /TIME	FF /CUE	

NOTE:  
FOR SCHEMATIC DIAGRAM AND CIRCUIT BOARD LAYOUT NOTES,  
REFER TO BEGINNING OF SCHEMATIC SECTION IN ORIGINAL SERVICE MANUAL.

NOTE:  
PARTS ENCLOSED IN DASHED LINES MARKED "Z" ARE NOT USED.

