




NOTE:
FOR SCHEMATIC DIAGRAM AND CIRCUIT BOARD LAYOUT NOTES,
REFER TO BEGINNING OF SCHEMATIC SECTION IN ORIGINAL SERVICE MANUAL.




WF1




WF6




WF11




WF16




WF19




WF23




WF27




WF32




WF2




WF7




WF12




WF17




WF20




WF23




WF27




WF33




WF3




WF7




WF13




CH1 WF18
CH2 WF22




WF20




WF23




WF28




WF4




WF8




WF14




CH1 WF18
CH2 WF22




WF20




WF24




WF29




WF5




WF9




WF15




CH1 WF18
CH2 WF22




WF21




WF25




WF30




WF6




WF10




WF16



WF22



WF26



WF31