


3-23 DRIVE SCHEMATIC DIAGRAM

← CAPSTAN SERVO SPEED LOOP
 ← CAPSTAN SERVO PHASE LOOP


← CYLINDER SERVO SPEED LOOP
 ← CYLINDER SERVO PHASE LOOP



E SCHEMATIC DIAGRAM

← CAPSTAN SERVO SPEED LOOP
 ← CAPSTAN SERVO PHASE LOOP

← CYLINDER SERVO SPEED LOOP
 ← CYLINDER SERVO PHASE LOOP



NOTE: THE WAVEFORM OF THIS DIAGRAM IS MEASURED WITH AIM THE CAMERA AT THE LOGARITHMIC GRAY SCALE CHART OR COLOUR CHART.

NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKETS () ON THIS DIAGRAM IS RECORD MODE WITH AIM THE CAMERA AT THE COLOR CHART.

THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE WITH PAL COLOUR SIGNAL.