



02/20/2001

POWERWARE® 9125

2-Post Rail Kit

Powerware is a registered trademark of Powerware Corporation.

©Copyright 2000 Powerware Corporation, Raleigh, NC, USA. All rights reserved. No part of this document may be reproduced in any way without the express written approval of Powerware Corporation.



RAIL KIT INSTALLATION

The 2-post rail kit includes:

- Two rails
- Four truss-head 10-32 \times 1/2" screws
- Two Z-brackets
- Two L-brackets
- Two PHMS 8-32 \times 1/4" screws


Before installing the rail kit, you will need:

- A Phillips screwdriver
- Four PHMS 12-24 \times 1/2" screws


Installing the UPS Rail Kit

The following steps explain how to install the UPS rail kit.



1. Attach each rail to the rack post using the four customer-supplied screws (PHMS 12-24 \times 1/2").



2. If you are using the L-bracket to secure the back of the UPS, remove the two bottom corner screws from the UPS rear panel and retain (see Step 4).
3. Lift the UPS and slide it into the rack.



4. Secure the back of the UPS to the rails with the supplied brackets and screws.



5. Secure the front of the UPS to the rack using the supplied truss-head screws.

The UPS is now secured in the rack.

