

NVM MAP

ADD (HEX)	DESCRIPTION																
00	RED COLOUR TEMPERATURE																
01	GREEN COLOUR TEMPERATURE																
02	BLUE COLOUR TEMPERATURE																
03	VERTICAL POSITION																
04	HORIZONTAL PHASE CONTROL																
05	VERTICAL AMPLITUDE																
06	VERTICAL BREATHING CORRECTION																
07	VERTICAL LINEARITY																
08	LUMA DELAY PAL																
09	LUMA DELAY SECAM																
0A	AGC																
0B	<p>OPTIONS:</p> <table border="1" style="margin-left: 40px;"> <tr> <td>ING_OSD</td> <td>A_F</td> <td>CHL</td> <td>PAL</td> <td>UHF</td> <td>T_LOCK</td> <td>AV_F</td> <td>FP</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> </table> <p>0: FP: SYSTEM B/G (0) - B/G+L, MESSAGE RECHERCHE (1) 1: AV FRONTAL: NOT INCLUDED (0), INCLUDED (1) 2: TUNING LOCK: LOCKED (1), NOT LOCKED (0) 3: UHF ONLY: BAND UHF (1) - ALL BANDS (0) 4: PAL ONLY (1), PAL+SECAM (0) 5: CHILD LOCK: CHILD LOCK ACTIVE (1) CHILD LOCK NO ACT (0) 6: AUTO FIRST: TUNING FIRST MENU: AUTO (1) MANUAL (0) 7: ING_OSD: OSD_INGLES (1) OSD_SYMBOL (0)</p>	ING_OSD	A_F	CHL	PAL	UHF	T_LOCK	AV_F	FP	7	6	5	4	3	2	1	0
ING_OSD	A_F	CHL	PAL	UHF	T_LOCK	AV_F	FP										
7	6	5	4	3	2	1	0										
0C	AFT ADJUSTMENT VALUE (B/G, L SYSTEMS)																
0D	AFT ADJUSTMENT VALUE (L' SYSTEM)																
0E	MAXIMUM VOLUME LIMIT																
0F	FIRM																
10	RED COLOUR TEMPERATURE																
11	GREEN COLOUR TEMPERATURE																
12	BLUE COLOUR TEMPERATURE																
13	VERTICAL POSITION																
14	HORIZONTAL PHASE CONTROL																
15	VERTICAL AMPLITUDE																
16	VERTICAL BREATHING CORRECTION																
17	VERTICAL LINEARITY																

ADD (HEX)	DESCRIPTION																
18	LUMA DELAY PAL																
19	LUMA DELAY SECAM																
1A	AGC																
1B	<p>OPTIONS:</p> <table border="1" data-bbox="399 399 1149 493"> <tr> <td>ING_OSD</td> <td>A_F</td> <td>CHL</td> <td>PAL</td> <td>UHF</td> <td>T_LOCK</td> <td>AV_F</td> <td>FP</td> </tr> <tr> <td>7</td> <td>6</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> <td>0</td> </tr> </table> <p>0: FP: SYSTEM B/G (0) - B/G+L, MESSAGE RECHERCHE (1) 1: AV FRONTAL: NOT INCLUDED (0), INCLUDED (1) 2: TUNING LOCK: LOCKED (1), NOT LOCKED (0) 3: UHF_ONLY: BAND UHF (1) - ALL BANDS (0) 4: PAL ONLY (1), PAL+SECAM (0) 5: CHILD LOCK: CHILD LOCK ACTIVE (1) CHILD LOCK NO ACT (0) 6: AUTO FIRST: TUNING FIRST MENU: AUTO (1) MANUAL (0) 7: ING_OSD: OSD_INGLES (1) OSD_SYMBOL (0)</p>	ING_OSD	A_F	CHL	PAL	UHF	T_LOCK	AV_F	FP	7	6	5	4	3	2	1	0
ING_OSD	A_F	CHL	PAL	UHF	T_LOCK	AV_F	FP										
7	6	5	4	3	2	1	0										
1C	AFT ADJUSTMENT VALUE (B/G, L SYSTEMS)																
1D	AFT ADJUSTMENT VALUE (L' SYSTEM)																
1E	MAXIMUM VOLUME LIMIT																
1F	FIRM																
20	RED COLOUR TEMPERATURE																
21	GREEN COLOUR TEMPERATURE																
22	BLUE COLOUR TEMPERATURE																
23	VERTICAL POSITION																
24	HORIZONTAL PHASE CONTROL																
25	VERTICAL AMPLITUDE																
26	VERTICAL BREATHING CORRECTION																
27	VERTICAL LINEARITY																
28	LUMA DELAY PAL																
29	LUMA DELAY SECAM																
2A	AGC																
2B	<p>OPTIONS:</p> <table border="1" data-bbox="399 1680 1149 1774"> <tr> <td>ING_OSD</td> <td>A_F</td> <td>CHL</td> <td>PAL</td> <td>UHF</td> <td>T_LOCK</td> <td>AV_F</td> <td>FP</td> </tr> <tr> <td>7</td> <td>6</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> <td>0</td> </tr> </table> <p>0: FP: SYSTEM B/G (0) - B/G+L, MESSAGE RECHERCHE (1) 1: AV FRONTAL: NOT INCLUDED (0), INCLUDED (1) 2: TUNING LOCK: LOCKED (1), NOT LOCKED (0) 3: UHF_ONLY: BAND UHF (1) - ALL BANDS (0) 4: PAL ONLY (1), PAL+SECAM (0) 5: CHILD LOCK: CHILD LOCK ACTIVE (1) CHILD LOCK NO ACT (0) 6: AUTO FIRST: TUNING FIRST MENU: AUTO (1) MANUAL (0) 7: ING_OSD: OSD_INGLES (1) OSD_SYMBOL (0)</p>	ING_OSD	A_F	CHL	PAL	UHF	T_LOCK	AV_F	FP	7	6	5	4	3	2	1	0
ING_OSD	A_F	CHL	PAL	UHF	T_LOCK	AV_F	FP										
7	6	5	4	3	2	1	0										

ADD (HEX)	DESCRIPTION
2C	AFT ADJUSTMENT VALUE (B/G, L SYSTEMS)
2D	AFT ADJUSTMENT VALUE (L' SYSTEM)
2E	MAXIMUM VOLUME LIMIT
2F	FIRM
30	TABLE LONG
31	FIRM
32	AGING ON. AUTOMATIC SWITCH ON.
33	SWITCH ON DELAY TIME
34	VOLUME
35	CONTRAST
36	COLOUR
37	BRIGHTNESS
38	PEAKING (RANGE: 1-7)
39	ACTUAL PROGRAMM
3A	TV STATE ON/OFF
3B	DECIMAL VOLUME VALUE (FACTORY PRESET)
3C	CONTRAST (FACTORY PRESET)
3D	COLOUR (FACTORY PRESET)
3E	BRIGHTNESS (FACTORY PRESET)
3F	PEAKING (RANGE: 0-7) (FACTORY PRESET)
40	ON TIMER LAST VALUE
41	OFF TIMER LAST VALUE

ADD (HEX)	DESCRIPTION
42-B9	PROGRAMS
BA (37AM-23H)	OSD STATE (X,X,X,X,X, CHILD_FRONT, CHILD_AV, NORM ON/OFF)
BA (35AT-25H)	OSD STATE BIT 0: PICTURE NORM ON/OFF BIT 1: SCART/AV LOCKED BIT 2: FRONTAL LOCKED BIT 3: ROW 8/30 PERMISS (PROGRAMMED INTERNALLY) BIT 4: PIN NUMBER OPTION (0-NOT APPEAR, 1-APPEAR) BIT 5: CLOCK STATE (PROGRAMMED INTERNALLY) BIT 6: ELIMINATE VERTICAL WHITE BARS IN MENUS BIT 7: X
BB	BKGD USER'S CORRECTION (NOT USED IN THIS MODEL)
BC	BKGD USER'S CORRECTION PRESET VALUE (NORMALIZED) (")
BD	VOLTAGE LIMIT BETWEEN L'-L SYSTEMS (MSB)
BE	VOLTAGE LIMIT BETWEEN L'-L SYSTEMS (LSB)
BF (37AM-23H)	HORIZONTAL OSD OFFSET
BF (37AT-25H)	HORIZONTAL OSD OFFSET BIT 7: DIRECTION SIGN: (0) INCREASE (1) DECREASE BIT 6: DON'T CARE BIT 5 - BIT 0: OFFSET VALUE
C0	PROG SEARCH SPEED (ALL BANDS) -HIGH NIBBLE COMPLEMENTED-
C1	PROG SEARCH SPEED (UHF BAND) -HIGH NIBBLE COMPLEMENTED-
C2	PROG SEARCH SPEED (VHL BAND) -HIGH NIBBLE COMPLEMENTED-
C3	PROG SEARCH SPEED (VHH BAND) -HIGH NIBBLE COMPLEMENTED-
C4	CHANNEL RANGE IN FACTORY AUTOINSTALL
C5	PASSWORD ON(1)/OFF(0)
C6	PASSWORD FIRST DIGIT
C7	PASSWORD SECOND DIGIT
C8	PASSWORD THIRD DIGIT
C9	PASSWORD FOURTH DIGIT
CA-CF	FREE
DO-FF (37AM-23H)	FREE
DO-FF (37AT-25H)	LIST STORED PAGES (8 PROGRAMS) (6 BYTES PER PROGRAM)

7. The changes introduced are automatically memorized.

8. Having finalized adjustments, push MODE button on R/C to exit Service Mode.