

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

PLUG-IN UNIT, ELECTRICAL

TEKTRONIX, TYPE 067-0938-00

APN 7917073

NSN 6625-01-264-3046

Current as of 17 May 14

Approved for public release, distribution is unlimited

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms) to: Commander, U.S. Army TMDE Support Group, ATTN: AMXTH-LML, Redstone Arsenal, AL 35898-5400. A reply will be furnished directly to you.

TABLE OF CONTENTS

			Page
Section	I.	INTRODUCTION	1
Section	II.	REPAIR PARTS LIST	
Group	0010	PLUG-IN, ELECTRICAL, MAINFRAME	2-1
	0020	CIRCUIT CARD ASSEMBLY	2-2
Section	III.	SPECIAL TOOLS LIST (Not applicable)	
Section	IV.	CROSS REFERENCE INDEXES	I-1

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

SECTION I. INTRODUCTION

1. Scope. This RPSTL lists and authorizes spares and repair parts required for performance of direct and general support maintenance of the Plug-in Unit, Electrical, Tektronix, Type 067-0938-00. It authorizes the requisitioning, issue, and disposition of spares and repair parts as indicated by the Source, Maintenance and Recoverability (SMR) codes.

2. General. In addition to this Section I, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. Parts lists are composed of functional groups in ascending numeric sequence. Parts are listed in alphabetical sequence within each group and figure number.


b. Section III. Special Tools List. Not applicable.

c. Section IV. Cross Reference Indexes. A list, in National Item Identification Number (NIIN) sequence, of all National Stock Numbered (NSN) items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listing. NSN's and part numbers are cross-referenced to each illustration figure and item number appearance. The figure and item number index lists figure and item numbers in alphanumeric sequence and cross-reference NSN, FSCM, and part numbers.

3. Explanation of Columns (Section II)

a. ITEM NUMBER (Column (1)). Indicates the number used to identify each item appearing in the listing.

b. SMR CODE (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instructions as shown in the following breakout:



*Complete Repair: Maintenance capacity, capability, and authority to perform all the corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.

(1) **Source Code.** The source code tells you how you get an item needed for maintenance, repair, or overhaul of an end item/equipment. Source codes are always the first two positions of the SMR code. Explanation of source codes follows:

Code	Explanation
PA -	Stocked items use the applicable NSN to request/requisition items with this code. This item is authorized to the category indicated by the code entered in the 3d position of the SMR code.

(2) **Maintenance Code.** Maintenance codes tell you the level(s) of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the SMR code as follows:

(a) The maintenance code entered in the third position tells you the maintenance level authorized to remove, replace, and use an item. The maintenance code entered in the third position will indicate authorization to the following level of maintenance.

Code	Application/Explanation
F -	Direct support level can remove, replace, and use the item.

(b) The maintenance code entered in the fourth position tells you whether or not the item is to be repaired and identifies the lowest maintenance level with the capability to do complete repair (i.e., perform all authorized repair functions). This position will contain one of the following codes.

Code	Application/Explanation
F -	Direct support is the lowest level that can do complete repair of the item.
Z -	Nonreparable. No repair is authorized.

(3) **Recoverability Code.** Recoverability codes are assigned to items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the SMR code as follows:

Recoverability Codes	Definition
F -	Reparable item. When uneconomically reparable, condemn and dispose of the item at the direct support level.
Z -	Nonreparable item. When unserviceable, condemn and dispose of the item at the level of maintenance shown in the third position of the SMR code.
A -	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material, or hazardous material). Refer to appropriate manuals/directives for specific instructions.

c. FSCM (Column (3)). The Federal Supply Code for Manufacturer (FSCM) is a 5-digit numeric code which is used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

d. PART NUMBER (Column (4)). Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE: When you use an NSN to requisition an item, the item you receive may have a different part number from the part ordered, but go ahead and use or furnish it as the replacement part.

e. DESCRIPTION AND USABLE ON CODE (UOC) (Column (5)). This column includes the following information:

- (1) The Federal item name and, when required, a minimum description to identify the item.
- (2) The usable on code, when applicable (see paragraph 5, Special Information).

f. QUANTITY (Column (6)). The quantity (quantity per figure column) indicates the quantity of the item used in the parts list which is prepared for a functional group, subfunctional group, or an assembly.

4. Explanation of Columns (Section IV)

a. NATIONAL STOCK NUMBER (NSN) INDEX

(1) **STOCK NUMBER column.** This column lists the NSN by National Item Identification Number (NIIN) sequence. The NIIN consists of the last nine digits of the NSN
NSN
 (i.e., 5305-01-674-1467). When using this column to locate an item, ignore the first 4 digits of the NSN. However, the
NIIN
 complete NSN should be used when ordering items by stock number.

(2) **FIGURE column.** Indicates the figure number used to identify each item appearing in the listing. The figures are in numerical order in Section II.

(3) **ITEM column.** The item number identifies the item associated with the figure listed in the adjacent figure column. This item is also identified by the NSN listed on the same line.

b. PART NUMBER INDEX. Part numbers in this index are listed by part number in ascending alphanumeric sequence (i.e., vertical arrangement of letter and number combination which places the first letter or digit of each group in order A through Z, followed by the numbers 0 through 9 and each following letter or digit in like order).

(1) **FSCM column.** The Federal Supply Code for Manufacturer (FSCM) is a 5-digit numeric code used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

(2) **PART NUMBER column.** Indicates the primary number used by the manufacturer (individual, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

(3) **STOCK NUMBER column.** This column lists the NSN for the associated part number and manufacturer identified in the PART NUMBER and FSCM columns to the left. The part number line entry (with NSN, when available) identifies the first figure/item number appearance for which the part number is applicable. The part number is not listed for additional figure/item number appearances identified by that part number.

(4) **FIGURE column.** This column lists the number of the figure where the item is located in Section II.

(5) **ITEM column.** The item number is that number assigned to the item as it appears in the figure referenced in the adjacent figure number column.

c. FIGURE AND ITEM NUMBER INDEX

(1) **FIGURE column.** This column lists the number of the figure where the item is identified/located in Section II.

(2) **ITEM column.** The item number is that number assigned to the item as it appears in the figure referenced in the adjacent figure number column.

(3) **STOCK NUMBER column.** This column lists the NSN for the item.

(4) **FSCM column.** The Federal Supply Code for Manufacturer (FSCM) is a 5-digit numeric code used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

(5) **PART NUMBER column.** Indicates the primary number used by the manufacturer (individual, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

5. Special Information

a. Repair parts for components of standards sets which can be identified as existing in the supply system will be requisitioned through normal supply channels from the appropriate supply commodity manager.

b. Repair parts for components of standards sets which cannot be identified as to proper supply source will be requisitioned from USAMICOM, using routing identifier B64 and furnishing, as a minimum, the following as exception data:

(1) Component stock number of the individual end item to be repaired.

(2) Component manufacturer's equipment model number and serial number.

(3) The equipment manufacturer's reference number as listed in the appropriate manual for the desired repair part.

(4) The repair part reference designation, circuit reference, circuit symbol schematic designation, or reference number as listed in the manufacturer's manual.

(5) The technical specification of the repair part as contained in the appropriate manufacturer's manual.

(6) The title and date of the manufacturer's manual from which the information in a and b(3), (4), and (5) above was taken.

c. For requisitioning miscellaneous consumable maintenance supplies or expendable supplies, use CTA 50-970.

d. The usable on code appears in the lower left corner of the Description column heading. Usable on codes are shown as "UOC" in the Description column (justified left) on the first line applicable item description/nomenclature. Uncoded items are applicable to all models.

e. This RPSTL does not contain illustrations for items listed in Section II, since the manufacturer's manual contains exploded view illustrations which are adequate for repair parts location. Copies of the manufacturer's manual for the Plug-in, Electrical, Tektronix, Type 067-0938-00 are furnished with the equipment for which this RPSTL is prepared. The figure and item numbers in the listing are for locating the item within this RPSTL.

6. How to Locate Repair Parts

a. When National Stock Number or Part Number is Not Known.

(1) **First.** Refer to the parts list to locate the item by description. This list is in alphabetical sequence within each group and figure number. Identification of group and figure numbers and the manufacturer's manual locational figure numbers are listed below:

Group	Figure	Manufacturer's Manual Locational Figure	Nomenclature	Part Number
0010	1	Figure 8-1	Plug-in Unit, Electrical	067-0938-00
0020	2	Figure 1	Circuit Card Assembly	672-0855-00

(2) **Second.** After locating the item in the Repair Parts List, refer to the Part Number Index to find the NSN.

b. When National Stock Number or Part Number is Known.

(1) **First.** Using the Index of National Stock Numbers and Part Numbers, find the pertinent National Stock Number or Part Number. The NSN index is in National Item Identification Number (NIIN) sequence. The part numbers in the Part Number index are listed in ascending alphanumeric sequence. Both indexes cross-reference you to the illustration figure and item number of the item you are looking for.

(2) **Second.** After finding the figure and item number, verify that the item is the one you're looking for, then locate the item number in the repair parts list for the figure.

7. Abbreviations. Not applicable.

SECTION II

TM 9-6625-2212-34P

(1) ITEM NO	(2) SMR CODE	(3) CAGEC	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
				GROUP 0010 - FIGURE 1 PLUG-IN UNIT, ELECTRICAL 7917073 (11876) 067-0938-00 (80009)	
10	PAFZZ	80009	401-0180-00	BRACKET, EYE, ROTATION 1-28.....	1
20	PAFZZ	80009	358-0029-00	BUSHING, MACHINE THR 1-3.....	1
30	PAFFF	80009	672-0855-00	CIRCUIT CARD ASSEMB A10 (FOR..... PANTS SEE GROUP 0020, FIGURE 2)	1
40	PAFZZ	80009	352-0169-01	CONNECTOR BODY, PLUG.....	1
50	PAFZA	96214	972487-0001	CONNECTOR, PLUG, ELEC 1-39.....	1
60	PAFZZ	18876	10684234	CONNECTOR, RECEPTACL J570.....	1
70	PAFZZ	18876	10672091	CONNECTOR, RECEPTACL J570.....	2
80	PAFZZ	80009	131-0604-00	CONTACT ASSEMBLY, EL 1-38.....	25
90	PAFZZ	80009	131-0963-00	CONTACT, ELECTRICAL.....	1
100	PAFZZ	80009	384-1136-00	EXTENSION SHAFT 1-22.....	1
110	PAFZZ	80009	426-0725-00	HOLDER, ELECTRICAL C 1-50.....	1
120	PAFZZ	80009	426-0724-00	HOLDER, ELECTRICAL C 1-51.....	1
110	PAFZZ	80009	401-0178-01	HOUSING, BEARING UNI 1-29.....	1
140	PAFZZ	80009	386-3657-01	JACKSCREW, ELECTRICA 1-48.....	2
150	PAFZZ	80009	366-1120-00	KNOB 177.....	2
155	PAFZZ	80009	366-1690-00	KNOB 1-12.....	1
160	PAFZA	80009	366-0500-00	KNOB 1-2.....	1
170	PAFZZ	80009	366-1023-00	KNOB 1-6.....	2
180	PAFZZ	80009	105-0719-00	LATCH 1-16.....	1
190	PAFZZ	80009	105-0718-01	BAR, LATCH RELEASE 1-18.....	1
200	PAFZZ	75743	2X28269-402	NUT, PLAIN, HEXAGON 1-4.....	1
210	PAFZZ	80009	210-0406-00	NUT, PLAIN, HEXAGON 1-30.....	10
220	PAFZZ	80009	210-0590-00	NUT, PLAIN, HEXAGON 1-4.....	1
230	PAFZZ	80009	337-1399-00	PLATE, ELECTRICAL SH 1-1.....	2
240	PAFZZ	80009	366-1512-00	PUSH BUTTON 1-13.....	1
250	PAFZZ	80009	366-1559-00	PUSH BUTTON 1-14.....	1
260	PAFZZ	81349	RCR07G510JS	RESISTOR, FIXED, COMP R1422.....	1
270	PAFZZ	79136	5100-37MD	RING, RETAINING 1-34.....	1
280	PAFZZ	80009	214-1752-00	ROLLER, DETENT 1-33.....	2
290	PAFZZ	80009	211-0678-00	SCREW, ASSEMBLED WAS 1-24.....	6
300	PAFZZ	80009	213-0123-00	SCREW, TAPPING, THREA 1-20.....	4
310	PAFZZ	80009	213-0113-00	SCREW, TAPPING, THREA 1-17.....	1
320	PAFZZ	80009	213-0146-00	SCREW, TAPPING, THREA 1-23.....	4
340	PAFZZ	80009	361-0685-00	SPACER, SWITCH 1-42.....	2
350	PAFZZ	80009	214-1061-00	SPRING, FLAT 1-49.....	1
360	PAFZZ	80009	214-1139-02	SPRING, FLAT 1-32.....	1
370	PAFZZ	80009	214-1139-03	SPRING, FLAT.....	1
380	PAFZZ	80009	361-0383-00	MOUNTING PAD, ELECTR 1-44.....	2
390	PAFZZ	76471	210-0978-00	WASHER, FLAT 1-5.....	1

SECTION II

TM 9-6625-2212-34P

(1) ITEM NO	(2) SMR CODE	(3) CAGEC	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 0020 - FIGURE 2					
CIRCUIT CARD ASSEMBLY					
672-0855-00 (80009)					
20	PAFZZ	28480	1258-0141	CONNECTOR, ELECTRICAL.....	1
30	PAFZZ	80009	283-0169-00	CAPACITOR, FIXED, CER C1431	1
40	PAFZZ	80009	285-1067-00	CAPACITOR, FIXED, MET C1332	2
50	PAFZZ	14752	230B1C105F	CAPACITOR, FIXED, MET C1326	1
60	PAFZZ	80009	285-1066-00	CAPACITOR, FIXED, MET C1325	2
70	PAFZZ	14702	230B1C104F	CAPACITOR, FIXED, MET C1331	1
80	PAFZZ	14/52	230B1C505F	CAPACITOR, FIXED, MET C1111	6
90	PAFZZ	00853	D153F791F0	CAPACITOR, FIXED, MIC C1322	2
100	PAFZZ	00853	D151E161F0	CAPACITOR, FIXED, MIC C1320	1
110	PAFZZ	80249	270332	CAPACITOR, FIXED, MIC C1311	1
120	PAFZZ	80009	285-1062-00	CAPACITOR, FIXED, PLA C1212	6
130	PAFZZ	80009	131-1425-00	CONTACT ASSEMBLY, EL J1331	1
140	PAFZZ	22526	65500-136	CONTACT ASSEMBLY, EL J1421	1
150	PAFZZ	73743	2X12161-402	NUT, PLAIN, HEXAGON.....	1
160	PAFZZ	80009	213-0232-00	SCREW, TAPPING, THREA.....	1
170	PAFZZ	80009	213-0717-00	SCREW, TAPPING, THREA.....	1
180	PAFZZ	80009	260-1209-00	SWITCH, PUSH.....	1
190	PAFZZ	80009	260-1208-00	SWITCH, PUSH S1432	1
200	PAFZZ	81349	RCR07G910JS	RESISTOR, FIXED, COMP R1425.....	1
210	PAFZZ	81349	RCR07G360JS	RESISTOR, FIXED, COMP R1431	1
220	PAFZZ	81349	RNC55J2002BS	RESISTOR, FIXED, FILM R1432	1
230	PAFZZ	81349	RNC55J3011BS	RESISTOR, FIXED, FILM R1424	1
240	PAFZZ	81349	RNC55K7681FS	RESISTOR, FIXED, FILM R1422	1
25U	PAFZZ	81349	RNC55K1740FS	RESISTOR, FIXED, FILM R1423	1
260	PAFZZ	81349	RNC55H5001BS	RESISTOR, FIXED, FILM R1421	1
270	PAFZZ	81349	RNC55K6191FS	RESISTOR, FIXED, FILM R1333	1
280	PAFZZ	81349	RNC55J2001BS	RESISTOR, FIXED, FILM R1332	1

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5310-00-006-8167	1	220	5999-01-088-7088	1	110
5905-00-106-1249	1	260	5998-01-088-7089	1	120
	2	200	5305-01-137-7034	1	310
5905-00-126-6698	2	210	5305-01-144-3893	2	170
5905-00-137-4511	2	220	5999-01-149-8316	1	80
5905-00-138-3291	2	280	5935-01-156-5524	2	20
5905-00-250-6045	2	250	5310-01-156-6423	1	210
5310-00-407-4600	2	150	5935-01-165-1782	1	50
5310-00-407-4601	1	200	5305-01-199-4348	2	160
5355-00-409-7131	1	150	5930-01-201-2103	1	100
5355-00-409-7205	1	170	5999-01-219-3807	2	130
5905-00-432-0428	2	240	5935-01-268-7737	1	140
5905-00-432-6388	2	270	5930-01-271-6050	1	340
5935-00-434-2897	1	40	5305-01-274-1253	1	290
5930-00-443-9476	2	180	5910-01-280-1421	2	110
5930-00-443-9630	2	190	5999-01-295-9898	1	30
5360-00-447-8721	1	370			
5360-00-480-3639	1	360			
5999-00-481-4821	1	90			
5310-00-492-2133	1	590			
5905-00-499-7268	2	230			
5305-00-551-5112	1	320			
5910-00-554-9736	2	30			
5305-00-559-8743	1	300			
5910-00-632-2826	2	90			
5935-00-689-4707	1	70			
5365-00-715-1152	1	270			
5935-00-789-6082	1	60			
5365-00-859-9247	1	20			
5355-01-008-6909	1	160			
5910-01-012-6197	2	70			
5910-01-012-6198	2	50			
6625-01-013-0470	1	10			
5910-01-022-3080	2	60			
5360-01-029-2164	1	350			
5910-01-031-0826	2	100			
5999-01-032-5408	Z	140			
5910-01-036-9780	2	60			
5910-01-037-8923	2	40			
5999-01-045-4598	1	230			
4920-01-054-4903	1	280			
5905-01-055-5579	2	260			
5930-01-055-8600	1	250			
5999-01-061-9771	1	380			
5130-01-063-1907	1	130			
5910-01-064-9853	2	120			
5340-01-075-8402	1	180			
5355-01-076-5008	1	155			
5950-01-084-9116	1	240			
6625-01-087-6577	1	190			

CROSS-REFERENCE INDEXES

FSCM	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
00853	D1518161F0		5910-01-031-0626	2	100
00853	D153F791F0		5910-00-632-2826	2	90
81349	RCR07G360JS		5905-00-126-6698	2	210
81349	RCR07G510JS		5905-00-106-1249	1	260
81349	RNC55H5001BS		5905-01-055-5579	2	260
81349	RNC55J2001BS		5905-00-138-3291	2	280
81349	RNC55J2002BS		5905-00-137-4511	2	220
81349	RNC55J3011BS		5905-00-499-7268	2	230
81349	RNC55K1740FS		5905-00-250-6045	2	250
81349	RNC55K6191FS		5905-00-432-6388	2	270
81349	RNC55K7681FS		5905-00-432-0428	2	240
80009	105-0718-01		6625-01-087-6577	1	190
80009	105-0719-00		5340-01-075-8402	1	180
18876	10672091		5935-00-689-4707	1	70
18876	10684234		5935-00-789-6082	1	60
28480	1258-0141		5935-01-156-5524	2	20
80009	131-0604-00		5999-01-149-8316	1	80
80009	131-0963-00		5999-00-481-4821	1	90
80009	131-1425-00		5999-01-219-3807	2	130
73743	2X12161-402		5310-00-407-4600	2	150
73743	2X28269-402		5310-00-407-4601	1	200
80009	210-0406-00		5310-01-156-6423	1	210
80009	210-0590-00		5310-00-006-8167	1	220
78471	210-0978-00		5310-00-492-2133	1	390
80009	211-0678-00		5305-01-274-1253	1	290
80009	213-0113-00		5305-01-137-7034	1	310
80009	213-0123-00		5305-00-559-8743	1	300
80009	213-0146-00		5305-00-551-5112	1	320
80009	213-0232-00		5305-01-199-4348	2	160
80009	213-0717-00		5305-01-144-3893	2	170
80009	214-1061-00		5360-01-029-2164	1	350
80009	214-1139-02		5360-00-480-3639	1	360
80009	214-1139-03		5360-00-447-8721	1	370
80009	214-1752-00		4920-01-054-4903	1	280
14752	230B1C104F		5910-01-012-6197	2	70
14752	230B1C105F		5910-01-012-6198	2	50
14752	230B1C505F		5910-01-022-3080	2	80
80009	260-1208-00		5930-00-443-9630	2	190
80009	260-1209-00		5930-00-443-9476	2	180
80249	270332		5910-01-280-1421	2	110
80009	283-0169-00		5910-00-554-9736	2	30
80009	285-1062-00		5910-01-064-9853	2	120
80009	285-1066-00		5910-01-036-9780	2	60
80009	285-1067-00		5910-01-037-8923	2	40
80009	337-1399-00		5999-01-045-4598	1	230
80009	352-0169-01		5935-00-434-2897	1	40
80009	358-0029-00		5365-00-859-9247	1	20
80009	361-0383-00		5999-01-061-9771	1	380
80009	361-0685-00		5930-01-271-6050	1	340
80009	366-0500-00		5355-01-008-6909	1	160

CROSS-REFERENCE INDEXES

FSCM	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
80009	366-1023-00		5355-00-409-7205	1	170
80009	366-1120-00		5355-00-409-7131	1	150
80009	366-1512-00		5930-01-084-9116	1	240
80009	366-1559-00		5930-01-055-8600	1	250
80009	366-1690-00		5355-01-076-5008	1	155
80009	384-1136-00		5930-01-201-2103	1	100
80009	386-3657-01		5935-01-268-7737	1	140
80009	401-0178-01		3130-01-063-1907	1	130
80009	401-0180-00		6625-01-013-0470	1	10
80009	426-0724-00		5998-01-088-7089	1	120
80009	426-0725-00		5999-01-088-7088	1	110
79136	5100-37MD		5365-00-715-1152	1	270
22526	65500-136		5999-01-032-5408	2	140
80009	672-0855-00		5999-01-295-9898	1	30
96214	972487-0001		5935-01-165-1782	1	50

CROSS-REFERENCE INDEXES

FIG.	ITEM	FIGURE AND ITEM NUMBER INDEX		PART NUMBER
		STOCK NUMBER	FSCM	
1	10	6025-01-013-0470	80009	401-0180-00
1	20	5365-00-859-9247	80009	358-0029-00
1	30	5999-01-295-9898	80009	672-0855-00
1	40	5935-00-434-2897	80009	352-0169-01
1	50	5935-01-165-1782	96214	972487-0001
1	60	5935-00-789-6082	18876	10684234
1	70	5935-00-689-4707	18876	10672091
1	80	5999-01-149-8316	80009	131-0604-00
1	90	5999-00-481-4821	80009	131-0963-00
1	100	5930-01-201-2103	80009	384-1136-00
1	110	5999-01-088-7088	80009	426-0725-00
1	120	5998-01-088-7089	80009	426-0724-00
1	130	3130-01-063-1907	80009	401-0178-01
1	140	5935-01-268-7737	80009	386-3657-01
1	150	5355-00-409-7131	80009	366-1120-00
1	155	5355-01-076-5008	80009	366-1690-00
1	160	5355-01-008-6909	80009	366-0500-00
1	170	5355-00-409-7205	80009	366-1023-00
1	180	5340-01-075-8402	80009	105-0719-00
1	190	6625-01-087-6577	80009	105-0718-01
1	200	5310-00-407-4601	73743	2X28269-402
1	210	5310-01-156-6423	80009	210-0406-00
1	220	5310-00-006-8167	80009	210-0590-00
1	230	5999-01-045-4598	80009	337-1399-00
1	240	5930-01-084-9116	80009	366-1512-00
1	250	5950-01-055-8600	80009	366-1559-00
1	260	5905-00-106-1249	81349	RCR07G510JS
1	270	5365-00-715-1152	79136	5100-37MD
1	260	4920-01-054-4903	80009	214-1752-00
1	290	5305-01-274-1253	80009	211-0678-00
1	300	5305-00-559-8743	80009	213-0123-00
1	310	5305-01-137-7034	80009	213-0113-00
1	320	5305-00-551-5112	80009	213-0146-00
1	340	5930-01-271-6050	80009	361-0685-00
1	350	5360-01-029-2164	80009	214-1061-00
1	360	5360-00-480-3639	80009	214-1139-02
1	370	5360-00-447-8721	80009	214-1139-03
1	380	5999-01-061-9771	80009	361-0383-00
1	390	5310-00-492-2133	78471	210-0978-00
2	20	5955-01-156-5524	28480	1258-0141
2	30	5910-00-554-9736	80009	283-0169-00
2	40	5910-01-037-8923	80009	285-1067-00
2	50	5910-01-012-6198	14752	230B1C105F
2	60	5910-01-036-9780	80009	285-1066-00
2	70	5910-01-012-6197	14752	230B1C104F
2	80	5910-01-022-3080	14752	230B1C505F
2	90	5910-00-632-2826	00853	D153F791F0
2	100	5910-01-031-0626	00853	D151E161F0
2	110	5910-01-280-1421	80249	270332
2	120	5910-01-064-9853	60009	285-1062-00
2	130	5999-01-219-3807	80009	131-1425-00

CROSS-REFERENCE INDEXES

FIG.	ITEM	FIGURE AND ITEM NUMBER INDEX		PART NUMBER
		STOCK NUMBER	FSCM	
2	140	5999-01-032-5408	22526	65500-136
2	150	5310-00-407-4600	73743	2X12161-402
2	160	5305-01-199-4348	80009	213-C232-00
2	170	5305-01-144-3893	0009	213-0717-00
2	180	5930-00-443-9476	60009	260-1209-00
2	190	5930-00-445-9630	80009	260-1208-00
2	200	5905-00-106-1249	81349	RCR07G510JS
2	210	5905-00-126-6698	51349	RCR07G360JS
2	220	5905-00-137-4511	81349	RNC55J2002BS
2	230	5905-00-499-7268	81349	RNC55J3011BS
2	240	5905-00-452-0428	81349	RNC55K7681FS
2	250	5905-00-250-6045	81349	RNC55K1740FS
2	260	5905-01-055-5579	86149	RNC55H5001BS
2	270	5905-00-432-6388	86149	RNC55K6191FS
2	280	5905-00-138-3291	1349	RNC55K6191FS

By Order of the Secretary of the Army:

CARL E. VUONO
General, United States Army
Chief of Staff

Official:

WILLIAM J. MEEHAN II
Brigadier General, United States Army
The Adjutant General

Distribution:

To be distributed in accordance with DA Form 12-34C, Block No. 319, requirements for calibration procedures publications.

