

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

COMB GENERATOR

TEKTRONIX, TYPE 067-0885-00

APN MIS-30526/9

NSN 6695-01-197-8023

Current as of 23 January 1986

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms) to: Commander, U.S. Army TMDE Support Group, ATTN: AMXTM-LML, Redstone Arsenal, AL 35898-5400. A reply will be furnished directly to you.

TABLE OF CONTENTS

	Page
Section I. INTRODUCTION	1
Section II. REPAIR PARTS LIST	
Group 0010 Generator, comb	2-1
0020 Circuit card assembly	2-1
Section III. SPECIAL TOOLS LIST (Not applicable)	
Section IV. NATIONAL STOCK NUMBER AND PART NUMBER INDEX	I-1

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

SECTION I. INTRODUCTION

1. Scope. This RPSTL lists and authorizes spares and repair parts required for performance of direct and general support maintenance of Comb Generator, Tektronix, Type 067-0885-00. It authorizes the requisitioning, issue, and disposition of spares and repair parts as indicated by the Source, Maintenance and Recoverability (SMR) codes.

2. General. In addition to this section I, Introduction, the Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. Parts lists are composed of functional groups in ascending numeric sequence. Parts are listed in alphabetical sequence within each figure number.


b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National Item Identification Number (NUN) sequence, of all National Stock Numbered (NSN) items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listing. NSN's and part numbers are cross-referenced to the figure and item number appearance.

3. Explanation of Columns (Section II)

a. Item No. (Column (1)). Indicates the number used to identify each item appearing in the listing.

b. SMR CODE (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instructions as shown in the following breakdown:



*Complete Repair: Maintenance capacity, capability, and authority to perform all the corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.

(1) **Source Code.** The source code tells you how you get an item needed for maintenance, repair, or overhaul of an end item/equipment. Source codes are always the first two positions of the SMR code. Explanation of source codes follows:

Code	Explanation
PA -	Stocked items use the applicable NSN to request/requisition items with this code. This item is authorized to the category indicated by the code entered in the 3d position of the SMR code.

(2) **Maintenance Code.** Maintenance codes tell you the level(s) of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the SMR code as follows:

(a) The maintenance code entered in the third position tells you the lowest maintenance level authorized to remove, replace, and use an item. The maintenance code entered in the third position will indicate authorization to the following level of maintenance.

Code	Application/Explanation
F	- Direct support level can remove, replace, and use the item.

(b) The maintenance code entered in the fourth position tells you whether or not the item is to be repaired and identifies the lowest maintenance level with the capability to do complete repair (i.e., perform all authorized repair functions). This position will contain one of the following codes.

Code	Application/Explanation
F	- Direct support is the lowest level that can do complete repair of the item.
Z	- Nonreparable. No repair is authorized.

(3) **Recoverability Code.** Recoverability codes are assigned to items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the SMR code as follows:

Recoverability Codes	Definition
Z	- Nonreparable item. When unserviceable, condemn and dispose of the item at the level of maintenance shown in the third position of the SMR code.
F	- Repairable item. When uneconomically repairable, condemn and dispose of the item at the direct support level.

c. FSCM (Column (3)). The Federal Supply Code for Manufacturer (FSCM) is a 5-digit numeric code which is used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

d. PART NUMBER (Column (4)). Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements to identify an item or range of items.

NOTE: When you use an NSN to requisition an item, the item you receive may have a different part number from the part ordered, but go ahead and use or furnish it as the replacement part.

e. DESCRIPTION AND USABLE ON CODE (UOC) (Column (5)). This column includes the following information:

- (1) The Federal item name and, when required, a minimum description to identify the item.
- (2) The usable on code, when applicable (see paragraph 5, Special Information).

f. QTY (Column (6)). The QTY (quantity per figure column) indicates the quantity of the item used in the parts list which is prepared for a functional group, subfunctional group, or an assembly.

4. Explanation of Columns (Section IV)

a. NATIONAL STOCK NUMBER (NSN) INDEX

(1) **STOCK NUMBER column.** This column lists the NSN by National item identification number (NIIN) sequence. The NIIN consists of the last nine digits of the NSN
 NSN
 (i.e., 5305-01-674-1467). When using this column to locate an item, ignore the first 4 digits of the NSN. However, the
 NIIN
 complete NSN should be used when ordering items by stock number.

(2) **FIG. column.** Indicates the figure number used to identify each item appearing in the listing. The figures are in numerical order in Section II.

(3) **ITEM column.** The item number identifies the item associated with the figure listed in the adjacent FIG. column. This item is also identified by the NSN listed on the same line.

b. PART NUMBER INDEX. Part numbers in this index are listed by part number in ascending alphanumeric sequence (i.e., vertical arrangement of letter and number combination which places the first letter or digit of each group in order A through Z, followed by the numbers 0 through 9 and each following letter or digit in like order).

(1) **FSCM column.** The Federal Supply Code for Manufacturer (FSCM) is a 5-digit numeric code used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

(2) **PART NUMBER column.** Indicates the primary number used by the manufacturer (individual, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements to identify an item or range of items.

(3) **STOCK NUMBER column.** This column lists the NSN for the associated part number and manufacturer identified in the PART NUMBER and FSCM columns to the left. The part number line entry (with NSN, when available) identifies the first figure/item number appearance for which the part number is applicable. The part number is not listed for additional figure/item number appearances identified by that part number.

(4) **FIG. column.** This column lists the number of the figure where the item is located in Section II.

(5) **ITEM column.** The item number is that number assigned to the item as it appears in the figure referenced in the adjacent figure number column.

5. Special Information

a. Repair parts for components of standards sets which can be identified as existing in the supply system will be requisitioned through normal supply channels from the appropriate supply commodity manager.

b. Repair parts for components of standards sets which cannot be identified as to proper supply source will be requisitioned from USAMICOM, using routing identifier B64 and furnishing, as a minimum, the following as exception data.

(1) Component stock number of the individual end item to be repaired.

(2) Component manufacturer's equipment model number and serial number.

(3) The equipment manufacturer's stock number as listed in the appropriate manual for the desired repair part.

(4) The repair part reference designation, circuit reference, circuit symbol schematic designation, or reference number as listed in the manufacturer's manual.

(5) The technical specification of the repair part as contained in the appropriate manufacturer's manual.

(6) The title and date of the manufacturer's manual from which the information in **a** and **b**(3), (4), and (5) above was taken.

c. For requisitioning miscellaneous consumable maintenance supplies or expendable supplies, use CTA 50-970.

d. The usable on code appears in the lower left corner of the Description column heading. Usable on codes are shown as "UOC" in the Description column (justified left) on the first line applicable item description/nomenclature.

e. This RPSTL does not contain illustrations for items listed in Section II, since the manufacturer's manuals contain exploded view illustrations which are adequate for repair parts location. Copies of the manufacturer's manual for Tektronix, Type 067-0885-00 are furnished with the equipment for which this RPSTL is prepared. The figure and item numbers in the listing are for locating the item within this RPSTL.

6. How to Locate Repair Parts

a. When National Stock Number or Part Number is Not Known.

(1) **First.** Refer to the parts list to locate the item by description. This list is listed in alphabetical sequence within each figure number.

(2) **Second.** After locating the item in the Repair Parts List, refer to the Part Number Index to find the NSN.

b. When National Stock Number or Part Number is Known.

(1) **First.** Using the Index of National Stock Numbers and Part Numbers, find the pertinent National Stock Number or Part Number. The NSN index is in National Item Identification Number (NIIN) sequence. The part numbers in the Part Number index are listed in ascending alphanumeric sequence. Both indexes cross-reference you to the illustration figure and item number of the item you are looking for.

(2) **Second.** After finding the figure and item number, verify that the item is the one you're looking for, then locate the item number in the repair parts list for the figure.

7. **Abbreviations.** Not applicable.

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 0010 - FIGURE 1					
GENERATOR, COMB					
MIS-30526/9 (18876)					
10	PAFZZ	80009	105-0718-01	BAR, LATCH RELEASE.....	1
15	PAFZZ	80009	200-0935-00	BASE, LAMPHOLDER.....	1
20	PAFFF	80009	670-4181-01	CIRCUIT CARD ASSEMB FOR PARTS SEE GROUP 20, FIGURE 2.....	1
30	PAFZZ	80009	136-0252-04	CONTACT, ELECTRICAL.....	3
40	PAFZZ	80009	426-1072-00	FRAME, PUSH BUTTON.....	1
50	PAFZZ	80009	426-0724-00	FRAME SECTION PLUG-.....	1
60	PAFZZ	80009	214-0667-00	HEAT SINK, ELECTRICAL.....	2
70	PAFZZ	80009	426-0725-00	HOLDER, ELECTRICAL C.....	1
80	PAFZZ	80009	361-0411-00	HOLDER, PRINTED CIRC.....	2
90	PAFZZ	80009	366-1690-00	KNOB.....	1
100	PAFZZ	80009	352-0157-00	LAMPHOLDER.....	1
110	PAFZZ	80009	105-0719-00	LATCH.....	1
130	PAFZZ	80009	378-0602-00	LENS, LIGHT.....	1
140	PAFZZ	78189	511-041800-00	NUT, PLAIN, ASSEMBLED.....	1
150	PAFZZ	80009	210-0551-00	NUT, PLAIN, HEXAGON.....	1
160	PAFZZ	73143	3145-402	NUT, PLAIN, HEXAGON.....	1
170	PAFZZ	80009	337-1399-00	PLATE, ELECTRICAL SH.....	2
180	PAFZZ	80009	366-1559-00	PUSH BUTTON.....	1
190	PAFZZ	80009	214-1914-00	RETAINER-EJECTOR, EL.....	2
200	PAFZZ	80009	211-0008-00	SCREW, MACHINE.....	3
210	PAFZZ	88818	H795220603	SCREW, MACHINE.....	7
220	PAFZZ	96906	MS35206-212	SCREW, MACHINE.....	2
230	PAFZZ	80009	213-0254-00	SCREW, TAPPING, THREA.....	1
240	PAFZZ	80009	214-1061-00	SPRING, FLAT.....	1
250	PAFZZ	08484	AL1256-86	WASHER, FLAT.....	1
260	PAFZZ	80009	210-1171-00	WASHER, SHOULDERED.....	1
GROUP 0020 - FIGURE 2					
CIRCUIT CARD ASSEMBLY					
670-6181-01 (80009)					
10	PAFZZ	80009	281-0184-00	CAPACITOR.....	1
20	PAFZZ	72982	8101-003COG100J	CAPACITOR, FIXED, CER.....	3
30	PAFZZ	81349	M39014/23-0355	CAPACITOR, FIXED, CER.....	9
40	PAFZZ	80009	283-0156-00	CAPACITOR, FIXED, CER.....	13
50	PAFZZ	81349	CC52TH101G	CAPACITOR, FIXED, CER.....	1
60	PAFZZ	91418	B1000D18209	CAPACITOR, FIXED, CER.....	1
70	PAFZZ	72982	8111B061COG220J	CAPACITOR, FIXED, CER.....	1
80	PAFZZ	80009	283-0185-00	CAPACITOR, FIXED, CER.....	1
90	PAFZZ	59873	283-0054-00	CAPACITOR, FIXED, CER.....	1
100	PAFZZ	80009	281-0202-00	CAPACITOR, VARIABLE,.....	1
110	PAFZZ	80009	108-0443-00	COIL, RADIO FREQUENC.....	1
120	PAFZZ	80009	108-0550-00	COIL, RADIO FREQUENC.....	2
130	PAFZZ	97942	1380007H01	CONNECTOR, RECEPTACL.....	1
140	PAFZZ	22526	47357	CONTACT, ELECTRICAL.....	9

SECTION II

TM 9-6695-273-34P

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
150	PAFZZ	11530	394-80060994659	CRYSTAL UNIT, QUARTZ.....	1
160	PAFZZ	71744	CM7220	LAMP, INCANDESCENT.....	1
170	PAFZZ	80009	120-0318-00	REACTOR.....	3
180	PAFZZ	81349	RCR07G102JS	RESISTOR, FIXED, COMP.....	2
190	PAFZZ	81349	RCR07G154JS	RESISTOR, FIXED, COMP.....	1
200	PAFZZ	81349	RCR07G273JS	RESISTOR, FIXED, COMP.....	1
210	PAFZZ	81349	RCR32G620JS	RESISTOR, FIXED, COMP.....	1
220	PAFZZ	81349	RCR07G181JS	RESISTOR, FIXED, COMP.....	1
230	PAFZZ	81349	RCR07G821JS	RESISTOR, FIXED, COMP.....	3
240	PAFZZ	81349	RCR07G222JS	RESISTOR, FIXED, COMP.....	2
250	PAFZZ	81349	RCR07G100JS	RESISTOR, FIXED, COMP.....	2
260	PAFZZ	81349	RCR07G151-JS	RESISTOR, FIXED, COMP.....	1
270	PAFZZ	81349	RCR07G471JS	RESISTOR, FIXED, COMP.....	1
280	PAFZZ	81349	RCR05G101JS	RESISTOR, FIXED, COMP.....	3
290	PAFZZ	81349	RCR07G470JS	RESISTOR, FIXED, COMP.....	1
300	PAFZZ	81349	RCR05G562JS	RESISTOR, FIXED, COMP.....	1
310	PAFZZ	81349	RCR07G221JS	RESISTOR, FIXED, COMP.....	3
320	PAFZZ	81349	RCR07G361JS	RESISTOR, FIXED, COMP.....	1
330	PAFZZ	80009	301-0100-00	RESISTOR, FIXED, COMP.....	1
340	PAFZZ	81349	RCR07G103JS	RESISTOR, FIXED, COMP.....	1
350	PAFZZ	81349	RCR05G221JS	RESISTOR, FIXED, COMP.....	1
360	PAFZZ	81349	RCR05G510JS	RESISTOR, FIXED, COMP.....	1
370	PAFZZ	81349	RCR07G202JS	RESISTOR, FIXED, COMP.....	1
380	PAFZZ	81349	RN65F4640F	RESISTOR, FIXED, FILM.....	1
390	PAFZZ	80009	08-0179-00	RESISTOR, FIXED, WIRE.....	1
400	PAFZZ	15818	CD8220	SEMICONDUCTOR DEVIC.....	4
410	PAFZZ	04713	MV109	SEMICONDUCTOR DEVIC.....	1
420	PAFZZ	80009	152-0457-00	SEMICONDUCTOR DEVIC.....	4
430	PAFZZ	74063	60104-004	SEMICONDUCTOR DEVIC.....	1
440	PAFZZ	80009	260-1771-00	SWITCH, PUSH.....	1
450	PAFZZ	80009	210-0255-00	TERMINAL, LUG.....	2
460	PAFZZ	04713	2N2907A	TRANSISTOR.....	1
470	PAFZZ	80009	151-0439-00	TRANSISTOR.....	1
480	PAFZZ	81349	JAN2N2222A	TRANSISTOR.....	1
490	PAFZZ	80009	151-0441-00	TRANSISTOR.....	1
500	PAFZZ	28480	1854-0345	TRANSISTOR.....	2
510	PAFZZ	80009	151-0410-00	TRANSISTOR.....	2
520	PAFZZ	80009	151-0333-00	TRANSISTOR.....	2
530	PAFZZ	80009	151-0650-00	TRANSISTOR.....	1
540	PAFZZ	13499	352-1075-010	TRANSISTOR.....	1

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

STOCK NUMBER	NATIONAL STOCK NUMBER INDEX				
	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5910-00-001-7570	2	40	5961-01-005-9752	2	420
5910-00-001-7571	2	80	5961-01-006-7998	2	540
6240-00-008-4550	2	160	5961-01-012-6683	2	510
5999-00-103-1763	1	60	5999-01-013-3837	2	140
5905-00-104-8368	2	290	5360-01-029-2164	1	240
5905-00-104-8370	2	320	5961-01-030-5315	2	470
5961-00-105-7681	2	400	5950-01-040-7562	2	170
5905-00-105-7764	2	240	5910-01-042-7757	2	100
5905-00-106-3666	2	340	5999-01-045-4598	1	170
5905-00-107-0656	2	250	5910-01-052-5823	2	20
5905-00-110-7620	2	180	5975-01-055-8600	1	180
5905-00-114-0708	2	370	5910-01-062-0510	2	70
5905-00-114-5339	2	190	5930-01-062-0608	2	440
5905-00-119-3504	2	200	5975-01-066-3185	1	40
5905-00-119-8768	2	230	5340-01-075-8402	1	110
5905-00-119-8811	2	260	5355-01-076-5008	1	90
5905-00-120-9154	2	270	6625-01-087-6577	1	10
5905-00-135-3973	2	310	5999-01-088-7088	1	70
5905-00-141-0742	2	220	6625-01-088-7089	1	50
5905-00-177-7486	2	350	5950-01-110-6374	2	120
5905-00-180-8301	2	280	5999-01-125-5944	1	190
5950-00-241-3676	2	110	5310-01-126-1222	1	260
5999-00-257-9041	1	30	5910-01-142-8675	2	30
5955-00-314-3280	2	150	5305-01-144-1632	1	230
5961-00-401-0507	2	500	5961-01-149-2477	2	530
5310-00-407-2292	1	160	6250-01-149-8341	1	15
5905-00-411-1851	2	300	5999-01-162-3892	1	80
5905-00-412-0758	2	360	5310-01-172-5574	1	150
5905-00-434-5335	2	390	5910-01-176-6962	2	10
5905-00-436-8089	2	330	6695-01-219-2913	1	20
6210-00-442-2336	1	130			
5905-00-463-9584	2	210			
6250-00-476-0489	1	100			
5961-00-477-7364	2	460			
5961-00-478-3046	2	520			
5910-00-688-8702	2	60			
5940-00-814-1982	2	450			
5310-00-836-3520	1	140			
5910-00-840-6530	2	50			
5910-00-879-6851	2	90			
5305-00-889-3116	1	200			
5310-00-891-3230	1	250			
5935-00-934-0101	2	130			
5961-00-943-4084	2	430			
5961-00-951-8757	2	480			
5305-00-984-4982	1	210			
5905-00-985-6437	2	380			
5305-00-993-0191	1	220			
5961-01-005-5155	2	410			
5961-01-005-9744	2	490			

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

FSCM	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
08484	AL1256-86		5310-00-891-3230	1	250
91418	B1000D18209		5910-00-688-8702	2	60
81349	CC52TH101G		5910-00-840-6530	2	50
15818	CD8220		5961-00-105-7681	2	400
71744	CM7220		6240-00-008-4550	2	160
88818	H795220603		5305-00-984-4982	1	210
81349	JAN2N2222A		5961-00-951-8757	2	480
96906	MS35206-212		5305-00-993-0191	1	220
04713	MV109		5561-01-005-5155	2	410
81349	M39014/23-0355		5910-01-142-8675	2	30
81349	RCR05G101JS		5905-00-180-8301	2	280
81349	RCR05G221JS		5905-00-177-7486	2	350
81349	RCR05G510JS		5905-00-412-0758	2	360
81349	RCR05G562JS		5905-00-411-1851	2	300
81349	RCR07G100JS		5905-00-107-0656	2	250
81349	RCR07G102JS		5905-00-110-7620	2	180
81349	RCR07G103JS		5905-00-106-3666	2	340
81349	RCR07G151-JS		5905-00-119-8811	2	260
81349	RCR07G154JS		5905-00-114-5339	2	190
81349	RCR07G181JS		5905-00-141-0742	2	220
81349	RCR07S202JS		5905-00-114-0708	2	370
81349	RCR07G221JS		5905-00-135-3973	2	310
81349	RCR07G222JS		5905-00-105-7764	2	240
81349	RCR07G273JS		5905-00-119-3504	2	200
81349	RCR07G361JS		5905-00-104-8370	2	320
81349	RCR07G470JS		5905-00-104-8368	2	290
81349	RCR07G471JS		5905-00-120-9154	2	270
81349	RCR07G821JS		5905-00-119-8768	2	230
81349	RCR32G620JS		5905-00-463-9584	2	210
81349	RN65F4640F		5905-00-985-6437	2	380
80009	105-0718-01		6625-01-087-6577	1	10
80009	105-0719-00		5340-01-075-8402	1	110
80009	108-0443-00		5950-00-241-3676	2	110
80009	108-0550-00		5950-01-110-6374	2	120
80009	120-0318-00		5950-01-040-7562	2	170
80009	136-0252-04		5999-00-257-9041	1	30
97942	138C007H01		5935-00-934-0101	2	130
80009	151-0333-00		5961-00-478-3046	2	520
80009	151-0410-00		5961-01-012-6683	2	510
80009	151-0439-00		5961-01-030-5315	2	470
80009	151-0441-00		5961-01-005-9744	2	490
80009	151-0650-00		5961-01-149-2477	2	530
80009	152-0457-00		5961-01-005-9752	2	420
28480	1854-0345		5961-00-401-0507	2	500
04713	2N2907A		5961-00-477-7364	2	460
80009	200-0935-00		6250-01-149-8341	1	15
80009	210-0255-00		5940-00-814-1982	2	450
80009	210-0551-00		5310-01-172-5574	1	150
80009	210-1171-00		5310-01-126-1222	1	260
80009	211-0008-00		5305-00-889-3116	1	200
80009	213-0254-00		5305-01-144-1632	1	230

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

FSCM	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
80009	214-0667-00		5999-00-103-1763	1	60
80009	214-1061-00		5360-01-029-2164	1	240
80009	214-1914-00		5999-01-125-5944	1	190
80009	260-1771-00		5930-01-062-0608	2	440
80009	281-0184-00		5910-01-176-6962	2	10
80009	281-0202-00		5910-01-042-7757	2	100
59873	283-0054-00		5910-00-879-6851	2	90
80009	283-0156-00		5910-00-001-7570	2	40
80009	283-0185-00		5910-00-001-7571	2	80
80009	301-0100-00		5905-00-436-8089	2	330
80009	308-0179-00		5905-00-434-5335	2	390
73743	3145-402		5310-00-407-2292	1	160
80009	337-1399-00		5999-01-045-4598	1	170
80009	352-0157-00		6250-00-476-0489	1	100
13499	352-1075-010		5961-01-006-7998	2	540
80009	361-0411-00		5999-01-162-3892	1	80
80009	366-1559-00		5975-01-055-8600	1	180
80009	366-1690-00		5355-01-076-5008	1	90
80009	378-0602-00		6210-00-442-2336	1	130
11530	394-80060994659		5955-00-314-3280	2	150
80009	426-0724-00		6625-01-088-7089	1	50
80009	426-0725-00		5999-01-088-7088	1	70
80009	426-1072-00		5975-01-066-3185	1	40
22526	47357		5999-01-013-3837	2	140
78189	511-041800-00		5310-00-836-3520	1	140
74063	60104-004		5961-00-943-4084	2	430
80009	670-6181-01		6695-01-219-2913	1	20
72982	8101-003COG100J		5910-01-052-5823	2	20
72982	8111B061COG220J		5910-01-062-0510	2	70

By Order of the Secretary of the Army:

JOHN A. WICKHAM. JR.
General, United States Army
Chief of Staff

Official:

R. L. DILWORTH
Brigadier General, United States Army
The Adjutant General

Distribution:

To be distributed in accordance with DA Form 12-34C, Block No. 319, requirements for calibration procedures publications.

☆ U.S. GOVERNMENT PRINTING OFFICE: 1986 491-885/40861

