VXI *bus*

Eight-Channel
Fixed Filter and Amplifier
Signal Conditioning Plug-on
VT1508A

User's Manual

The VT1508A manual also applies to Agilent/HP E1413Bs as Agilent/HP E1413 Option 18.

Enclosed is the User's Manual for the VT1508A Signal Conditioning Plug-on. Insert this manual in your VT1413C or Agilent/HP E1313 manual behind the "Signal Conditioning Plug-ons" divider.

VXI
Technology

VT1508A
Eight-Channel Fixed Filter and Amplifier Signal Conditioning Plug-on

Introduction

The VT1508A is a Signal Conditioning Plug-on that provides eight fixed low-pass filters with a 3 dB cutoff frequency of 7 Hz and eight amplifiers with gain of 16. Also provided is input over-voltage protection and open transducer detection on each channel.

About this Manual

This manual shows you how to control the Signal Conditioning Plug-on (SCP) using SCPI commands as well as Register-Based commands, and explains the capabilities of this SCP. Finally, it covers specifications for this SCP. The contents of this manual are:

Installation

Installation for this Plug-on is common to several others and is covered in Chapters 1 and 2 of your VT1413C or Agilent/HP E1313 manual.

Identifying the Plug-on

You'll find the VXI Technology part number on the connector side of the SCP to the left of the serial number bar code. For the VT1508A, the part number is : VT1508A.

Connecting To The Terminal Module

This section shows how to make connections to the Terminal Module.

The SCP connections for the Terminal Modules are shown on the stick-on labels that came with the SCP. Use the appropriate label for the type of Terminal Module you have. The connections and appropriate stickers are as follows:

- For VT1413C and above Terminal Modules, use stickers for VT1508A SCPs. The connections are shown in Figure 1.
- For Agilent/HP E1313 Terminal Moduless, use stickers for VT1508A SCPs. The connections are shown in Figures 2 and 3.
- For Agilent/HP E1413B and below Terminal Modules, use stickers for Agilent/HP E1413 Option 18 SCPs. The connections are shown in Figure 4.


Figure 1 VT1508A C-Size Terminal Module Connections

SCP 0

00	01	02	03	04	05	06	07
H L G	H L G	H L G	H L G	H L G	H L G	H L G	H L G

SCP 3

24	25	26	27	28	29	30	31
G L H	G L H	G L H	G L H	G L H	G L H	G L H	G L H

LTS HTS LT1 HT1   TRG OUT EXT TRIG   GND   LCAL HCAL LO HI
OHMS

DO NOT USE CENTER
BLOCK FOR CH 32-63

SCP 1

08	09	10	11	12	13	14	15
H L G	H L G	H L G	H L G	H L G	H L G	H L G	H L G

SCP 2

16	17	18	19	20	21	22	23
G L H	G L H	G L H	G L H	G L H	G L H	G L H	G L H

Figure 2 VT1508A B-size Terminal Module Connections (Ch 00-31)

SCP 4

32	33	34	35	36	37	38	39
H L G	H L G	H L G	H L G	H L G	H L G	H L G	H L G

SCP 7

56	57	58	59	60	61	62	63
G L H	G L H	G L H	G L H	G L H	G L H	G L H	G L H

LTS HTS LT1 HT1   TRG OUT EXT TRIG   GND   LCAL HCAL LO HI
OHMS

DO NOT USE CENTER
BLOCK FOR CH 32-63

SCP 5

40	41	42	43	44	45	46	47
H L G	H L G	H L G	H L G	H L G	H L G	H L G	H L G

SCP 6

48	49	50	51	52	53	54	55
G L H	G L H	G L H	G L H	G L H	G L H	G L H	G L H

Figure 3 VT1508A B-size Terminal Module Connections (Ch 32-63)

SCP 0

H	L	H	L	H	L	G	G
05		06		07		G0	

| H | L | H | L | H | L | H | L | H | L |
| 00 | | 01 | | 02 | | 03 | | 04 | |

SCP 2

| H | L | H | L | H | L | G | G |
| 20 | | 21 | | 22 | | 23 | | G2 | |

| H | L | H | L | H | L | H | L |
| 16 | | 17 | | 18 | | 19 | |

SCP 5

| G | G | L | H | L | H | L | H |
| G5 | | 40 | | 41 | | 42 | | 43 | |

| L | H | L | H | L | H | L | H |
| 44 | | 45 | | 46 | | 47 | |

SCP 7

| G | G | L | H | L | H | L | H |
| G7 | | 56 | | 57 | | 58 | |

| L | H | L | H | L | H | L | H |
| 59 | | 60 | | 61 | | 62 | | 63 | |

SCP 1

| H | L | H | L | G | G |
| 14 | | 15 | | G1 | |

H	L	H	L	H	L
11		12		13	
08		09		10	
H	L	H	L	H	L

SCP 3

| H | L | H | L | G | G |
| 30 | | 31 | | G3 | |

H	L	H	L	H	L
27		28		29	
24		25		26	
H	L	H	L	H	L

SCP 4

| G | G | L | H | L | H |
| G4 | | 32 | | 33 | |

L	H	L	H	L	H
34		35		36	
37		38		39	
L	H	L	H	L	H

SCP 6

| G | G | L | H | L | H |
| G6 | | 48 | | 49 | |

L	H	L	H	L	H
50		51		52	
53		54		55	
L	H	L	H	L	H

Figure 4 Agilent/HP E1413B Option 18 Terminal Module Connections

Programming With SCPI Commands

The SCPI commands shown here are covered in Chapters 3 and 5 of your VT1413C or Agilent/HP E1313 manual. This section will relate those commands to the parameter values which are specific to this Plug-on.

Checking the ID of the SCP

To verify the SCP type(s) installed on the VT1413C or Agilent/HP E1313 use the SYSTem:CTYPe? (@<channel>) command.

- The *channel* parameter specifies a single channel in the channel range covered by the SCP of interest. The first channel number for each of the eight SCP positions are; 0,8,16,24,32,40,48 and 56.

The value returned for the SCP in an Agilent/HP E1413B is:
HEWLETT-PACKARD,E1413 Opt 18 8-Channel Fixed Gain-Filter SCP,0,0

The value returned for the SCP in a VT1413C or Agilent/HP E1313A is:
HEWLETT-PACKARD,E1508 8-Channel Fixed Gain-Filter SCP,0,0

To determine the type of SCP installed on channels 0 through 7 send

    SYST:CTYP? (@100)   query SCP type @ ch 0
    enter statement here

Querying the Filter Cutoff Frequency

While the VT1508A does not provide programmable cutoff frequency the filter frequency can be queried. The response to this query will always be 7. To query any channel for its cutoff frequency use the INPut:FILTer[:LPASs]:FREQuency? (@<*channel*>) command. The INP:FILT:FREQ? command returns the numeric cutoff value currently set for the channel specified.

- The *channel* parameter must specify a single channel.

To query the cutoff frequency of channel 6 send

    INP:FILT:FREQ? (@106)   query channel 6
    enter statement here

Querying the Filter State

While the VT1508A does not allow controlling whether the filters are enabled or disabled, this state can be queried. The response to this query will always be 1. To query any channel to determine if it is enabled or disabled use the INPut:FILTer[:LPASs][:STATe]? (@<*channel*>) command. The INP:FILT? command returns a 0 if the channel is OFF or a 1 if the channel is ON.

• The *channel* parameter must specify a single channel.

To query the filter state of channel 2 send

    INP:FILT? (@102)   query channel 2
    enter statement here

Querying the Channel Gain

While the VT1508A's amplifiers have fixed gain, the channel gain can be queried. The response to this query will always be 16. To query any channel to determine its gain setting use the INPut:GAIN? (@<*channel*>) command. The INP:GAIN? command returns the current gain value for the specified channel.

• The channel parameter must specify a single channel.

To query the gain setting of channel 8 send

    INP:GAIN? (@108)   query channel 8
    enter statement here

Detecting Open Transducers

This SCP provides a method to detect open transducers. When Open Transducer Detect (OTD) is enabled, the SCP injects a small current into the HIGH and LOW input of each channel. The polarity of the current pulls the HIGH inputs toward +17 volts and the LOW inputs towards -17 volts. If a transducer is open, measuring that channel will return an over-voltage condition. OTD is available on a per SCP basic. all eight channels of an SCP are enabled or disabled together. See Figure for a simplified schematic diagram of the OTD circuit.


Figure 5 Open Transducer Detect Circuit

NOTES	1) When OTD is enabled, the inputs have up to 0.2 μA injected into them. If this current will adversely affect your measurement, but you still want to check for open transducers, you can enable OTD, make a single scan, check the CVT for bad measurements, then disable OTD and make your regular measurement scans. The specifications apply only when OTD is off.
	2) Allow 5 minutes before checking for open transducers to allow filter capacitors to charge.

To enable or disable Open Transducer Detection, use the DIAGnostic:OTDetect *<enable>*, *(@<ch_list>)* command.

- The *enable* parameter can specify ON or OFF
- An SCP is addressed when the *ch_list* parameter specifies a channel number contained on the SCP. The first channel on each SCP is:
        0, 8, 16, 24, 32, 40, 48, and 56

To enable Open Transducer Detection on all channels on SCPs 1 and 3:

DIAG:OTD ON, (@100,116)   0 is on SCP 1 and 16 is on SCP3

To disable Open Transducer Detection on all channels on SCPs 1 and 3:

DIAG:OTD OFF, (@100,116)

Register Based Programming

The register-based commands shown here are covered in Appendix D of the VT1413C or Agilent/HP E1313 manual. You should read that section first to become familiar with accessing registers and executing Register-Based Commands. This section will relate those commands to the parameter values which are specific to this Plug-on.

When Register Programming an SCP most communication is through the Signal Conditioning Bus. For that you will use the Register Commands:
  SCBWRITE *<regaddr>* *<regvalue>*
                    and
  SCBREAD? *<regaddr>*

VT1508A Register Map

Read (returned value)	Write(<regvalue>)	SCP Register	<regaddr> Value
SCP ID (9010_{16})		Whole SCP Reg 0	$00ppp000000_2$

ppp=Plug-on
ccc=SCP channel

In addition you will access bits in the Card Control register to control Open Transducer Detection.

Checking ID of SCP

To query an SCP for its ID value, write the following value to Parameter Register 1:

$$(SCP\ number) \times 40_{16}$$

Then write the opcode for SCBREAD? (0800_{16}) to the Command Register. The ID value will be returned to the Query Response Register.

Detecting Open Transducers

Open Transducer Detection (OTD) is controlled by bits in the Card Control Register. For more information on OTD see Figure 1.

Card Control Register   (Base + 12_{16})

15	14	14-13	12	11	10-8	7-0
PSI Pwr Reset	FIFO Mode	unused	FIFO Clear	VPPEN	A24 Window	Open Transducer Detect

Writing a one (1) to a bit enables open transducer detect on that signal conditioning module. Writing a zero (0) to a bit disables open transducer detect.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
SCP 7	SCP 6	SCP 5	SCP 4	SCP 3	SCP 2	SCP 1	SCP 0

Specifications

These specifications for the VT1508A reflect the combined performance of the VT1413C or Agilent/HP E1313 and the VT1508A Signal Conditioning Plug-on. These specifications are not to be added to those presented in the VT1413C User's Manual.

General Specifications

Measurement ranges

DC Volts	±3.9 mV to ±1 V FS
Temperature	Thermocouples - -200 to +1700°C Thermistors - (Opt 15 required) -80 to +160°C RTD's - (Opt 15 required) -200 to +850°C
Resistance	(Opt 15 required) 128 Ohms to 131 kOhms FS
Strain	25,000 μe or limit of linear range of strain gage

Maximum input voltage
(Normal mode plus common mode)

Operating: <±16 V peak   Damage level: > ±42 V peak

Maximum common mode voltage

Operating: <±16 V peak   Damage level: > ±42 V peak

Normal mode rejection

@ 7 Hz -3 dB, @ 60 Hz >-25 dB

Common mode rejection

0 - 60 Hz -100 dB

Input impedance

100 MOhm ±10% (each differential input to ground)

Maximum tare cal offset

(Maximum tare offset depends on A/D range and SCP gain)

A/D range ±V F.Scale	16	4	1	0.25	0.0625
Max Offset	0.20009	0.05007	0.01317	0.00349	0.00112

**Measurement accuracy
DC Volts**

(90 days) 23°C±1°C (with *CAL? done after 1 hr warm up and CAL:ZERO? within 5 min.). If autoranging is ON, add ±0.02% FS to accuracy specifications.
For Agilent/HP E1313, multiply Noise Spec. by 1.4.

Gain 16	Range ±V FS	Linearity % of reading	Offset Error μV (10Hz)	Noise μV 3 sigma	Noise μV* 3 sigma
	.0039	0.01	3.8	3.4	2.9
	.0156	0.01	4.2	4.4	3.8
	.0625	0.01	4.9	7.5	6.3
	.25	0.01	8	28	23
	1	0.01	31	113	64

* [SENSe:]FILTer[:LPASs][:STATe] ON (max scan rate - 100 rdgs/sec/channel)

Temperature Coefficients: Gain - 15 ppm/°C.   Offset - (0 - 30°C) 0.16 μV/°C, (30 - 40°C) 0.18 μV/°C, (40 - 55°C) 0.39 μV

**Measurement accuracy
Temperature**

(simplified specifications, see temperature accuracy graphs in VT1413C manual for details)

(90 days) 23°C±1°C (with *CAL? done after 1 hr warm up and CAL:ZERO? within 5 min.). If autoranging is ON, add ±0.02% FS to accuracy specifications.

The temperature accuracy specifications include instrument and firmware linearization errors. The linearization algorithm used is based on the IPTS-68(78) standard transducer curves. Add your transducer accuracy to determine total measurement error.

Thermocouples

Type E	A/D Filter	-200 to 0°C	0 to 200°C	200 to 400°C	400 to 800°C
	OFF	1.30°C	0.14°C	0.14°C	0.20°C

Type EEXtended	A/D Filter	-200 to 0°C	0 to 200°C	200 to 800°C	800 to 1000°C
	OFF	1.80°C	0.30°C	0.20°C	0.35°C

Type J	A/D Filter	-200 to 0°C	0 to 280°C	280 to 600°C	600 to 775°C
	OFF	1.60°C	0.15°C	0.22°C	0.22°C

Type K	A/D Filter	-200 to 0°C	0 to 375°C	375 to 800°C	800 to 1400°C
	OFF	2.50°C	0.20°C	0.25°C	0.40°C

Type R	A/D Filter	0 to 100°C	100 to 200°C	200 to 600°C	600 to 1000°C
	OFF	1.80°C	0.90°C	0.70°C	0.60°C

[SENSe:]FILTer[:LPASs][:STATe] ON (max scan rate - 100 rdgs/sec/channel)

Measurement accuracy Temperature (cont.) (simplified specifications, see temperature accuracy graphs in VT1413C manual for details)

Thermocouples (cont.)

Type S	A/D Filter	0 to 100°C	100 to 200°C	200 to 800°C	800 to 1750°C
	OFF	3.50°C	1.75°C	0.80°C	0.85°C

Type T	A/D Filter	-200 to -100°C	-100 to 0°C	0 to 200°C	200 to 400°C
	OFF	1.55°C	0.32°C	0.18°C	0.18°C

5 kΩ Reference Thermistor

A/D Filter	-10 to 65°C	65 to 85°C
OFF	0.012°C	0.013°C

100 Ω Reference RTD

A/D Filter	-125 to 70°C
OFF	0.145°C

100 Ω RTD

A/D Filter	-200 to 75°C	75 to 300°C	300 to 600°C	600 to 970°C
OFF	0.08°C	0.21°C	0.27°C	0.37°C

2252 Ω Thermistor

A/D Filter	0 to 30°C	30 to 70°C	70 to 80°C	80 to 100°C
OFF	0.006°C	0.013°C	0.010°C	0.014°C

5 kΩ Thermistor

A/D Filter	0 to 30°C	30 to 70°C	70 to 85°C
OFF	0.012°C	0.014°C	0.019°C

10 kΩ Thermistor

A/D Filter	0 to 30°C	30 to 60°C	60 to 90°C	90 to 115°C
OFF	0.015°C	0.016°C	0.018°C	0.022°C