General Specifications

Model MU5
Universal Temperature Converter
(Free Range Type)

JUXTA

GS 77J04U05-01E

■ General

The MU5 is a plug-in type universal temperature converter that converts input signal (thermocouple, RTD or mV signal) into isolated DC current or DC voltage signals.

- Selection of input type(thermocouple, RTD or mV signal), I/O range setting, burnout setting, output adjustment, I/O monitoring, and loop back test can be made using the optional Parameter Setting Tool (VJ77) or Handy Terminal (JHT200).
- The operation indicating lamp shows the operation status, abnormalities in a setting etc.
- Output adjustment, wiring resistance correction, and ON/OFF of RJC can be made using the switches on the front panel of the MU5 without a setting tool such as Handy Terminal.

■ Model and Suffix Codes

MU5 -01□-□□00 /□

Model

Output
1: 1 output

Power supply
1: 15-40V DC (Operating range: 12 to 48 V)
6: 100-240 V AC/DC (Operating range: 85 to 264 V)

Input signal
U:Thermocouple, RTD, mV
Z: (Custom order)
Customized thermocouple or RTD

Output signal

A: 0 to 20 mA DC	Span is 5 mA or more
B: 0 to 5 mA DC	Span is 1 mA or more
1: –10 to +10 V DC	Span is 0.1 V or more
2: –100 to +100 mV DC	Span is 10 mV or more

Z: (Custom order)
Customized current signals or voltage signals

Optional specification
/SN: Without socket
/RJCN: Without RJC sensor



■ Ordering Information

Specify the following when ordering.
- Model and suffix codes: e.g. MU5-016-UA00
- Input type: e.g. Pt100 (ITS-90)
- Input range: e.g. 0 to 100°C
- Output range: e.g. 4 to 20 mA DC
- Burnout: e.g. Up

The universal temperature converter will be shipped with an input type of Pt100 (ITS-90) and an input range of 0 to 100°C if no specification of input type and input range.

1st Edition Jul. 2005

■ Input/Output Specifications

Input signal:

Thermocouple: Type K, T, E, J, R, S, B, N (ITS-90: JIS'97), W3(Note1), W5(Note2)

(Note1)W97Re3-W75Re25
(Tungsten97% Rhenium 3% - Tungsten75% Rhenium25%)
The abbreviation of ASTM E988 Standard.

(Note2) W95Re5-W74Re26
(Tungsten95% Rhenium 5% - Tungsten74% Rhenium 26%)
The abbreviation of ASTM E988 Standard.

RTD:
Pt100 (ITS-90: JIS'97), JPt100 (JIS'89)
Pt50 (JIS'81), Pt100 (IPTS68: JIS'89)
Pt100 (ITS-90): R_0 = 100 Ω, R_{100} /R_0 = 1.3851
JPt100 (JIS'89): R_0 = 100 Ω, R_{100} /R_0 = 1.3916
Pt100 (IPTS-68): R_0 = 100 Ω, R_{100} /R_0 = 1.3850

mV DC signal: –500 to +500 mV DC

Input type and measuring range:

Input type (thermocouple)	Measuring range (°C)
Type K	–270 to +1372
Type T	–270 to +400
Type E	–270 to +1000
Type J	–210 to +1200
Type R	–50 to +1768
Type S	–50 to +1768
Type B	0 to +1820
Type N	–270 to +1300
Type W3	0 to +2300
Type W5	0 to +2300
Input type (RTD)	Measuring range (°C)
Pt100 (ITS-90)	–200 to +850
Pt100 (IPTS-68)	–200 to +660
JPt100 (JIS'89)	–200 to +510
Pt50 (JIS'81)	–200 to +649
Input type (mV DC)	Measuring range (mV DC)
mV	–500 to +500

Measuring span: 3 mV or more (thermocouple, mV signal) , 10°C or more (RTD)

Input resistance: 1 MΩ during power on; 10 kΩ during power off (thermocouple, mV signal)

Input external resistance:

Thermocouple, mV signal: 500 Ω or less
However, this resistance value can be added to the BARD600 internal resistance when the converter is used with BARD600.

RTD: Input span (°C) × 0.4 Ω or less / wire or 10 Ω, whichever is smaller.
However, this resistance value can be added to the BARD700 internal resistance when the converter is used with BARD700.

RTD detective current: Approx. 0.7 mA

Maximum allowable input: ±4 V DC

Output signal: 1 point of DC current or DC voltage signal

Output signal setting range:

Output signal suffix code	Setting range
A	0 to 20 mA DC Span is 5 mA or more
B	0 to 5 mA DC Span is 1 mA or more
1	±10 V DC Span is 0.1 V or more
2	±100 mV DC Span is 10 mV or more

Allowable load resistance:

Voltage output: 2 kΩ or more for ±5 V DC
10 kΩ or more for ±10 V DC
250 kΩ or more for ±100 mV DC

Current output: 15 (V)/max. output (A) (Ω) or less

Adjustment range:

Input adjustment: ±1% of span or more (Zero/Span)

Output adjustment: ±5% of span or more (Zero/Span)

■ Standard Performance

Accuracy rating: ±0.1% of span
However, the accuracy is not guaranteed for output levels less than 0.5% of the span of a 0 to X mA output range type.
The accuracy is limited according to the input/output range settings.
For thermocouple, add the accuracy of RJC to the calculated accuracy.

• Accuracy Calculation
Accuracy = Input accuracy + Output accuracy (%)

[Input accuracy]

<Thermocouple>

- ±0.1% of span or ±1°C, whichever is greater when the following range is included.
  Type K, E and T: Less than –200°C
  Type B: 400°C to less than 600°C
  Type E and J: More than 750°C
  Type N: More than 1200°C
- ±0.1% of span or ±2°C, whichever is greater when the following range is included.
  Type N: Less than –200°C
- Accuracy is not guaranteed for less than 400°C of Type B.
- When the measuring range is ±20 mV in thermoelectromotive force, substitute 10 for Tm of the following expression. When ±100 mV, substitute 40. An obtained value is applied as an input accuracy.
  Tm/measuring span (mV)× input accuracy*
  *: Any of ±0.1%, ±1°C or ±2°C.
- Type K, E, T and N: For the measured temperatures less than –200°C, add the following coefficient (Te) to the input accuracy mentioned above. An obtained value is the input accuracy.
  Te [°C]=(–200 [°C] – measured temp. [°C]) / X
  (X=10 for Type K, T, and E; X=5 for Type N)
- Accuracy of reference junction compensation (RJC):
  Other than Type R and S: ±1°C (0 to 50°C)
  Type R and S: ±2°C (0 to 50°C)
  Type K, E, T and N: For the measured temperatures less than –200°C, multiply the input accuracy mentioned above by K, where
  K=(Thermocouple output change/°C near 0°C)/(Thermocouple output change/°C at measured temperature)

<RTD>

±0.05% of span or ±0.05°C, whichever is greater. For Pt50 (JIS'81), ±0.1% of span or ±0.1°C, whichever is greater.

<mV signal>

Compare the specified input range with the input range in the table below (narrower range) and choose accuracy calculation conditions. However, ±0.05% is applied if an input accuracy obtained from the expression is less than ±0.05%.

Input accuracy = ±0.05% × a/b

Input range	Accuracy calculation condition	
	a	b
±20 mV DC	10(mV)	Input span
±100 mV DC	40(mV)	
Outside of ±100 mV DC and within ±500 mV DC	200(mV)	

[Output accuracy]

Compare the specified output range with the output range in the table below (narrower range) and choose accuracy calculation conditions. However, ±0.05% is applied if an output accuracy obtained from the expression is less than ±0.05%.

Output accuracy = ±0.05% × a/b

Output signal suffix code	Output range	Accuracy calculation condition a	b
A	0 to 20 mA DC	10(mA)	Output span
B	0 to 5 mA DC	2.5(mA)	
1	±2.5 V DC	1(V)	
	Outside of ±2.5 V DC and within ±10 V DC	4(V)	
2	±25 mV DC	10(mV)	
	Outside of ±25 mV DC and within ±100 mV DC	40(mV)	

Burnout: Up, Down or Off; the maximum burnout time is specified as 60 seconds.
Response speed: 150 ms, 63% response (10 to 90%)
Effect of power supply voltage fluctuations:
±0.1% of span or less for the fluctuation within the operating range of each power supply voltage specification.
Effect of ambient temperature change:
±0.15% of span or less for a temperature change of 10°C.
Effect of leadwire resistance change:
Thermocouple: ±15 μV or less for a change of 100 Ω
RTD: ±0.2°C or less for a change of 10 Ω/wire.

■ Power Supply and Isolation

Power supply rated voltage:
15-40 V DC ⎓ or
100-240 V AC/DC ≂ 50/60 Hz
Power supply input voltage:
15-40 V DC ⎓ (±20%) or
100-240 V AC/DC ≂ (–15, +20%) 50/60 Hz
Power consumption:
24 V DC 1.7 W, 110 V DC 1.6 W
100 V AC 3.5 VA, 200 V AC 4.9 VA
Insulation resistance:
100 MΩ at 500 V DC between input, output, power supply, and grounding terminals mutually.
Withstand voltage:
2000 V AC for 1 minute between input, output, power supply and grounding terminals mutually.

■ Environmental Conditions

Operating temperature range: 0 to 50°C
Operating humidity range: 5 to 90% RH (no condensation)
Operating conditions: Avoid installation in such environments as corrosive gas like sulfide hydrogen, dust, sea breeze and direct sunlight.
Installation altitude: 2000 m or less above sea level.

■ Mounting and Dimensions

Construction: Plug-in type
Material: Main unit : ABS resin (black), UL94 V-0
ABS resin + polycarbonate resin (black), UL94 V-0
PBT resin, including glass fiber (black), UL94 V-0
Socket: Modified polyphenylene oxide resin, including glass fiber (black), UL94 V-1
Mounting: Wall or DIN rail mounting
Connection: M3.5 screw terminals
External dimensions: 86.5 (H)×51 (W)×123 (D) mm (including a socket)
Weight: Main unit: approx. 200 g
Socket: approx. 60 g

■ Accessories

Spacer: One (for DIN rail mounting)
Range label: One
RJC sensor: One (except for "/RJCN")

■ Front Panel

Output adjustment, wiring resistance correction, and ON/OFF of RJC can be made using the selection switch and adjustment switch.



Position of selection switch	Item to be adjusted
0	No function
1	Output zero adjustment
2	Output span adjustment
6	Wiring resistance correction
7	ON/OFF of RJC

■ Terminal Assignments



Terminal No.	Signal name	Thermocouple	RTD	mV signal
1	OUTPUT	(+)		
2	OUTPUT	(–)		
3	INPUT	(+)	(A)	(+)
4	INPUT	(–) RJC	(B)	(–)
5	INPUT	RJC reverse side	(B)	N.C
6	GND	(GND)		
7	SUPPLY	(L+)		
8	SUPPLY	(N–)		

■ Block Diagrams



■ External Dimensions

Unit: mm



<Mounting Dimensions>



Note:
- When mounting the units close together, leave a space of at least 5mm between them.
- Use the supplied spacer to keep a space of 5 mm for DIN rail mounting.

• The information covered in this document is subject to change without notice for reasons of improvements in quality and/or performance.