General Specifications

GS 77J05Y53-01E

Model DME Nest for Control I/O cards




General

The DME is a connector-connection type 16-unit mounting nest. It is available for connection with DCS I/O modules for the CENTUM series of Yokogawa Electric Corporation.

This nest includes the connector for portable manipulator (Yokogawa SPBD) by each loop as standard, for emergency backup of a control unit or each converter.

 Ranges and parameters can be set using DSC2 or the JHT200, Yokogawa handy terminal. (The availability depends on the model of signal conditioners.)

Model and Suffix Codes




Ordering Information

Specify the following when ordering.

• Model and suffix codes: e.g. DME-32*A

Standard Performance

Insulation resistance: 100 MΩ or more at 500 V DC between all of the following: input, output, power supply, ground, and CN1-CN2.



Withstand voltage: 1500 V AC/min. between input and (output, power supply, ground and CN1-CN2). 500 V AC/min. between all of the following: output, power supply, ground, and CN1-CN2.

Operating temperature range: 0 to 50°C Operating humidity range: 5 to 90% RH (no condensation)

Mounting and Dimensions

Connection cable: KS1 (Yokogawa-originated cable) (CN1, CN2) I/O signal connection: M4 screw terminals Power supply and ground connection: M4 screws terminals I/O cable shield connection: M3 screw terminal Mounting method: Rack or Wall mounting (horizontal mounting) Nest mounting screw: M5 screws x 4 Color: Black Weight: Approx. 3.8 kg

Standard Accessories

Plate: Installed on the empty slot when shipping Mounting bracket: 1 pair Tag number label: 16

DCS Connection Modules and Signal Conditioners

Modules connectable with CN1/CN2		Signal conditioners mountable for each slot						
		Slot	Models					
Input: 8 points Analog I/O		AAB841/M4A00 ^(*1) AMC80 ^(*2) MAC2 ^(*3)	odd-number	DA1, DA2, DA5, DH1, DH2, DH5, DM1, DT5, DR5, DRU, DS1, DP3, DF1, DB1, DG1, DD1, DSK ^(Note1) , DX1				
Analog I/O	Output: 8 points	WI (OZ ()	even-number	DC0, DSK (Note1), DX1 (Note2)				
Pulse train input	Input: 8 points	AAP849 (*1) PAC2 (*3)	odd-number	DP1, DSK (Note1), DX1 (Note2)				
Analog output	Output: 8 points		even-number	DC0, DSK ^(Note1) , DX1 ^(Note2)				

*1: FIO module of CENTUM CS3000, *2: RIO module of CENTUM CS3000/CS1000, *3: I/O card of CENTUM XL/µXL/V Note1: DSK is not connectable to DCS. DSK mounted to the slot cannot send or receive signals through CN1/CN2. Note2: DX1-21N*A and DX1-31N*A (when 250Ω is selected) cannot be mounted to this nest.



Yokogawa Electric Corporation 2-9-32, Nakacho, Musashino-shi, Tokyo, 180-8750 Japan Tel.: 81-422-52-7179 Fax.: 81-422-52-6619 GS 77J05Y53-01E ©Copyright Sept. 2007(YK) 1st Edition Sept.30, 2007(YK)

Assignment of Input/Output Terminals

Signal Conditioners		Field side I/O terminal			Front terminal of the signal conditioner					
		A	В	С	1	2	3	4	AIR	
DM1, DT5		+		-			+	-		
,							For Oi	utput 2		
							+	_		
DR5		Wiring resistance of A and B should be equal					Eor O	utput 2		
		0 0	RTD	¢.	Ŷ	Ŷ				
DRU			• W •				+	-		
5.10							For O	utput 2		
DS1		100% CE		0%			+	-		
201		Wiring resist	ance of A and C	should be equal			For O	utput 2		
	2-wire type (Voltage contact)	+		-						
DP1	Internal power supply 2-wire type	Signal	Power supply				+	-		
DP3							For Output 2			
	Internal power supply 3-wire type	+	Power supply	_			+	_		
DH1, [DH2, DH5	+		-			For O	utput 2		
		Available for the combination with BARD $\begin{array}{c} & & \\ $					+	_		
DA1, E	DA2, DA5	For 2-wire In case power supply transmitter is not necessary					For O	utput 2		
DX1		+		_						
DG1						v °± ×V	+	-		
							For O	utput 2		
DB1					A <u>P_k</u>		+	-		
					K**L			utput 2		
DD1					Vo <u></u> figt		+ For Or	utput 2		
					+ – For Output 2				0	
DF1								IN∯		
DSK		+		_	NO/NC	COM	NO/NC	COM		
DSK					Outp	out 1	Out	out 2		

Signal Conditionara	Field side I/O terminal			Front terminal of the signal conditioner				
Signal Conditioners	A	В	С	1	2	3	4	AIR
DC0	+		-					
DX1 (Note.1)	+		-					

Note.1: 250Ω type cannot be used as the output card (even-numbered slot.)

System side connecting cable

Connector No.	Signal	Cable model
CN1	Connector 1 for MAC2/PAC	KS1
CN2	Connector 2 for MAC2/PAC	KS1

CN1/CN2 connector pin assignment

CN1/CN2	CN1/CN	l2 cor	nnect	or pin assi	gnmer	nt
40 39 38 37	CN1/CN2 Pin No.	Slot	No.	CN1/CN2 Pin No.	Slot N	۱o.
36 35 34 33	40 39			20 19	4	+
32 31 30 29	38 37	1	+ -	18 17	6	+
28 27 26 25	36 35	3	+	16 15	8	+
24 23	34 33	5	+	14 13	10	+
22 21 20 19	32 31	7	+	12 11	12	+
18 17 16 15	30 29	9	+	10 09	14	+
14 13	28 27	11	+	08 07	16	+
12 11 10 09	26 25	13	+	06 05		
08 07 06 05	23 24 23	15	+	03		
04 03 02 01	20 22 21	2	+	02 01		

Odd numbered slots: input cards Even numbered slots: output cards


2

Assignment of Power Supply and Communication Terminals

4	1
6	3

Terminal number	DN	/IE-30*A	DME-32*A		
1	+		+		
2	-	24 V DC	_	24 V DC	
3	GND		GND		
4			A(-)		
5			B(+)	RS-485	
6			SG		

External Dimensions



Note A mounting method is limited to horizontal installation in 19 inch rack of the EIA/JIS-standard.