

**TECHNICAL MANUAL**

**TM 9-4931-393-34P**

**\*TM 9-4931-393-34P**  
**HEADQUARTERS**  
**DEPARTMENT OF THE ARMY**  
**WASHINGTON, DC, 8 August 1986**

**DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE**

**REPAIR PARTS AND SPECIAL TOOLS LIST**

**FOR**

**POWER METER CALIBRATOR**

**HEWLETT-PACKARD, MODEL 8402B**

**APN 7911026**

**NSN 6625-00-702-0177**

**Current as of 16 April 1986**

**REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS**

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms) to: Commander, U.S. Army TMDE Support Group, ATTN: AMXTM-LML, Redstone Arsenal, AL 35898-5400. A reply will be furnished directly to you.

**TABLE OF CONTENTS**

		Page
Section	I. INTRODUCTION.....	1
Section	II. REPAIR PARTS LIST .....	
Group	0010 Calibrator, power meter.....	2-1
Section	III. SPECIAL TOOLS LIST (Not applicable).....	
Section	IV. NATIONAL STOCK NUMBER AND PART NUMBER INDEX.....	I-1

---

\*This manual supersedes TM 9-4931-393-34P, 4 October 1977.

**DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE**

**REPAIR PARTS AND SPECIAL TOOLS LIST**

**SECTION I. INTRODUCTION**

**1. Scope.** This RPSTL lists and authorizes spares and repair parts required for performance of direct and general support maintenance of Power Meter Calibrator, Hewlett-Packard, Model 8402B. It authorizes the requisitioning, issue, and disposition of spares and repair parts as indicated by the Source, Maintenance and Recoverability (SMR) codes.

**2. General.** In addition to this section I, Introduction, the Repair Parts and Special Tools List is divided into the following sections:

a. **Section II. Repair Parts List.** A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. Parts lists are composed of functional groups in ascending numeric sequence. Parts are listed in alphabetical sequence within each figure number.


b. **Section III. Special Tools List.** Not applicable.

c. **Section IV. National Stock Number and Part Number Index.** A list, in National Item Identification Number (NIIN) sequence, of all National Stock Numbered (NSN) items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listing. NSN's and part numbers are cross-referenced to the figure and item number appearance.

**3. Explanation of Columns (Section 11)**

a. **Item No. (Column (1)).** Indicates the number used to identify each item appearing in the listing.

b. **SMR CODE (Column (2)).** The Source, Maintenance, and Recoverability (SMR) code is a 5- position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instructions as shown in the following breakdown:



\*Complete Repair: Maintenance capacity, capability, and authority to perform all the corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.

(1) **Source Code.** The source code tells you how you get an item needed for maintenance, repair, or overhaul of an end item/equipment. Source codes are always the first two positions of the SMR code. Explanation of source codes follows:

<b>Code</b>	<b>Explanation</b>
PA -	Stocked items; use the applicable NSN to request/requisition items with this code. This item is authorized to the category indicated by the code entered in the 3d position of the SMR code.
XD -	Item is not stocked. Order an "XD" coded item through normal supply channels using the FSCM and part number given, if no NSN is available.

(2) **Maintenance Code.** Maintenance codes tell you the level(s) of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the SMR code as follows:

(a) The maintenance code entered in the third position tells you the lowest maintenance level authorized to remove, replace, and use an item. The maintenance code entered in the third position will indicate authorization to the following level of maintenance.

<b>Code</b>	<b>Application/Explanation</b>
F	-Direct support level can remove, replace, and use the item.
(b)	The maintenance code entered in the fourth position tells you whether or not the item is to be repaired and identifies the lowest maintenance level with the capability to do complete repair (i.e., perform all authorized repair functions). This position will contain the following code.

<b>Code</b>	<b>Application/Explanation</b>
Z	-Non-reparable. No repair is authorized.

(3) **Recoverability Code.** Recoverability codes are assigned to items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the SMR code as follows:

<b>Recoverability Codes</b>	<b>Definition</b>
Z	-Non-reparable item. When unserviceable, condemn and dispose of the item at the level of maintenance shown in the third position of the SMR code.

**c. FSCM (Column (3)).** The Federal Supply Code for Manufacturer (FSCM) is a 5-digit numeric code which is used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

**d. PART NUMBER (Column (4)).** Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements to identify an item or range of items.

**NOTE:** When you use an NSN to requisition an item, the item you receive may have a different part number from the part ordered, but go ahead and use or furnish it as the replacement part.

**e. DESCRIPTION AND USABLE ON CODE (UOC) (Column (5)).** This column includes the following information:

- (1) The Federal item name and, when required, a minimum description to identify the item.
- (2) The usable on code, when applicable (see paragraph 5, Special Information).

**f. QTY (Column (6)).** The QTY (quantity per figure column) indicates the quantity of the item used in the parts list which is prepared for a functional group, sub-functional group, or an assembly.

#### 4. Explanation of Columns (Section IV)

##### a. NATIONAL STOCK NUMBER (NSN) INDEX

(1) **STOCK NUMBER column.** This column lists the NSN by National item identification number (NIIN) sequence. The NIIN consists of the last nine digits of the NSN

NSN  
(i.e., 5305-01-674-1467). When using this column to locate an item, ignore the first 4 digits of the  
NIIN  
NSN. However, the complete NSN should be used when ordering items by stock number.

(2) **FIG. column.** Indicates the figure number used to identify each item appearing in the listing. The figures are in numerical order in Section II.

(3) **ITEM column.** The item number identifies the item associated with the figure listed in the adjacent FIG. column. This item is also identified by the NSN listed on the same line.

**b. PART NUMBER INDEX.** Part numbers in this index are listed by part number in ascending alphanumeric sequence (i.e., vertical arrangement of letter and number combination which places the first letter or digit of each group in order A through Z, followed by the numbers 0 through 9 and each following letter or digit in like order).

(1) **FSCM column.** The Federal Supply Code for Manufacturer (FSCM) is a 5-digit numeric code used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

(2) **PART NUMBER column.** Indicates the primary number used by the manufacturer (individual, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements to identify an item or range of items.

(3) **STOCK NUMBER column.** This column lists the NSN for the associated part number and manufacturer identified in the PART NUMBER and FSCM columns to the left. The part number line entry (with NSN, when available) identifies the first figure/item number appearance for which the part number is applicable. The part number is not listed for additional figure/item number appearances identified by that part number.

(4) **FIG. column.** This column lists the number of the figure where the item is located in Section 11.

(5) **ITEM column.** The item number is that number assigned to the item as it appears in the figure referenced in the adjacent figure number column.

## 5. Special Information

a. Repair parts for components of standards sets which can be identified as existing in the supply system will be requisitioned through normal supply channels from the appropriate supply commodity manager.

b. Repair parts for components of standards sets which cannot be identified as to proper supply source will be requisitioned from USAMICOM, using routing identifier B64 and furnishing, as a minimum, the following as exception data.

(1) Component stock number of the individual end item to be repaired.

(2) Component manufacturer's equipment model number and serial number.

(3) The equipment manufacturer's stock number as listed in the appropriate manual for the desired repair part.

(4) The repair part reference designation, circuit reference, circuit symbol schematic designation, or reference number as listed in the manufacturer's manual.

(5) The technical specification of the repair part as contained in the appropriate manufacturer's manual.

(6) The title and date of the manufacturer's manual from which the information in a and b(3), (4), and (5) above was taken.

c. For requisitioning miscellaneous consumable maintenance supplies or expendable supplies, use CTA 50-970.

d. The usable on code appears in the lower left corner of the Description column heading. Usable on codes are shown as "UOC" in the Description column (justified left) on the first line applicable item description/nomenclature.

e. This RPSTL does not contain illustration for items listed in Section II, since the manufacturer's manuals contain exploded view illustrations which are adequate for repair parts location. Copies of the manufacturer's manual Hewlett-Packard, Model 8402B are furnished with the equipment for which this RPSTL is prepared. The figure and item numbers in the listing are for locating the item within this RPSTL.

## 6. How to Locate Repair Parts

### a. When National Stock Number or Part Number is Not Known.

(1) **First.** Refer to the parts list to locate the item by description. This list is listed in alphabetical sequence within each figure number.

(2) **Second.** After locating the item in the Repair Parts List, refer to the Part Number Index to find the NSN.

### b. When National Stock Number or Part Number is Known.

(1) **First.** Using the Index of National Stock Numbers and Part Numbers, find the pertinent National Stock Number or Part Number. The NSN index is in National Item Identification Number (NIIN) sequence. The part numbers in the Part Number index are listed in ascending alphanumeric sequence. Both indexes cross-reference you to the illustration figure and item number of the item you are looking for.

(2) **Second.** After finding the figure and item number, verify that the item is the one you're looking for, then locate the item number in the repair parts list for the figure.

## 7. Abbreviations. Not applicable.

## SECTION II

TM9-4931-393-34P

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 0010 - FIGURE 1 CALIBRATOR, POWER METER 8402B (28480)) 7911026 (19200)					
10	XDFZZ	18876	10018712-004	CAPACITOR, FIXED 10 V DC, 33 UF ( 10 0/0).....	1
20	XDFZZ	28480	0160-0168	CAPACITOR, FIXED .....	1
30	XDFZZ	56289	400D10F050CC4	CAPACITOR, .....	2
40	PAFZZ	18876	11065337-010	CAPACITOR, FIXED 50 V DC, 40 UF .....	2
50	PAFZZ	81349	CMRO5F151GODR	CAPACITOR, FIXED, MIC .....	1
60	PAFZZ	28480	0140-0157	CAPACITOR, FIXED, MIC MICA, 1857 PF 1 PCT 500 VDCW .....	2
70	PAFZZ	56289	192P82292	CAPACITOR, FIXED, PAP .....	1
80	PAFZZ	28480	0160-0165	CAPACITOR, FIXED PLA .....	1
90	PAFZZ	28480	08402-6001	CIRCUIT CARD ASSEMB .....	1
100	PAFZZ	18876	9995407	CONNECTOR, RECEPTACL 3 MALE CONTACTS, PLASTIC DIELECTRIC, POLARIZED, STGHT SHAPE, 0.84 W, 0.62 H, 1.88 LG .....	1
100	PAFZZ	28480	1251-0153	CONNECTOR, RECEPTACL .....	1
120	XDFZZ	28480	1250-0083	CONNECTOR .....	1
130	PAFZZ	81349	F02A250V1/4A	FUSE, CARTRIDGE 1-4 AMP1250 V .....	1
140	PAFZZ	28480	1400-0084	FUSEHOLDER, EXTRACTO .....	1
150	PAFZZ	28480	0340-0090	INSULATOR, PLATE .....	1
160	PAFZZ	28480	0340-0086	INSULATOR, PLATE .....	2
170	PAFZZ	28480	0370-0067	KNOB .....	1
180	PAFZZ	28480	0370-0112	KNOB .....	4
190	PAFZZ	28480	0370-0064	KNOB .....	1
200	PAFZZ	49956	1450-0048	LIGHT, INDICATOR .....	1
210	PAFZZ	18876	8192704	POST, BINDING, ELECTR BR, NI-PLTD FIN., 3/8 DIA, 19/32 H .....	3
220	PAFZZ	18876	9100817	POST, BINDING, ELECTR PLASTIC CAP, BR NI-PLTD FIN. BASE, 1/2 DIA, 19/32 H OF POST ABOVE MTG SUPFACE .....	1
225	PAFZZ	81349	RNC55K124FS	RESISTOR .....	1
230	PAFZZ	28460	0698-0024	RESISTOR, FIXED, COMP .....	1
240	XDFZZ	28480	C698-3260	RESISTOR, FIXED, FILM .....	1
250	XDFZZ	28480	0757-0123	RESISTOR, FIXED, FIILM .....	1
260	XDFZZ	28480	0698-3167	RESISTOR, FIXED, FILM .....	1
270	PAFZZ	81349	RNC55K4992FS	RESISTOR, FIXED, FILM .....	1
280	PAFZZ	81349	RNC70K1471FS	RESISTOR, FIXED, FILM .....	1
290	PAFZZ	81349	RNC55K1692FS	RESISTOR, FIXED, FILM .....	1
300	PAFZZ	81349	RNC55K10R0FS	RESISTOR, FIXED, FILM .....	2
310	PAFZZ	81349	RNC55K5621FS	RESISTOR, FIXED, FILM .....	1
320	PAFZZ	81349	RNC55K1000FS	RESISTOR, FIXED, FILM .....	2
330	PAFZZ	81349	RNC55K3322FS	RESISTOR, FIXED, FILM FSCM 28480 P/N 0757-0454 .....	1
340	PAFZZ	81349	RNC55K56R2FS	RESISTOR, FIXED, FILM .....	1
350	XDFZZ	28480	0698-3136	RESISTOR, FIXED, FILM .....	1
360	PAFZZ	61349	RNC55K9091FS	RESISTOR, FIXED, FILM PN 0757-0288 .....	1

## SECTION II

TM9-4931-393-34P

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
370	XDFZZ	28480	0698-4307	FSCM 28480 .....	
390	XDFZZ	28480	0757-0443	RESISTOR, FIXED, FILM.....	1
400	XDFZZ	28480	0811-1684	RESISTOR, FIXED, FILM.....	1
410	PAFZZ	81349	RNC55K14R7FS	RESISTOR, FIXED, FILM FSCM 28480 P/N 0698-3428.....	2
420	PAFZZ	81349	RNC55K1621FS	RESISTOR, FIXED, FILM.....	1
430	PAFZZ	81349	RNC55K1332FS	RESISTOR, FIXED, FILM.....	1
440	PAFZZ	81349	RNC55K1962FS	RESISTOR, FIXED, FILM.....	2
450	XDFZZ	28480	0698-3162	RESISTOR, FIXED, FILM.....	1
460	XDFZZ	28480	0698-3154	RESISTOR, FIXED, FILM.....	1
470	XDFZZ	28480	0698-3408	RESISTOR, FIXED, FILM.....	1
480	XDFZZ	28480	0698-3459	RESISTOR, FIXED, FILM.....	1
490	XDFZZ	28480	0698-3243	RESISTOR, FIXED, FILM.....	1
500	PAFZZ	81349	KNC55K3831FS	RESISTOR, FIXED, FILM.....	1
510	PAFZZ	81349	RNC55K2002FS	RESISTOR, FIXED, FILM.....	1
520	PAFZZ	81349	RNC55K1003FS	RESISTOR, FIXED, FILM 100K OHM, 1PCT, 1-8 WATT .....	1
530	XDFZZ	28480	0757-0442	RESISTOR, FIXED, FILM.....	2
540	XDFZZ	28480	0757-0438	RESISTOR, FIXED, FILM.....	1
550	PAFZZ	81349	RNC55K6810FS	RESISTOR, FIXED, FILM.....	1
560	PAFZZ	28480	0757-0416	RESISTOR, FIXED, FILM.....	3
570	XDFZZ	75042	CEATO-2000F	RESISTOR, FIXED, FILM.....	2
530	XDFZZ	28480	0811-1687	RESISTOR, FIXED, WIRE .....	1
590	XDFZZ	28480	0811-1685	RESISTOR, FIXED, WIRE .....	1
600	PAFZZ	81349	RBR53L28021BR	RESISTOR, FIXED, WIRE .....	1
610	PAFZZ	81349	RBR53L88500BR	RESISTOR, FIXED, WIRE .....	1
620	XDFZZ	28480	0811-1680	RESISTOR, FIXED, WIRE .....	1
630	XDFZZ	28480	0811-1681	RESISTOR, FIXED, WIRE .....	1
640	PAFZZ	28480	0811-1686	RESISTOR, FIXED, WIRE .....	1
650	XDFZZ	28480	0811-1682	RESISTOR, FIXED, WIRE .....	1
660	XDFZZ	28480	0811-1648	RESISTOR, FIXED, WIRE .....	1
670	PAFZZ	81349	RBR55L100R6BR	RESISTOR, FIXED, WIRE .....	1
680	XDFZZ	28480	0811-1646	RESISTOR, FIXED, WIRE .....	1
690	XDFZZ	28480	0811-1679	RESISTOR, FIXED, WIRE .....	1
700	XDFZZ	28480	0811-1688	RESISTOR, FIXED, WIRE .....	1
710	XDFZZ	28480	0811-1690	RESISTOR, VARIABLE .....	1
720	PAFZZ	28480	2100-1611	RESISTOR, VARIABLE, W .....	1
730	PAFZZ	28480	2100-0052	RESISTOR, VARIABLE, N NONWIRE WOUND ELEMENT .....	2
740	PAFZZ	28480	2100-1772	RESISTOR, VARIABLE, W .....	1
750	PAFZZ	28480	2100-1767	RESISTOR, VARIABLE, W .....	7
760	PAFZZ	28480	2100-1769	RESISTOR, VARIABLE, W .....	3
770	PAFZZ	28480	2100-1770	RESISTOR, VARIABLE, W .....	1
780	PAFZZ	28480	2100-1771	RESISTOR, VARIABLE, W .....	1
790	PAFZZ	18876	11031494-4	SEMICONDUCTOR DEVIC.....	6
800	XDFZZ	28480	1902-0785	SEMICONDUCTOR DEVIC.....	1
810	PAFZZ	28480	1902-0044	SEMICONDUCTOR DEVIC.....	1
815	PAFZZ	28480	1854-0221	SEMICONDUCTOR DEVIC.....	1
820	PAFZZ	28480	3100-1848	SWITCH, ROTARY.....	1
830	PAFZZ	28480	3100-1849	SWITCH, ROTARY.....	1
840	PAFZZ	28480	3100-1847	SWITCH, ROTARY.....	1

**SECTION II****TM9-4931-393-34P**

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
850	PAFZZ	28480	3100-1853	SWITCH, ROTARY .....	1
860	PAFZZ	18876	11065244	SWITCH, SLIDE DPDT, 125 V AC, 3 AMP 125 V DC, 0.5 AMP, 9/32 H, 17/32 W, 1-3/ 8 LG, W/6 SOLDER LUG TYPE TERM,.....	1
870	XDFZZ	28480	9100-1733	TRANSFORMER, POWER .....	1
880	PAFZZ	28480	9100-0400	TRANSFORMER, POWER .....	1
890	PAFZZ	81349	JAN2N2905A	TRANSISTOR SILICON, HERMETICALLY SEALED.0.26 X 0.37, W/3 WIRE LEAD TYPE TERM .....	1
900	PAFZZ	18876	10041335	TRANSISTOR.....	1
910	PAFZZ	28480	1854-0045	TRANSISTOR.....	1
920	PAFZZ	28480	1853-0020	TRANSISTOR.....	2
930	XDFZZ	18876	7914063	TRANSISTOR.....	1

## NATIONAL STOCK NUMBER AND PART NUMBER INDEX

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
5920-00-043-2641	1	130	5961-00-949-1440	1	890
5961-00-059-3063	1	910	5355-00-976-4343	1	190
6210-00-085-4526	1	200	5930-00-977-1760	1	860
5935-00-089-5883	1	100	5961-00-978-7468	1	790
5905-00-208-4293	1	520	5961-00-983-0313	1	810
5970-00-225-8549	1	150	5905-00-988-0921	1	730
5905-00-232-9602	1	410	5905-00-998-1795	1	560
5905-00-243-2199	1	300	5910-01-030-1770	1	50
5905-00-250-5986	1	270	5905-01-163-2149	1	600
5970-00-269-7037	1	160	5905-01-163-2150	1	610
5905-00-270-1400	1	550	5905-01-168-3226	1	670
5905-00-431-7826	1	225			
5905-00-431-7833	1	360			
5905-00-432-0380	1	320			
5905-00-432-0387	1	430			
5905-00-432-0396	1	290			
5905-00-432-0402	1	510			
5905-00-432-6373	1	420			
5905-00-432-6375	1	440			
5905-00-432-6384	1	310			
6625-00-498-6460	1	90			
5905-00-499-6934	1	500			
5940-00-626-7653	1	220			
5905-00-721-3724	1	340			
5905-00-758-4795	1	330			
5961-00-761-9379	1	900			
5355-00-809-9330	1	170			
5910-00-810-6735	1	40			
5940-00-815-2612	1	210			
5961-00-836-1887	1	815			
5920-00-881-4636	1	140			
5905-00-891-2808	1	230			
5935-00-891-4204	1	110			
5950-00-891-4206	1	880			
5910-00-891-4208	1	80			
5905-00-891-4218	1	780			
5905-00-891-4221	1	740			
5905-00-891-4230	1	760			
5905-00-891-4235	1	750			
5905-00-891-4242	1	640			
5910-00-891-4245	1	60			
5930-00-891-4251	1	820			
5930-00-898-1797	1	830			
5930-00-898-1798	1	840			
5930-00-898-1822	1	850			
5961-00-904-2540	1	920			
5355-00-919-9953	1	180			
5905-00-927-8491	1	720			
5905-00-931-6980	1	770			
5910-00-947-1045	1	70			

**NATIONAL STOCK NUMBER AND PART NUMBER INDEX**  
**PART NUMBER INDEX**

FSCM	PART NUMBER	STOCK NUMBER	FIG.	ITEM
75042	CEATO-2000F		1	570
81349	CMR05F151G0DR	5910-01-030-1770	1	50
81349	F02A250V1/4A	5920-00-043-2641	1	130
81349	JAN2N2905A	5961-00-949-1440	1	890
81349	RbR53L28021BR	5905-01-163-2149	1	600
81349	RBR53L86500BR	5905-01-163-2150	1	610
81349	RBR55L100R6BR	5905-01-168-3226	1	670
81349	RNC55K10R0FS	5905-00-243-2199	1	300
81349	RNC55K1000FS	5905-00-432-0380	1	320
81349	RNC55K1003FS	5905-00-208-4293	1	520
81349	RNC55K1242FS	5905-00-431-7826	1	225
81349	RNC55K1332FS	5905-00-432-0387	1	430
81349	RNC55K14R7FS	5905-00-232-9602	1	410
81349	RNC55K1621FS	5905-00-432-6373	1	420
81349	RNC55K1692FS	5905-00-432-0396	1	290
81349	RNC55K1962FS	5905-00-432-6375	1	440
81349	RNC55K2002FS	5905-00-432-0402	1	510
81349	RNC55K3322FS	5905-00-758-4795	1	330
81349	RNC55K3831FS	5905-00-499-6934	1	500
81349	RNC55K4992FS	5905-00-250-5986	1	270
81349	RNC55K56R2FS	5905-00-721-3724	1	340
81349	RNC55K5621FS	5905-00-432-6384	1	310
81349	RNC55K6810FS	5905-00-270-1400	1	550
81349	RNC55K9091FS	5905-00-431-7833	1	360
81349	RNC70K1471FS		1	280
28480	0140-0157	5910-00-891-4245	1	60
28480	0160-0165	5910-00-891-4208	1	80
28480	0160-0168		1	20
28480	0340-0086	5970-00-269-7037	1	160
28480	0340-0090	5970-00-225-8549	1	150
26480	0370-0064	5355-00-976-4343	1	190
28480	0370-0067	5355-00-809-9330	1	170
28480	0370-0112	5355-00-919-9953	1	180
28480	0698-0024	5905-00-891-2808	1	230
28480	0698-3136		1	350
28480	0698-3154		1	460
28480	0698-3162		1	450
28480	0698-3167		1	260
28480	0698-3243		1	490
28480	0698-3260		1	240
28480	0698-3408		1	470
28480	0698-3459		1	480
28480	0698-4307		1	370
28480	0757-0123			250
28480	0757-0416	5905-00-998-1795	1	560
28480	0757-0438		1	540
28480	0757-0442		1	530
28480	0757-0443		1	390
28480	0811-1646		1	680
28480	0811-1648		1	660
28480	0811-1679		1	690

**NATIONAL STOCK NUMBER AND PART NUMBER INDEX**  
**PART NUMBER INDEX**

FSCM	PART NUMBER	STOCK NUMBER	FIG.	ITEM
28480	0811-1680		1	620
28480	0811-1681		1	630
28480	0811-1682		1	650
28480	0811-1684		1	400
28480	0811-1685		1	590
28480	0811-1686	5905-00-891-4242	1	640
28480	0811-1687		1	580
28480	0811-1688		1	700
28480	0811-1190		1	710
28480	08402-6001	6625-00-498-6460	1	90
18876	10018712-004		1	10
18876	10041335	5961-00-761-9379	1	900
18876	11031494-1	5961-00-978-7468	1	790
18876	11065244	5930-00-977-1760	1	860
18876	11065337-010	5910-00-810-6735	1	40
28480	1250-0083		1	120
28480	1251-0153	5935-00-891-4204	1	110
28480	1400-0084	5S20-00-881-4636	1	140
49956	1450-0048	6210-00-085-4526	1	200
28480	1853-0020	5961-00-9042540	1	920
28480	1854-0045	5961-00-059-3063	1	910
28480	1854-0221	5961-00-836-1887	1	815
28480	1902-0044	5961-00-983-0313	1	810
28480	1902-0785		1	800
56289	192P82292	5910-00-947-1045	1	70
28480	2100-0052	5905-00-988-0921	1	730
28480	2100-1611	5905-00-927-8491	1	720
28480	2100-1767	5905-00-891-4235	1	750
28480	2100-1769	5905-00-891-4230	1	760
28480	2100-1770	5905-00-931-6980	1	770
28480	2100-1771	5905-00-891-4218	1	780
28480	2100-1772	5905-00-891-4221	1	740
23480	3100-1847	5930-00-898-1798	1	840
28480	3100-1848	5930-00-891-4251	1	820
28480	3100-1849	5930-00-898-1797	1	830
28480	3100-1853	5930-00-898-1822	1	850
56289	40D106F050CC4		1	30
18876	7914063		1	930
18876	8192704	5940-00-815-2612	1	210
28480	9100-0400	5950-00-891-4206	1	880
28480	9100-1733		1	870
18876	9100817	5940-00-626-7653	1	220
18876	9995407	5935-00-089-5883	1	100

By Order of the Secretary of the Army:

JOHN A. WICKHAM, JR.  
*General, United States Army*  
*Chief of Staff*

Official:

R. L. DILWORTH  
*Brigadier General, United States Army*  
*The Adjutant General*

Distribution:

To be distributed in accordance with DA Form 12-34C, Block No. 319, requirements for calibration procedures publications.

\* U.S. Government Printing Office: 1986-698-078/40166

PIN: 022703 000

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

SOMETHING WRONG WITH THIS PUBLICATION?



THEN. . JOT DOWN THE  
DOPE ABOUT IT ON THIS  
FORM, CAREFULLY TEAR IT  
OUT, FOLD IT AND DROP IT  
IN THE MAIL!

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 11-5825-270-10

PUBLICATION DATE

23 Jul 81

PUBLICATION TITLE

Radio Frequency R-2176/FRN

BE EXACT. . PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG  
AND WHAT SHOULD BE DONE ABOUT IT:

PAGE  
NO.

PARA-  
GRAPH

FIGURE  
NO.

TABLE  
NO.

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 2028-2  
1 JUL 79

PREVIOUS EDITIONS  
• ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR  
RECOMMENDATION MAKE A CARBON COPY OF THIS  
AND GIVE IT TO YOUR HEADQUARTERS.

**PIN 022703**