

**TM 11-5895-687-20P**

---

**TECHNICAL MANUAL  
ORGANIZATIONAL MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS LIST  
FOR**

**INTERROGATOR SET AN/TPX-50 (NSN 5895-00-782-5296)**

---

**HEADQUARTERS, DEPARTMENT OF THE ARMY**

**JULY 1977**



TECHNICAL MANUAL }  
NO. 11-5895-687-20P }

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, DC, 19 Jul 1977

ORGANIZATIONAL MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS LISTS  
FOR

INTERROGATOR SET AN/TPX-50 (NSN 5895-00-782-5296)  
Current as of 20 April 1977

REPORTING OF ERRORS

You can improve this manual by recommend improvement using DA Form 2028-2 (Test) located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 (Test) in the back of your manual, use the standard DA Form 2028 (Recommended Changes to publication and Blank Forms) and forward to the Commander, US Army Electronics Command ATTN: DRSEL-MA-Q, Fort Monmouth, NJ 07703.

In either case a reply will be furnished direct to you.

Table of Contents

	Page	Illus Figure
SECTION I. Introduction .....	1	
II. Repair parts list .....	5	
Group 00 Interrogator Set AN/TPX-50 .....	5	1
Cable Assembly, Special purpose Electrical CX-10876/U (7 ft 8 in) .....	7	2
Cable Assembly, Special purpose, Electrical Branched, CX-10878/TPX-50 .....	9	3
Programmer Kit MK-1161/TPX-50 .....	11	4
01 Interrogator Set Group OX-8/TPX-50 .....	13	5
0101 Signal Processor CP-936/TPX-50 .....	15	6
0102 Synchronizer, Electrical SN-421/TPX-50 .....	17	7
0103 Receiver-Transmitter, Radio RT-903/TPX-50 .....	19	8
02 Control, Interrogator Set C-7651/TPX-50 .....		
SECTION III. Special tools list (Not applicable)	20	
IV. National stock number and part numbr index .....		



## SECTION I INTRODUCTION

### 1. Scope

This manual lists repair parts required for performance of organizational maintenance of the AN/TPX-50.

### 2. General

This Repair Parts and Special Tools List is divided into the following sections:

*a. Section II. Repair Parts List.* A list of repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending numerical sequence, with the parts in each group listed in figure and item number sequence.

*b. Section III. Special Tool List.* Not applicable.

*c. Section IV. National Stock Number and Part Number Index.* A list, in ascending numerical sequence, of all National stock numbers appearing in the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

### 3. Explanation of Columns

The following provides an explanation of columns found in the tabular listings

*a. Illustration.* This column is divided as follows

(1) *Figure number.* Indicates the figure number of the illustration in which the item is shown.

(2) *Item number.* The number used to identify each item called out in the illustration.

*b. Source, Maintenance, and Recoverability Codes (SMR).*

(1) *Source code.* Source codes are assigned to support items to indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
PA	Item procured and stocked for anticipated or known usage.
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.

PD—Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.

#### NOTE

Cannibalization or salvage may be used as a

source of supply for any items source coded above except three coded XA, XD, and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows

(a) *The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate the following level of maintenance:*

Code	Application/Explanation
0	Support item is removed, replaced, used at the organizational level.
F	The lowest maintenance level capable of complete repair of the support item is the direct support level.
D	The lowest maintenance level capable of complete repair of the support item is the depot level, performed by depot.
Z	Nonreparable. No repair is authorized.

0—Support item is removed, replaced, used at the organizational level.

(b) *The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:*

Code	Application/Explanation
F	The lowest maintenance level capable of complete repair of the support item is the direct support level.
D	The lowest maintenance level capable of complete repair of the support item is the depot level, performed by depot.
Z	Nonreparable. No repair is authorized.

F—The lowest maintenance level capable of complete repair of the support item is the direct support level.

D—The lowest maintenance level capable of complete repair of the support item is the depot level, performed by depot.

Z—Nonreparable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability Codes	Definition
Z	Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
F	Reparable item. When uneconomically repairable, condemn and dispose at the direct support level.
D	Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L	Reparable item. Repair, condemnation, and disposal not authorized below depot/specializes repair activity level.

Z—Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.

F—Reparable item. When uneconomically repairable, condemn and dispose at the direct support level.

D—Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.

L—Reparable item. Repair, condemnation, and disposal not authorized below depot/specializes repair activity level.

*c. National Stock Number.* Indicates the National stock number assigned to the item and will be used for

requisitioning purposes.

*d. Part Number.* Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specification standards, and inspection requirements, to identify an item or range of items.

**NOTE**

When a stock-numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

*Federal Supply Code for Manufacturer (FSCM)*

The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.

*f. Description.* Indicates the Federal item name and, if required, a minimum description to identify the item.

*g. Unit of Measure (U/M).* Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc.). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

*h. Quantity Incorporated in Unit.* Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column in lieu of a quantity indicates that no specific quantity is applicable, (e.g., shims, spacers, etc.).

**4. Special Information**

*a.* The following publication pertains to the AN/TPX-50 and its components

TM 11-5895-687-12, Interrogator Set AN/TPX-50.

*b.* The illustrations in this manual are identical to those published in TM 11-5895-687-34P-1, TM 11-5895-887-34P-2, TM 11-5895-687-34P-3, and TM 11-5895-687-34P-4. Only those parts assigned

the third position SMR maintenance code "O" are listed in the tabular listing; therefore, there may be a break in the item number sequence. Only illustrations containing organizational authorized items appear in this manual.

*c.* National stock numbers (NSN's) that are missing from P source-coded items have been applied for and will be added to this TM by future change/revision when they are entered in the Army Master Data File (AMDF). Until the NSN's are established and published, submit exception requisitions to: Commander, US Army Electronics Command, ATTN: DRSEL-MM, Fort Monmouth, NJ 07703 for the part required to support your equipment.

**5. How to Locate Repair Parts**

*a.* When National stock number or part number is unknown:

(1) *First.* Using the table of contents, determine the functional group or subgroup within which the repair part belongs. This is necessary since illustrations are prepared for functional groups or subgroups, and listings are divided into the same groups.

(2) *Second.* Find the illustration covering functional group or subgroup to which the repair part belongs.

(3) *Third.* Identify the repair part on the illustration and note the illustration figure and item number of the repair part.

(4) *Fourth.* Using the Repair Parts Listing, find the figure and item number noted on the illustration.

*b.* When National stock number or part number is known:

(1) *First.* Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in ascending NSN sequence, followed by a list of part numbers in ascending alphanumeric sequence, cross-referenced to the illustration figure number and item number.


(2) *Second.* After finding the figure and item number, locate the figure and item number in the repair parts list.

**6. Abbreviations**

(Not applicable.)

(Next printed page is 4.)





**NOTE:**  
REFERENCE DESIGNATIONS ARE ABBREVIATED,  
PREFIX REFERENCE DESIGNATION WITH WI.  
E00B001

Figure 1. Cable Assembly, Special, Electrical CX-10876/U.



SECTION II (1) ILLUSTRATION (A) (B) FIG ITEM NO NO		(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	TM11-5895-687-20P (6) DESCRIPTION	USABLE ON CODE	(7) U/M	(8) QTY INC IN UNIT
GROUP: 00 INTERROGATER SET AN/TPX-50									
1		PAODZ	5995-00-136-4980	SMB679388	80063	CABLE ASSEMBLY,SPECIAL PURPOSE,ELECTRICAL CX-10876/U		EA	1
1	2	PAOZZ	5970-00-828-3451	202A163-3	06090	CAP,PROTECTIVE,DUST AND MOISTURE SEAL		EA	1
1	9	PAOZZ	5970-00-904-2491	222A174-3	06090	CAP,PROTECTIVE,DUST AND MOISTURE SEAL		EA	1





Figure 2. Cable Assembly, Special Purpose, Electrical, Branched CX-10878/TPX-50.

SECTION II		TM11-5895-687-20P						
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	
ILLUSTRATION					DESCRIPTION		QTY	
(A)	(B)	SMR	NATIONAL	PART			INC	
FIG	ITEM	CODE	STOCK	NUMBER	FSCM	USABLE ON CODE	U/M	
NO	NO		NUMBER				UNIT	
2		PAODD	5995-00-132-3321	SMC679298	80063	CX-10878/TPX-50CABLE ASSEMBLY CX-10878/TPX-50	EA	1



ELO08003

Figure 3. Programmer Kit MK-1161/TPX-50.

SECTION II		TM11-5895-687-20P						
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	
ILLUSTRATION								
(A)	(B)	NATIONAL	PART		DESCRIPTION		QTY	
FIG	ITEM	STOCK	NUMBER	FSCM		USABLE ON CODE	INC	
NO	NO	NUMBER	NUMBER				IN	
							UNIT	
3	1	PDOFF	5895-00-133-1193	SMB679374	80063	MK-1161/TPX-50, PROGRAMMER KIT	EA	1
3	2	PAOZZ	5895-00-410-2423	SMC680134	80063	PROGRAM CONNECTOR	EA	1
3	3	PAOZZ	5895-00-410-2425	SMB679374	80063	PROGRAM CONNECTOR	EA	1
3	4	PAOZZ	5895-00-410-2421	SMC680136	80063	PROGRAM CONNECTOR	EA	1
3	5	PAOZZ	5895-00-410-2420	SMC680137	80063	PROGRAM CONNECTOR	EA	1
3	6	PAOZZ	5895-00-410-2419	SMC680138	80063	PROGRAM CONNECTOR	EA	1
3	7	PAOZZ	5895-00-410-2422	SMC680135	80063	PROGRAM CONNECTOR	EA	1





Figure 4. Interrogator Set Group OX-8/TPX-60.

SECTION II		TM11-5895-687-20P					
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION							
(A)	(B)	NATIONAL			DESCRIPTION		QTY
FIG	ITEM	STOCK	PART	FSCM		USABLE ON CODE	INC
NO	NO	NUMBER	NUMBER			U/M	IN
							UNIT
					GROUP: 01 INTERROGATOR SET GROUP		
					OX-8/TPX-50		
4		PDODD 5895-00-130-5817	SME679363	80063	INTERROGATOR SET GROUP OX-8/TPX-50		EA 1
4	3	PDODD 5895-00-129-6066	SME679362	80063	CABINET, INTERROGATOR SET GROUP CY-6442/TPX-50		EA 1
4	5	PDODD 5895-00-130-5815	SMD679393	80063	RECEIVER-TRANSMITTER, RADIO RT-903/TPX-50		EA 1
4	6	PDODD 5895-00-130-5814	SME679364	80063	SYNCHRONIZER, ELECTRICAL SN-421/TPX-50		EA 1
4	7	PDODD 5895-00-135-9106	SME679365	80063	SIGNAL PROCESSOR CP-936/TPX-50		EA 1
4	11	PAOZZ 6240-00-763-7744	CM387	71744	LAMP, INCANDESCENT		EA 1



NOTE:  
 REFERENCE DESIGNATIONS ARE ABBREVIATED,  
 PREFIX REFERENCE DESIGNATION WITH IAI.

ELO08005

Figure 5. Signal Processor CP936/TPX-50.



SECTION II		TM11-5895-687-20P						
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	
ILLUSTRATION					DESCRIPTION		QTY	
(A)	(B)	NATIONAL	PART	FSCM		USABLE ON CODE	INC	
FIG	ITEM	STOCK	NUMBER			U/M	IN	
NO	NO	CODE	NUMBER				UNIT	
GROUP: 0101 SIGNAL PROCESSOR								
CP-936/TPX-50								
5	9	PAODL	5895-00-410-9954	SMD680109	80063		EA 1	
5	13	PAODL	5895-00-410-9959	SMD680108	80063		EA 1	
5	17	PAODL	5895-00-410-9950	SMD679369	80063		EA 1	
5	18	PAODL	5895-00-410-9953	SMD680111	80063		EA 1	
5	19	PAODL	5895-00-410-9958	SMD680110	80063		EA 1	
5	34	PAOZZ	6240-00-763-7744	CM387	71744		EA 5	




Figure 6. Synchronizer, Electrical SN-421/TPX-50.

ELOOB006

SECTION II						TM11-5895-687-20P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)		
ILLUSTRATION							QTY		
(A)	(B)	NATIONAL			DESCRIPTION		INC		
FIG	ITEM	STOCK	PART	FSCM		USABLE ON CODE	U/M	IN	
NO	NO	CODE	NUMBER					UNIT	
GROUP: 0102 SYNCHRONIZER, ELECTRICAL									
SN-421/TPX-50									
6	11	PAOFL	5895-00-410-9967	SMC679286	80063	DELAY MODULE	EA	1	
6	12	PAODL	5895-00-437-2394	SMD679367	80063	INTERFACE MODULE	EA	1	
6	13	PAODL	5895-00-437-2386	SMD680112	80063	CODER DECODER MODULE	EA	1	
6	14	PAODL	5895-00-437-2397	SMD679299	80063	POWER SUPPLY MODULE	EA	1	
6	15	PAODL	5895-00-419-9649	SMD680107	80063	TIMING MODULE	EA	1	
6	22	PAOZZ	6240-00-763-7744	CM387	71744	LAMP, INCANDESCENT	EA	5	
6	33	PAOZZ		SMB679485-2	80063	KNOB	EA	1	





Figure 7. Receiver-Transmitter, Radio RT-903/TPX-50.

ELOOB007

SECTION II		TM11-5895-687-20P						
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	
ILLUSTRATION								
(A)	(B)		NATIONAL		DESCRIPTION		QTY	
FIG	ITEM	SMR	STOCK	PART			INC	
NO	NO	CODE	NUMBER	NUMBER	FSCM	USABLE ON CODE	U/M	
							UNIT	
GROUP: 0103 RECEIVER-TRANSMITTER, RADIO								
RT-903/TPX-50								
7	12	PAODL	5895-00-411-4023	SMD679397	80063	POWER SUPPLY MODULE	EA 1	
7	16	PAODD	5895-00-411-4025	SMD679398	80063	SWITCH ASSEMBLY	EA 1	
7	20	PAOZZ	6240-00-763-7744	CM387	71744	LAMP, INCANDESCENT	EA 4	



NOTE:  
 REFERENCE DESIGNATIONS ARE ABBREVIATED,  
 PREFIX REFERENCE DESIGNATION WITH 2.

Figure 8. Control, Interrogator Set C-7651/TPX-50

SECTION II		TM11-5895-687-20P					
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION							QTY
(A)	(B)	NATIONAL			DESCRIPTION		INC
FIG	ITEM	STOCK	PART	FSCM		USABLE ON CODE	IN
NO	NO	NUMBER	NUMBER			U/M	UNIT
					GROUP: 02 CONTROL, INTERROGATOR SET		
					C-7561/TPX-50		
8		PDODD 5895-00-130-5816	SMB679366	80063	CONTROL, INTERROGATOR SET C-7651/TPX-50	EA	1
8	1A	PAOZZ 6240-00-143-6558	MS3338-6839	96906	LAMP, INCANDESCENT	EA	1
8	2A	PAOZZ 6240-00-143-6558	MS3338-6839	96906	LAMP, INCANDESCENT	EA	1
8	22	PAODL 5895-00-410-9960	SMD679361	80063	CIRCUIT CARD ASSEMBLY (LAMP DRIVER)	EA	1
8	40	PAOZZ	SMB679270	80063	KNOB ASSEMBLY, SELECTOR	EA	2
8	47	PAOZZ 6240-00-763-7744	CM387	71744	LAMP, INCANDESCENT	EA	10

## NATIONAL STOCK NUMBER AND PART NUMBER INDEX

STOCK NUMBER	FIGURE NO	ITEM NO	STOCK NUMBER	FIGURE NO	ITEM NO
5895-00-129-6066	4	3	5895-00-410-9954	5	9
5895-00-130-5814	4	6	5895-00-410-9958	5	19
5895-00-130-5815	4	5	5895-00-410-9959	5	13
5895-00-130-5816	8		5895-00-410-9960	8	22
5895-00-130-5817	4		5895-00-410-9967	6	11
5995-00-132-3321	2		5895-00-411-4023	7	12
5895-00-133-1193	3	1	5895-00-411-4025	7	16
5895-00-135-9106	4	7	5895-00-419-9649	6	15
5995-00-136-4980	1		5895-00-437-2386	6	13
6240-00-143-6558	8	1A	5895-00-437-2394	6	12
6240-00-143-6558	8	2A	5895-00-437-2397	6	14
5895-00-410-2419	3	6	6240-00-763-7744	4	11
5895-00-410-2420	3	5	6240-00-763-7744	5	34
5895-00-410-2421	3	4	6240-00-763-7744	6	22
5895-00-410-2422	3	7	6240-00-763-7744	7	20
5895-00-410-2423	3	2	6240-00-763-7744	8	47
5895-00-410-2425	3	3	5970-00-828-3451	1	2
5895-00-410-9950	5	17	5970-00-904-2491	1	9
5895-00-410-9953	5	18			

PART NUMBER	FSCM	FIG. NO	ITEM NO	PART NUMBER	FSCM	FIG. NO	ITEM NO
CM387	71744	4	11	SMD679361	80063	8	22
CM387	71744	5	34	SMD679367	80063	6	12
CM387	71744	6	22	SMD679369	80063	5	17
CM387	71744	7	20	SMD679393	80063	4	5
CM387	71744	8	47	SMD679397	80063	7	12
MS3338-6839	96906	8	1A	SMD679398	80063	7	16
MS3338-6839	96906	8	2A	SMD680107	80063	6	15
SMB679270	80063	8	40	SMD680108	80063	5	13
SMB679374	80063	3	1	SMD680109	80063	5	9
SMB679374	80063	3	3	SMD680110	80063	5	19
SMB679388	80063	1		SMD680111	80063	5	18
SMB679485-2	80063	6	33	SMD680112	80063	6	13
SMC679286	80063	6	11	SME679362	80063	4	3
SMC679298	80063	2		SME679363	80063	4	
SMC680134	80063	3	2	SME679364	80063	4	6
SMC680135	80063	3	7	SME679365	80063	4	7
SMC680136	80063	3	4	SME679366	80063	8	
SMC680137	80063	3	5	202A163-3	06090	1	2
SMC680138	80063	3	6	222A174-3	06090	1	9
SMD679299	80063	6	14				



RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL MANUALS



**SOMETHING WRONG WITH THIS MANUAL?**

THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM, TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

FROM: (YOUR UNIT'S COMPLETE ADDRESS)  
 Commander  
 Stateside Army Depot  
 ATTN: AMSTA-US  
 Stateside, N.J. 07703  
 DATE 10 July 1975

PUBLICATION NUMBER: TM 11-5840-340-12      DATE: 23 Jan 74      TITLE: Radar Set AN/P-3-76

BE EXACT... PIN-POINT WHERE IT IS				IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:
PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.	
2-25	2-28			<p>Recommend that the installation antenna alignment procedure be changed through to specify a 2° IFF antenna lag rather than 1°.</p> <p>REASON: Experience has shown that with only a 1° lag, the antenna servo system is too sensitive to wind gusting in excess of 20 knots, and has a tendency to rapidly accelerate and decelerate as it hunts, causing strain to the drive train. Hunting is minimized by adjusting the lag to 2° without degradation of operation.</p>
3-10	3-3		3-1	<p>Item 5, Function column. Change "2 db" to "3db."</p> <p>REASON: The adjustment procedure for the TRANS POWER FAULT indicator calls for a 3 db (500 watts) adjustment to light the TRANS POWER FAULT indicator.</p>
5-6	5-8			<p>Add new step f.1 to read, "Replace cover plate removed in step e.1, above."</p> <p>REASON: To replace the cover plate.</p>
		F03		<p>Zone C 3. On J1-2, change "+24 VDC to "+5 VDC."</p> <p>REASON: This is the output line of the 5 VDC power supply. + 24 VDC is the input voltage.</p>

TEAR ALONG DOTTED LINE

TYPED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER: SSG I. M. DeSpirito 999-1776      SIGN HERE: *SSG I. M. DeSpirito*



Allow  $\frac{3}{4}$  Inches  
Margin to trim

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL MANUALS



# SOMETHING WRONG WITH THIS MANUAL?

THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM, TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

FROM: (YOUR UNIT'S COMPLETE ADDRESS)

DATE

PUBLICATION NUMBER

DATE

TITLE

BE EXACT... PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.
----------	------------	------------	-----------

TEAR ALONG DOTTED LINE

TYPED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 2028-2 (TEST)  
1 AUG 74

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR MANUAL "FIND," MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR  
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

\_\_\_\_\_  
\_\_\_\_\_

**OFFICIAL BUSINESS**  
PENALTY FOR PRIVATE USE, \$300

POSTAGE AND FEES PAID  
DEPARTMENT OF THE ARMY  
DOD-314



Commander  
US Army Electronics Command  
ATTN: DRSEL-MA-Q  
Fort Monmouth, New Jersey 07703

TEAR ALONG DOTTED LINE

FOLD BACK

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL MANUALS



# SOMETHING WRONG WITH THIS MANUAL?

THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM, TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

FROM: (YOUR UNIT'S COMPLETE ADDRESS)

DATE

PUBLICATION NUMBER

DATE

TITLE

BE EXACT... PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.
----------	------------	------------	-----------

TEAR ALONG DOTTED LINE

TYPED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 2028-2 (TEST)  
1 AUG 74

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR MANUAL "FIND" MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR  
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS  
PENALTY FOR PRIVATE USE, \$300

POSTAGE AND FEES PAID  
DEPARTMENT OF THE ARMY  
DOD-314



Commander  
US Army Electronics Command  
ATTN: DRSEL-MA-Q  
Fort Monmouth, New Jersey 07703

TEAR ALONG DOTTED LINE

FOLD BACK

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL MANUALS



# SOMETHING WRONG WITH THIS MANUAL?

THEN...JOT DOWN THE  
DOPE ABOUT IT ON THIS  
FORM, TEAR IT OUT, FOLD  
IT AND DROP IT IN THE  
MAIL!

FROM: (YOUR UNIT'S COMPLETE ADDRESS)

DATE

PUBLICATION NUMBER

DATE

TITLE

BE EXACT...PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG  
AND WHAT SHOULD BE DONE ABOUT IT:

PAGE NO.	PARA- GRAPH	FIGURE NO.	TABLE NO.
-------------	----------------	---------------	--------------

TEAR ALONG DOTTED LINE

TYPED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 2028-2 (TEST)  
1 AUG 74

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR MANUAL "FIND" MAKE  
A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR  
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS  
PENALTY FOR PRIVATE USE, \$300

POSTAGE AND FEES PAID  
DEPARTMENT OF THE ARMY  
DOD-314



Commander  
US Army Electronics Command  
ATTN: DRSEL-MA-Q  
Fort Monmouth, New Jersey 07703

TEAR ALONG DOTTED LINE

FOLD BACK



By Order of the Secretary of the Army

**BERNARD W. ROGERS**  
*General, United States Army*  
*Chief of Staff*

Official:

**PAUL T. SMITH**  
*Major General, United States Army*  
*The Adjutant General*

**DISTRIBUTION:**

To be distributed in accordance with DA Form 12-32, organizational Maintenance Requirements for Chaparral and Hawk Missile Systems.





**PIN : 014737 - 000**