

**TECHNICAL MANUAL  
ORGANIZATIONAL,  
DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS LIST  
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)  
FOR  
RADIO TERMINAL SET AN/MRC-127  
(NSN 5820-00-935-6481)**

---

**HEADQUARTERS, DEPARTMENT OF THE ARMY**

**JULY 1976**

TECHNICAL MANUAL  
No. 11-5895-694-24P

{

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, DC, 22 July 1976

**Organizational, Direct Support and General Support Maintenance  
Repair Parts and Special Tools Lists  
(Including Depot Maintenance Repair Parts and Special Tools)**

For

**RADIO TERMINAL SET AN/MRC-127  
(NSN 5820-00-935-6481)  
*Current as of 29 ,March 1976***

**REPORTING OF ERRORS**

You can improve this manual by recommending improvements using DA Form 2028-2 (Test) located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 (Test) in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Electronics Command, ATTN: DRSEL-MA-Q, Fort Monmouth, New Jersey 07703.

In either case a reply will be furnished direct to you.

SECTION	GROUP	Page	Illus	Figure
		1		
I.		5		
II.		5		
	00	5		1
	01	7		2
	02	Converter Telephone Signal CV-1548/G (See TM 11-5805-367-25p/5 for parts)		
	03	Key Generator, Electronic TSEC/KG-27 (See TM 11-5810-232-12P and TM 11-5810-232-34P for parts)		
		11		3
		13		4
	04	Multiplexer, TD-660/G or TD-660 A/G (See TM 11-5805-382-12 and TM 11-5805-382-35P for parts)		
	05	Radio Set AN/GRC-103(V) (See TM 11-5820-540-12, TM 11-5820-540-540-35P, TM 11-5820-54035P-2, and TM11-5820-540-35P-3 for parts)		
SECTION	III.	Special tools List ( Not applicable)		
	IV.	National stock number and part number index ..... 14		

\*This manual supersedes so much of TM 11 -5895-694-1 5, 13 August 1 969, including all Changes, as pertains to repair parts and special tools list.

## SECTION I INTRODUCTION

---

### 1. Scope

This manual lists repair parts and special tools required for performance of organizational, direct support, and general support maintenance of the AN/MRC-127.

### 2. General

This Repair Parts and Special Tools manual is divided into the following sections:

a. *Section II. Repair Parts List.* A list of repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending numerical sequence, with the parts in each group listed in figure and item number sequence.

b. *Section III. Special Tools List.* Not applicable.

c. *Section IV. National Stock Number and Part Number Index.* A list, in ascending National item identification number (NIIN, last 9 digits) sequence, of all National stock numbers appearing in the listings, followed by a list, in alphabetic sequence, of all part numbers appearing in the listings. National stock number and part numbers are cross-referenced to each illustration figure and item number appearance.

### 3. Explanation of Columns

The following provides an explanation of columns found in the tabular listings:

a. *Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration in which the item is shown.

(2) *Item number.* The number used to identify each item called out in the illustration.

b. *Source, Maintenance, and Recoverability Codes (SMR).*

(1) *Source code.* Source codes are assigned to support items to indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
PA -	Item procured and stocked for anticipated or known usage.
PD -	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
XD -	A support item that is not stocked. When required, item will be procured through normal supply channels.

### NOTE

**Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA, XD, and aircraft support items as restricted by AR 70042.**

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

<i>Code</i>	<i>Application/Explanation</i>
0 -	Support item is removed, replaced, used at the organizational level.
F -	Support item is removed, replaced, used at the direct support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

<i>Code</i>	<i>Application/Explanation</i>
F -	The lowest maintenance level capable of complete repair of the support item is the direct support level.
D -	The lowest maintenance level capable of complete repair of the support item is the depot level.
Z -	Nonreparable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

<i>Recoverability codes</i>	<i>Definition</i>
Z -	Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
F -	Reparable item. When uneconomically repairable, condemn and dispose at the direct support level.
D -	Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.

c. *National Stock Number.* Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

d. *Part Number.* Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements, to identify an item or range of items.

#### **NOTE**

Lichen a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

e. *Federal Supply Code for Manufacturer (FSCM).* The FSCM is a 5-digit numeric code listed in SB 70842 which is used to identify the manufacturer, distributor, or Government agency, etc.

f. *Description.* Indicates the Federal item name and, if required, a minimum description to identify the item.

g. *Unit of-Measure (U/M)* Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc.). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. *Quantity Incorporated in unit.* Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly.

#### **4. Special Information**

The following publications pertain to the AN/MRC-127 and its components:

TM 11-5805-367-12, Multiplexers TD-202/U, TD-203/U, TD-204/U, TD-352/U, and TD 353/U; Restorer, Pulse Form TD-206/U, and Converter, Telephone Signal CV-1,548/G and CV-1548A/G

TM 11-5805-367-25P/5, Converter, Telephone Signal CV-1548/G, CV-1548/G, and 18A4 Panel Assembly

TM 11-5805-367-34-5, Converters, Telephone Signal CV-1548/G and CV-1548A/G

TM 11-5805-382-12, Multiplexers TD-660/G and TD-60A/G

TM 11-5805-382-35P, Multiplexer TD-60A/G and Dual Inline Packaging Configuration.

TM 11-5810-232-12P, Communications Security Equipment TSEC/KG-27

TM 11-5810-232-34P, Communications Security Equipment TSEC/KG-27

TM 11-5820-540-12, Radio Set AN/GRC-103(V) 1, 2, and 3 and Extension Kit, Mast MK-1009/GRC-103(V)

TM 11-5820-540-35P, Radio Set AN/GRC-103(V)1; Mast Extension Kit, and Direct Support Cable Kit

TM 11-5820-540-35P-2, Radio Set AN/GRC-103(V)2

TM 11-5820-540-35P-3, Radio Set AN/GRC-103(V)3

#### **5. How to Locate Repair Parts**

a. When National stock number or part number is unknown.

(1) *First.* Using the table of contents, determine the functional group within which the repair part belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.

(2) *Second.* Find the illustration covering the functional group to which the repair part belongs.

(3) *Third.* Identify the repair part on the illustration and note the illustration figure and item number of the repair part.

(4) *Fourth.* Using the Repair Parts Listing, find the figure and item number noted on the illustration.

b. When National stock number or part number is known.

(1) *First.* Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in ascending NIIN sequence followed by a list of part numbers in ascending alphabetic sequence, cross-referenced to the illustration figure number and item number.

(2) *Second.* After finding the figure and item number, locate the figure and item number in the repair parts list.

#### **6. Abbreviations Not applicable.**

Not applicable




Figure 1. Radio Terminal Set AN/MRC-127.

## SECTION II

TM 11-5895-694-24P

(1) ILLUSTRATION		(2)	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION	(7)	(8) QTY INC IN UNIT
(a) FIG NO.	(b) ITEM NO.	SMR CODE				<i>USABLE ON CODE</i>	U/M	
1	1	PDOODD	5820-00-868-8137	ANGRROC03	80059	GROUP 00 RADIO TERMINAL SET AN/MRC-127		
1	2	XDOFF	5895-00-134-0007	V415MPC	80058	RADIO SET	EA	2
1	3	PDOODD	5820-00-928-3382	TD660AG	80058	TRAILER FACILITY	EA	1
1	3	PDOODD	5820-00-930-8079	TD66OG	80058	MULTIPLEXER	EA	1
1	4	PDOODD	5805-00-069-8795	CV1548G	80058	OR	EA	1
1	5	PDOODD	5810-00-054-9110	TSECKG27	80058	MULTIPLEXER	EA	1
						CONVERTER TELEPHONE SIGNAL	EA	1
						KEY GENERATOR,ELECTRONIC	EA	1




Figure 2. Trailer Facility V-415/MRC-

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8) QTY INC IN UNIT
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		U/M	
						GROUP 01 TRAILER FACILITY V-415/MPC		
2	1	PAOZZ	5965-00-086-6874	10711	82872	HOLDER, HANDSET	EA	2
2	2	PAOZZ	6210-00-089-8815	22082	08621	Fixture, Lighting	EA	2
2	3	PAOZZ	5970-00-869-6263	SCC76202-1	80063	CAP, ELECTRICAL	EA	104
2	4	PAFZZ	5935-00-225-2144	G1519A128BI-25P	06324	ADAPTER, CONNECTOR	EA	3
2	5	PAFZZ	5935-00-064-5560	UG1375U	81349	CONNECTOR, ADAPTER	EA	2
2	6	PAFZZ	5935-00-902-8856	MS3116P8-3S	96936	CONNECTOR, PLUG, ELECTRICAL	EA	3
2	7	PAFZZ	5935-00-466-1347	MS35170-260E	96906	CONNECTOR, PLUG, ELECTRICAL	EA	16
2	8	PAFZZ	5935-00-552-4490	UP1204	80058	CONNECTOR, PLUG,	EA	2
2	9	PAFZZ	5935-00-931-7490	UP221M	81349	CONNECTOR, PLUG, ELECTRICAL	EA	1
2	10	PAFZZ	5935-00-822-1956	PT06W12-3S	77820	CONNECTOR, PLUG, ELECTRICAL	EA	1
2	11	PAFZZ	5935-00-238-0232	PT06WE2-3P	77820	CONNECTOR, PLUG, ELECTRICAL	EA	1
2	12	PAFZZ	5935-00-484-5033	BTG6B12-3S	09922	CONNECTOR, PLUG, ELECTRICAL	EA	6
2	13	PAFZZ	5935-00-957-0807	PT06W14-19S	77820	CONNECTOR, PLUG, ELECTRICAL	EA	18
2	14	PAFZZ	5935-00-848-6680	PT07E12-3S	12143	CONNECTOR, RECEPTACLE, ELECTRICAL	EA	1
2	15	PAFZZ	5935-00-994-0388	PT07E12-3P	77820	CONNECTOR, PLUG, ELECTRICAL	EA	1
2	16	PAOZZ	5120-00-946-5148	SCB539592	80063	GRIP, CABLE, WOVEN	EA	2
2	17	PAOZZ	5120-00-946-5114	SCB539593	80063	GRIP, CABLE, WOVEN	EA	1
2	18	PAOZZ	6230-00-729-9614	SCC539491	80063	LANTERN, ELECTRIC	EA	1
2	19	PAOZZ	6150-00-495-1214	SCB539492	80063	LEAD, ELECTRICAL	EA	1
2	20	PAOZZ	6230-00-115-2687	SCC539496	80063	LIGHT, EXTENSION	EA	1
2	21	PAOZZ	5975-00-705-5841	N3	06229	CLIP, CRADLE	EA	12
2	22	PAOZZ	5935-00-258-4568	CW282AU	81349	COVER, CONNECTOR, ELECTRICAL	EA	16
2	23	PAOZZ	4210-00-288-6849	RBI	33525	BRACKET, FIRE, EXTINGUISHER	EA	1
2	24	PAFZZ	6145-00-752-2473	WT26U	80058	CABLE, POWER, ELECTRICAL	EA	65
2	25	PAFZZ	5935-00-134-5266	U2378G	80058	CONNECTOR, PLUG, ELECTRICAL	EA	3
2	26	PAOZZ	8130-00-656-1090	RC435U	80058	REEL, CABLE	EA	1
2	27	PAFZZ	5910-00-142-4515	S32943	24615	CAPACITOR, FIXED, PAPER	EA	1
2	28	PAOZZ	6105-00-234-3504	SCD539825	80063	MOTOR, ALTERNATING, CURRENT	EA	1
2	29	PAOZZ	5975-00-838-0443	2665	90190	ROD, GROUND	EA	1
2	30	PAFZZ	5930-00-659-2672	3SR3S2	82121	SWITCH, ROTARY	EA	1
2	31	PAFZZ	6625-00-542-1897	MR36W05ACAAR	81349	AMMETER	EA	1
2	32	PAFZZ	5935-00-283-4003	5262	74545	CONNECTOR, RECEPTABLE, ELECTRICAL	EA	2
2	33	PAFZZ	5935-00-064-5732	U238BG	80058	CONNECTOR, RECEPTABLE, ELECTRICAL	EA	1
2	34	PAFZZ	5930-00-772-9276	MS25036-232	96906	SWITCH, TOGGLE	EA	1
2	35	PAFZZ	6625-00-341-4071	MR36W15OACVVR	81349	VOLTMETER	EA	1
2	36	PAFZZ	5930-00-087-4712	8906K1384	15605	SWITCH, TOGGLE	EA	24
2	37	PAFZZ	5935-00-045-9832	U187AG	80058	CONNECTOR, RECEPTABLE, ELECTRICAL	EA	2
2	38	PAFZZ	5940-00-283-5386	U106U	80058	POST, BINDING	EA	104
2	39	PAOZZ	5975-00-947-3068	M37803FS	21873	COVER, CONNECTOR, RECEPTACLE	EA	2

## SECTION II

TM 11-5895-694-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8) QTY INC IN U/M UNIT
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM			
2 2 2	40 41 42	PAFZZ PAFZZ PAOZZ	5925-00-850-1031 5925-00-492-1887 6210-00-809-4274	AM33MG6-15 AM12MG6-5 LM74	74193 74193 96906	CIRCUIT BREAKER CIRCUIT BREAKER LIGHT,INDICATOR	EA EA EA	1 3 2

8/(9 Blank)





Figure 3. Installation Kit, TSEC/,K-27.

(1) ILLUSTRATION		(2)	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION	(7) QTY INC IN U/M	(8) QTY INC IN UNIT
(a) FIG NO.	(b) ITEM NO.	SMR CODE				<i>USABLE ON CODE</i>		
3	1	PAODD	5995-00-181-9545	5CD693658GR9	80063	GROUP 0301 INSTALLATION KIT,TSEC/KG-27		
3	2	PAODD	5995-00-181-9545	SCD693658GR10	80063	CABLE ASSEMBLY, RADIO FREQUENCY	EA	1
3	3	PAODD	5995-00-001-1467	SCD595511GR87	80063	CABLE ASSEMBLY, RADIO FREQUENCY	EA	1
3	4	PAODD	5995-00-177-4555	SCD681112GR2	80063	CABLE ASSEMBLY, RADIO FREQUENCY	EA	1
3	5	PAODD	5995-00-197-6399	SCD595511GR88	80063	CABLE ASSEMBLY, SHIELDED POWER	EA	1
3	6	PAODD	5995-00-192-9607	SCD595511GR86	80063	CABLE ASSEMBLY, RADIO FREQUENCY	EA	1
						CABLE ASSEMBLY, RADIO FREQUENCY	EA	1



ELOND004

Figure 4. Loop-Back Test Kit, TSEC/KG-27.

## SECTION II

TM 11-5895-694-24P

(1) ILLUSTRATION		(2)	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION	(7)	(8) QTY INC IN UNIT
(a) FIG NO.	(b) ITEM NO.	SMR CODE				<i>USABLE ON CODE</i>	U/M	
4	1	PAODD	5995-00-177-4675	CG3473U	80058	GROUP 0302 LOOP-BACK TEST KIT,TSEC/KG-27	EA	4
4	2	PAODD	5995-00-177-4667	CG3419U	80058	CABLE ASSEMBLY, RADIO FREQUENCY	EA	5
4	3	PAODD	5995-00-177-4665	CX10764G	80058	CABLE ASSEMBLY, VIDEO	EA	1
4	4	PAODD	5995-00-935-5294	CX17727G	80058	CABLE,SHIELDED POWER	EA	1
						CABLE ASSEMBLY, POWER		

### NATIONAL STOCK NUMBER AND PART NUMBER INDEX

FIGURE ITEM

FIGURE ITEM

**NOTE: LATEST NATIONAL STOCK NUMBER ASSIGNMENTS ARE INCLUDED AT THE END OF INDEX.**

STOCK NUMBER	NO.	NO.	STOCK NUMBER	NO.	NO.
5935-00-045-9832	2	37	6150-00-495-1214	2	19
9935-00-364-5560	2	5	6625-00-542-1897	2	31
5035-00-064-5732	2	33	5935-03-552-4490	2	8
5805-00-369-8795	1	4	8130-00-656-1090	2	26
5965-00-086-6874	2	1	5930-00-659-2672	2	30
5930-00-387-4112	2	36	5975-00-705-5841	2	21
6210-00-089-8815	2	2	6230-00-729-9614	2	18
6230-00-115-2687	2	20	6145-00-752-2473	2	24
5895-00-134-0007	1	2	5930-00-772-9276	2	44
5935-00-134-5266	2	25	6210-00-809-4274	2	42
5995-00-177-4155	3	4	5935-00-822-1956	2	10
5995-00-177-4665	4	3	5970-30-869-6263	2	3
9995-00-177-4667	4	2	5935-00-902-8856	2	6
5995-00-177-4675	4	1	5820-00-928-3382	1	3
5995-00-181-9545	3	1	5820-00-930-8079	1	3
5995-30-181-9545	3	2	5935-00-931-7490	2	9
6105-00-234-3504	2	28	5995-00-935-5294	4	4
5935-00-238-0232	2	11	5120-00-946-5114	2	17
5935-30-283-4003	2	32	5120-00-946-5148	2	16
5940-00-283-9385	2	38	5975-00-947-3068	2	39
4210-00-288-6849	2	23	5935-00-957-0807	2	13
5935-00-484-5033	2	12			

PART NUMBER	FIG. NO.	ITEM NO.	PART NUMBER	FIG. NO.	ITEM NO.	
FSCM	FIG. NO.	ITEM NO.	FSCM	FIG. NO.	ITEM NO.	
AM12MG6-5	74193	2	41	SCC539491	80063	2
AM33MG6-15	74193	2	40	SCC539496	80063	2
ANCRC1O3	80058	1	1	SCC76202-1	80063	2
BTG6812-3S	09922	2	12	SCD1539825	80063	2
CG3419U	80058	4	2	SCD595511GR86	80063	3
CG3473U	80058	4	1	SCD595511GR87	80063	3
CV1548G	80058	1	4	SCC595511GR88	80063	3
CW282AU	81349	2	22	SCD681112GR2	80063	3
CX107645	80058	4	3	SCD693658GR10	80063	3
CX17727G	80058	4	4	SCDC693658GR9	80063	3
C1519Al28B1-25P	06324	2	4	S32943	24165	2
LM74	96906	2	42	TD660AG	80058	1
MR36W050ACAAR	81349	2	31	TD660G	80058	1
MR36W150ACVVR	81349	2	35	TSECKG27	80058	1
MS25036-232	96006	2	34	UG1375U	81349	2
MS3116F8-3S	96906	2	6	UP120M	80058	2
MS35170-260C	96936	2	7	UP221M	81349	2
M3780FS	21873	2	39	U106U	80058	2
N3	06229	2	21	U187AG	80058	2
P706WI2-3P	77820	2	11	U237BG	80058	2
PT06WI2-3S	77820	2	to	U238BG	80058	2
PT06WI4-19S	77820	2	13	V415MP0	80058	1
PT07FT2-3P	77820	2	15	MT26U	80058	2
PT07F12-3S	12143	2	14	10711	82872	2
RB1	33525	2	23	22082	08621	2
RC435U	80058	2	26	2665	90190	2
SC8539492	80063	2	19	3SR3S2	82121	2
SC853O592	80063	2	16	5262	74545	2
SC539593	80063	2	17	8906K1384	15605	2

### LATEST NATIONAL STOCK NUMBER ASSIGNMENTS

FIGURE ITEM

STOCK NUMBER NO. NO.

5995-00-001-1467	3	3
5910-00-142-4515	2	27
5995-00-192-9607	3	6
5994-00-197-6399	3	5
5935-00-225-2144	2	4
5935-00-258-4568	2	22
6625-00-341-4071	2	35
5935-00-466-1347	2	7
5925-00-492-1887	2	41
5975-00-838-0443	2	29
5935-00-848-6680	2	14
5925-00-850-1031	2	40
5820-00-868-8137	1	1
5935-00-994-0388	2	15
5810-00-054-9110	1	5

By Order of the Secretary of the Army:

FRED C.WEYAND  
*General, United Staff Army*  
*Chief of Staff*

Official:

PAUL T. SMITH  
*Major General, United States Army*  
*The Adjutant General*

## DISTRIBUTION

Active Army:

USASA (2)	USAICS (3)
COE (1)	MAAG (1)
TSG (1)	USARMIS (1)
USAARENBD (1)	Installations (2) except
DARCOM (1)	Fort Carson (1)
TRADOC (2)	Fort Gordon (10)
OS Maj Comd (4)	Fort Gillem (10)
LOGCOMDS (3)	Fort Huachuca (10)
MICOM (2)	Ft Richardson (ECOM Ofc) i2)
TECOM (2)	LBAD (14)
USACC (4)	SAAD (30)
MDW (1)	SHAD (3)
Armies (2)	Sig FLDMS (1)
Corps (2)	USAERDAA (1)
HISA (Ft Monmouth) (33)	USAERDAW (1)
Svc Colleges (1)	Units org under fol TOE (1)
USAESS (5)	1 ^5
USAADS (2)	118
USAFAS (2)	11-13
USAARMS (2)	29-134
USAIS (2)	29-136
USAES (2)	

NG: None

USAR: None

For explanation of abbreviations used see, AR 310-50

## **RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS**



**SOMETHING WRONG WITH THIS PUBLICATION?**

**FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)**

**THEN. . JOT DOWN THE  
DOPE ABOUT IT ON THIS  
FORM, CAREFULLY TEAR IT  
OUT, FOLD IT AND DROP IT  
IN THE MAIL!**

DATE RENT

**PUBLICATION NUMBER**

**PUBLICATION DATE**

**PUBLICATION TITLE**

**BE EXACT... PIN-POINT WHERE IT IS**

**IN THIS SPACE TELL WHAT IS WRONG  
AND WHAT SHOULD BE DONE ABOUT IT:**

PAGE NO.	PARA- GRAPH NO.	FIGURE NO.	TABLE NO.
-------------	-----------------------	---------------	--------------

TITAN ALONG PERIODIC LINE

**PRINTER NAME, GRADE OR TITLE, AND THE PHONE NUMBER**

**SIGN HERE**

**DA FORM 1 JUL 79 2028-2**

**PREVIOUS EDITIONS  
ARE OBSOLETE.**

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR  
RECOMMENDATION MAKE A CARBON COPY OF THIS  
AND GIVE IT TO YOUR HEADQUARTERS.

**PIN: 018219-000**