

TECHNICAL MANUAL

**ORGANZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MNTENANCE REPAIR PARTS AND SPECIAL TOOLS)**

FOR

**TEST SET, ELECTRONIC SYSTEM AN/ASM-338
(NSN 6625-00-878-7990)**

HEADQUARTERS, DEPARTMENT OF THE ARMY

JULY 1976

1-TS 4828-----

**ORGANIZATIONAL, DIRECT SUPPORT, AND
GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)**

FOR

TEST SET, ELECTRONIC SYSTEM AN/ASM-338

(NSN 6625-0 877990)

Current as of 1 January 1976

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 (Test) located in the back of the manual. Simply tear out the self addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 (Test) in the back of your manual use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Electronics Command, ATTN: DRSELMA-Q, Fort Monmouth, New Jersey 07703. In either case a reply will be furnished direct to you.

		Page	Illustration Figure
Section	I. Introduction	1	
	II. Repair parts	5	
Group	00 Test Set, Electronic System AN/ASM338	5	1
	01 Test Set, Electronic System TS-2676/ASM-338	7	2-4
	0101 Circuit card assembly	13	5
	02 Case, test set.	15	6
	0201 Cable Assembly, Special Purpose CX1081/U.....	17	7
	0202 Cable Assembly, Special Purpose CX10852/U (No parts authorized)		
	0203 Cable Assembly, Special Purpose CX10853/U.....	19	8
	0204 Cable Assembly, Special Purpose CX10854/U.....	21	9
	0205 Board Assembly, Extender MX8096/ASM338.....	23	10
Section	III. Special tools lists (Not applicable)		
	IV. National stock number and parts number index.....	24	

*This manual supersedes so much of TM-6625-1704-15, 29 March 1968, as pertains to repair parts and special tools list .

**SECTION I
INTRODUCTION**

1. Scope

This manual list repair parts and special tools required for performance of organizational, direct support, and general support maintenance of the AN/ASM338.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II-Repair Parts List. A list of repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending numerical sequence, with the parts in each group listed in figure and item number sequence.

b. Section III Special Tools List. Not applicable.

c. Section IV National Stock Number and Part Number Index. A list, in ascending National item identification number (NIIN, last 9 digits) sequence, of all National stock numbers appearing in the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the Listing. National stock number and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

The following provides an explanation of columns found in the tabular listings:

a. *Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration in which the item is shown.

(2) *Item number.* The number used to identify each item called out in the illustration.

b. *Source, Maintenance, and Recoverability Codes (SMR).*

(1) *Source code.* Source codes are assigned to

support items to indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
PA	Item procured and stocked for anticipated or known usage.
XA	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XD	A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA, XD, and aircraft support items as restricted by AR 70042.

(2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

<i>Code</i>	<i>Application/Explanation</i>
O	Support item is removed, replaced, used at the organizational level.
H	Support item is removed, replaced, used at the general support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete

repair (i.e., all authorized maintenance function). This position will contain one of the following maintenance Codes:

<i>Code</i>	<i>Application/Explanation</i>
H -----	The lowest maintenance level capable of complete repair of the support item is the general support level.
Z -----	Nonreparable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

<i>Recoverability codes</i>	<i>Definition</i>
Z -----	Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
H -----	Reparable item. When uneconomically reparable, condemn and dispose at the general support level.

c. *National Stock Number.* Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

d. *Part Number.* Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements, to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

e. *Federal Supply Code for Manufacturer (FSCM).* The FSCM is a 5digit numeric code listed in SB 70842 which is used to identify the manufacturer, distributor, or Government agency, etc.

f *Description.* Indicates the Federal item name and, if required, a minimum description to identify the item.

g. *Unit of Measure (U/M).* Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g, ea, in pr, etc).

When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. *Quantity Incorporated in Unit.* Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly.

4. Special Information

The following publication pertains to the AN/ ASM338 and its components:

TM 116625170415, Test Set, Electronic System AN/ASM338.

5. How to Locate Repair Parts

a. When National stock number or par number is unknown.

(1) *First.* Using the table of contents, determine the functional group within which the repair part belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.

(2) *Second.* Find the illustration covering the functional group to which the repair part belongs.

(3) *Third.* Identify the repair part on the illustration and note the illustration figure and item number of the repair part.

(4) *Fourth.* Using the Repair Part Listing, find the figure and item number noted on the illustration.

b. When National stock number or part number is known.

(1) *First.* Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or par number. This index is in ascending NIIN sequence followed by a list of par numbers in ascending alphanumeric sequence, cross-referenced to the illustration figure number and item number.

(2) *Second.* After finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations

Not applicable.

(Next printed page is 4.)

FRED C. WEYAND
General, United States Army
Chief of Staff


Official:

PAUL T. SMITH
Major General, United States Army
The Adjutant General

Distribution:

To be distributed in accordance with DA Form 1236A, Organizational Maintenance requirements for AN/ASM338.

TM 11-6625-1704-24P	3
TM 11-6625170424P	5
TM 11-6625-1704-24P	7
TM 11-6625-1704-24P	9
TM 11-6625-1704-24P	11
TM 11-6625-1704-24P	13
TM 11-6625-1704-24P	15
TM 11-6625-1701-24P	17
TM 11-6625-1704-24P	19
TM 11-6625-1704-24P	21
	23
4	TM 11-6625-1704-24P
6	TM 11-6625-1704-24P
8	TM 11-6625-1704-24P
10	TM 11-6625-1704-24P
12	TM 11-6625-1704-24P
14	TM 11-6625-1704-24P
16	TM 11-6625-1704-24P
18	TM 11-6625-1704-24P
20	TM 11-6625-1704-24P
22	TM 11-6625-1704-24P
24	TM 11 6625 1704-24P



ELICE001

Figure 1. Test Set, Electronic System AN/ASM-338.

SECTION II

TM 11-6625-1704-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7) DESCRIPTION	(8)	
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE		U/M	QTY INC IN UNIT
1	1	XDHHH		TS2676ASM338	80058		GROUP 00 TEST SET,ELECTRCNIC SYSTEM ANAS4338		EA
1	2	PAHZZ	6625-00-880-1978	CY6470ASM338	80058		PANEL ASSEMBLY, TEST SET, ELECTRICAL SYSTEM		EA
					5		CASE, TEST SET		1




Figure 2. Test Set, Electronic System TS2676/ASM338.

SECTION II

TM 11-6625-1704-24P

ILLUSTRATION		(1)	(2) (3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION USABLE ON CODE	U/M	QTY INC IN UNIT
						GROUP 01 TEST SET, ELECTRONIC SYSTEM TS-2676/ASM-338		
2	1	PAHZZ	5826-00-879-7399	570-391-029-1	97495	CIRCUIT ASSEMBLY	EA	1
2	2	PAHHH	5826-00-879-7396	570-091-007-1	97499	BOARD ASSEMBLY	EA	1
2	3			570-091-018-3	97499	WIRING ASSEMBLY	EA	1
					7			





Figure 3. Test Set, Electronic System TS2676/ASM338, panel assembly.

SECTION II

TM 11-6625-1704-24P

ILLUSTRATION		(1)	(2) (3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	U/M	QTY INC IN UNIT
FIG NO.	ITEM NO.							
3	1	PAHZZ	5935-00-984-8100	MS3110E20-41S	96906	CONNECTOR	EA	1
3	2	PAHZZ	5940-00-615-2282	111-102	74970	POST	EA	4
3	3	PAHZZ	5935-00-849-7188	MS3110E16-26S	96906	CONNECTOR	EA	1
3	4	PAHZZ	5935-00-844-2737	MS3110E12-10S	96906	CONNECTOR	EA	1
3	5	PAHZZ	5935-00-004-6810	MS3110E10-6P	96906	CONNECTOR	EA	1
3	6	PA0ZZ	6210-00-084-3920	MS25256-2-327	96906	LIGHT	EA	1
3	7	PA0ZZ	5940-00-688-2770	111-103	74970	POST	EA	1
3	8	XDHZZ		RE60G2501	81349	RESISTOR	EA	1
3	9	PA0ZZ	6210-00-806-9412	MS25256-4-327	96906	LIGHT	EA	1
3	10	PA0ZZ	5210-00-672-9833	MS25256-6-327	96906	LIGHT	EA	3
3	11	PA0ZZ	5355-00-682-6548	2223	86660	KNOB	EA	3
3	12	PAHZZ	5821-00-971-6137	S90CP20-13	19904	NUTRING	EA	1
3	13	PAHZZ	5305-00-889-2999	MS35206-217	96906	SCREW	EA	8
3	14	XDHZZ		120-017S4R5	97499	SCREW	EA	1
3	15	PAHZZ	5920-00-280-3144	HKP	71400	HOLDER,FUSE	EA	2
3	16	PAHZZ	5310-00-167-0831	AN960-4L	88044	WASHER	EA	8
3	17	XDHZZ		NAS679A04	80205	NUT	EA	8
3	18	PAHZZ	5310-00-637-4885	12C1087	81073	WASHER	EA	2
3	19	XDHZZ		570-097-017-7	97499	PANEL ASSEMBLY	EA	1
					9			



EL1CE004

Figure 4. Test Set, Electronic System TS2676/ASM338, panel assembly, rear view.

SECTION II

TM 11-6625-1704-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	U/M	QTY INC IN
4	1	PAHZZ	5305-00-880-6077	120-17S4R14	97499	SCREW	EA	3
4	2	XDHZZ	5305-00-8902997	MS35206-215	96906	SCREW	EA	22
4	3	XDHZZ	5365-00-684-5983	AN960-4L	80205	SPACER	EA	3
4	4	PAHZZ	5310-00-467-0831	AN960-4L	88044	WASHER	EA	8
4	5	PA0ZZ	5920-00-284-9220	MS90078-24	96906	FUSE	EA	2
4	6	PAHZZ	5940-00-615-2282	111-102	74970	POST	EA	6
4	7	PAHZZ	5935-00-685-9421	473-018-01	02660	CONNECTOR	EA	1
4	8	PAHZZ	5960-00-850-9440	1N2984B	01295	DIODE	EA	1
4	9	PAHZZ	5930-00-814-7375	44M-03-3-4N	81073	SWITCH	EA	1
4	10	PAHZZ	5940-00-688-2770	111-103	74970	POST	EA	1
4	11	XDHZZ		44N30-03-4-3N	81073	SWITCH	EA	1
4	12	PAHZZ	5930-00-655-1514	MS35058-22	96906	SWITCH	EA	1
4	13	PAHZZ	5930-00-655-1575	MS35059-22	96906	SWITCH	EA	1
4	14	PAHZZ	5930-00-556-0307	MS25089-3G	96906	SWITCH	EA	2
4	15	PAHZZ	5905-00-539-5013	RV4NAYSD252A	81349	POTENTIOMETER	EA	1
4	16	XDHZZ	5340-00-543-5060	MS35338-39	96906	WASHER	EA	2
4	17	PAHZZ	5305-00-974-4977	MS35206-220	96906	SCREW	EA	3
4	18	PAHZZ	5950-00-819-1671	TW9D26T	02640	TRANSFORMER	EA	1
4	19	XDHZZ		NAS679A04	80205	NUT	EA	8
4	20	XDHZZ	5910-00-817-9056	NAS971-2	80205	NUT	EA	6
4	21	PAHZZ	5305-00-889-3118	MS35206-203	96906	SCREW	EA	2
4	22	XDHZZ		120-017S2R4	97499	SCREW	EA	2
4	23	XKHZZ		5790-91-014-1	97499	CHASSIS ASSEMBLY	EA	1
4	24	PAHZZ	5305-00-889-2997	MS35206-205	96906	SCREW	EA	1
4	25	PAHZZ	5310-00-515-8000	MS35337-39	96906	WASHER	EA	2
4	26	XDHZZ		120-017S4R5	97499	SCREW	EA	1
4	27	PAHZZ	5340-00-780-3701	7717-12DAP	13103	PAC, MOUNTING	EA	4
4	28	PAHZZ	5305-00-983-7126	120-017S4R8	97499	SCREW	EA	6
4	29	XDHZZ	5310-00-187-2395	AN960PD616L	88044	WASHER	EA	4
4	30	XDHZZ	5305-00-983-6730	MS35206-218	96906	SCREW	EA	2
					11			





Figure 5. Circuit Board Assembly.

SECTION II

TM 11-6625-1704-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	U/M	QTY INC IN
						GROUP 0101 CIRCUIT CARD ASSEMBLY		
5	1	PAHZZ	6615-00-809-3926	1MM655-2	99165	MODULATOR	EA	1
5	2	PAHZZ	5905-00-681-6462	RC07GF102J	81349	RESISTOR	EA	4
5	3	XDHZZ		AN960-4L	81349	CAPACITOR	EA	1
5	4	PAHZZ	5905-00-686-3368	RC07GF203J	81349	RESISTOR	EA	2
5	5	PAHZZ	5905-00-192-3978	RC20GF303J	81349	RESISTOR	EA	1
5	6	PAHZZ	5940-00-848-4004	1N9688	01295	DIODE	EA	1
5	7	PAHZZ	5905-00-727-8001	RC07GF681J	81349	RESISTOR	EA	1
5	8	PAHZZ	5910-00-648-8204	CP09A1KB153K	81349	CAPACITOR	EA	1
5	9	PAHZZ	5905-00-681-8854	RC97GF304J	81349	RESISTOR	EA	1
5	10	PAHZZ	5961-00-993-8522	2N910	01259	TRANSISTOR	EA	4
5	11	XDHZZ		44N30-03-4-3N	81349	CAPACITOR	EA	1
5	12	PAHZZ	5905-00-994-7137	RW69V360	81349	RESISTOR	EA	1
5	13	PAHZZ	5905-00-726-3807	RC07GF912J	81349	RESISTOR	EA	1
5	14	PAHZZ	5905-00-892-0359	RC32GF223J	96906	RESISTOR	EA	1
5	15	PAHZZ	5905-00-937-2887	324-5D	70674	TRANSFORMER	EA	1
5	16	PAHZZ	5305-00-279-1876	RC20GF222J	81349	RESISTOR	EA	2
5	17	PAHZZ		B2L332J	12406	CAPACITOR	EA	1
5	18	PAHZZ	5905-00-686-3838	RC07GF273J	81349	RESISTOR	EA	1
5	19	PAHZZ	5960-00-894-0684	1N758A	01295	DIODE	EA	2
5	20	PAHZZ	5905-00-681-9970	RC97GF822J	81349	RESISTOR	EA	1
5	21	PAHZZ	5305-00-686-3370	RC97GF202J	81349	RESISTOR	EA	1
5	22	PAHZZ	5961-00-087-6047	1N645	01295	DIODE	EA	5
5	23	PAHZZ	5910-00-882-0816	CP10A1KB474K	81349	CAPACITOR	EA	1
5	24	PAHZZ	5305-00-683-2238	RC07GF103J	81349	RESISTOR	EA	1
5	25	PAHZZ	5305-00-686-3356	RC07GF823J	81349	RESISTOR	EA	2
5	26	PAHZZ	5961-00-578-1699	1N628	01295	DIODE	EA	2
5	27	XDHZZ		B1L153J	12406	CAPACITOR	EA	1
5	28	PAHZZ	5305-00-800-0179	RC09GF563J	81349	RESISTOR	EA	1
5	29	PAHZZ	5350-00-937-2876	324-6D	70674	TRANSFORMER	EA	1
5	30	PAHZZ	5305-00-686-9995	RC017GF154J	81349	RESISTOR	EA	1
					13			



ELICE006

Figure 6. Case, Test Set.

SECTION II

TM 11-6625-1704-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	U/M	QTY INC IN
						GROUP 02 CASE, TEST SET		
6	1	PAHZZ	6110-00-299-1070	100-020-1M	97499	PLATE	EA	1
6	2	PAHZZ	5305-00-989-7434	AN520-10R8	88044	SCREW	EA	8
6	3	XDHZZ		120-017-10R8	97499	SCREW	EA	8
6	4	PA0ZZ	6625-00-935-5180	CX10852U	80058	CABLE ASSEMBLY	EA	1
6	5	PA0ZZ	6625-00-935-5178	CX10853U	80058	CABLE ASSEMBLY	EA	1
6	6	PA0ZZ	6625-00-935-5181	CX10851U	80058	CABLE ASSEMBLY	EA	1
6	7	PA0ZZ	6625-00-935-5179	CX10854U	80058	CABLE ASSEMBLY	EA	1
6	8	PA0ZZ	5826-00-879-7398	MX8096ASM338	80058	EXTENDER BOARD MODULE	EA	1
					15			





Figure 7. Cable Assembly, Special Purpose CX10851/U.

SECTION II

TM 11-6625-1704-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	U/M	QTY INC IN
						GROUP 0201 CABLE ASSEMBLY, SPECIAL PURPOSE CX-10851/U		
7	1	PAHZZ	5935-00-726-6487	MS3126F20-41P	96906	CONNECTOR	EA	1
7	2	PAHZZ	5935-00-724-7592	MS3126F20-41S	96906	CONNECTOR	EA	1
7	3	XDHZZ		85T4-625-72	97499	TUBING	EA	1
7	4	PAHZZ	5999-00-834-6397	30-010-3	97499	CAP, END	EA	3
					17			



ELICE008[®]

Figure 8. Cable Assembly, Special Purpose CX10853/U.

SECTION II

TM 11-6625-1704-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	U/M	QTY INC IN
						GROUP 0203 CABLE ASSEMBLY, SPECIAL PURPOSE CX-10853/U		
8	1	PAHZZ	5935-11-723-6753	MS3120416-26S	96906	CONNECTOR	EA	1
8	2	XDHZZ		85T4-375-36	97499	TUBE	EA	1
8	3	PAHZZ	5935-00-725-7723	MS3126F16-26P	96906	CONNECTOR	EA	1
8	4	PAHZZ	5975-00-984-5410	30-010-1	97499	CAP, END	EA	3
					19			




Figure 9. Cable Assembly, Special Purpose CX-10854/U

SECTION II

TM 11-6625-1704-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	U/M	QTY INC IN
						GROUP 0204 CABLE ASSEMBLY, SPECIAL PURPOSE CX-10854/U		
9	1	PAHZZ	5940-00-115-8632	53210	7901	TERMINAL	EA	3
9	2	XDHZZ		85T-9-4	97499	TUBE, INSULATED	EA	3
9	3	XDHZZ		85T4-1-72	97499	TUBE, INSULATED	EA	1
9	4	PAHZZ	5935-00-715-2756	MS3126F10-65-S	96906	CONNECTOR	EA	1
					21			




Figure 10. Board Assembly, Extender MX8096/ASM338.

ELICEOIC

SECTION II

TM 11-6625-1704-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	U/M	QTY INC IN
						GROUP 0205 CABLE ASSEMBLY, SPECIAL PURPOSE CX-10855/U		
10	1	XDHZZ		570-091-024-1	97499	GUIDE	EA	1
10	2	XDHZZ		NAS671-4	80205	NUT	EA	5
10	3	PAHZZ	5905-00-087-7108	120-017S4R9	97499	SCREW	EA	2
10	4	PAHZZ	5310-00-543-2410	MS35338-40	96906	WASHER	EA	5
10	5	XKHZZ		120-017S4R10	97499	SCREW	EA	2
10	6	XAHZZ		570-091-025-55	97499	DECAL	EA	1
10	7	PAHZZ	5935-00-671-7806	133-018-03-1001	02660	CONNECTOR	EA	1
10	8	PAHZZ	5935-00-982-0298-	133-018-03-1017	02660	CONNECTOR	EA	1
10	9	PAHZZ	5935-00-982-0220	133-018-03-1018	02660	CONNECTOR	EA	1
10	10	XDHZZ		143-018-003-1001	02660	CONNECTOR	EA	1
10	11	XDHZZ		143-018-03-1017	02660	CONNECTOR	EA	1
10	12	XDHZZ		143-018-03-1018	02660	CONNECTOR	EA	1
10	13	PAHZZ	5935-00-864-37-32	SKT103PC	98219	JACK, TEST POINT	EA	11
					23			

SECTION IV

TM 11-6625-1704-24P

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

NOTE: LATEST NATIONAL STOCK NUMBER ASSIGNMENTS ARE INCLUDED AT END OF INDEX

STOCK NUMBER	FIGURE NO.	ITEM	STOCK NUMBER NO.	FIGURE	ITEM NO.	NO.
5935-00-044-6810	3		5	5905-00-72-63807	5	13
6210-00-084-3920	3		6	5935-00-726-6487	7	1
5961-00-087-6047	5		22	5905-00-727-8001	5	7
5310-00-167-831	3		16	5340-00-780-3701	4	27
5310-00-167-0831	4		4	5905-00-800-0179	5	28
5310-00-187-2395	4		29	6210-00-806-9421	3	9
5905-00-192-3978	5		5	6615-00-809-3926	5	1
5905-00-279-1676	5		16	5310-00-817-9056	4	20
5920-00-284-9220	4		5	5950-00-819-1671	4	18
5905-00-539-5013	4		15	5999-00-834-6397	7	4
5310-00-543-2410	10		4	5935-00-844-2737	3	4
5310-00-543-5060	4		16	5961-00-848-7007	5	6
5930-00-556-0307	4		14	5935-00-849-7188	3	3
5940-00-615-2282	3		2	5935-00-864-3732	10	13
5940-00-615-2282	4		6	5826-00-879-7396	2	2
5310-00-637-4885	3		18	5826-00-879-7398	6	8
5910-00-648-8204	5		8	5826-00-879-7399	2	1
5930-00-655-1514	4		12	6625-00-880-1978	1	2
5930-00-655-1575	4		13	5910-00-882-0816	5	23
5935-00-671-7806	10		7	5305-00-889-2997	4	2
5905-00-681-6462	5		9	5305-00-889-2997	4	2
5905-00-681-8854	5		20	5305-008-89-2999	3	13
5905-00-681-9970	5		11	5305-00-889-3118	4	21
5355-00-682-6548	3		10	5905-00-892-0359	5	14
6210-00-682-9833	3		24	6625-00-935-5178	6	5
5905-00-683-2238	5		3	6625-00-935-5179	6	7
5165-00-684-5983	4		7	6625-00-935-5180	6	4
5365-00-685-9421	4		25	6625-00-935-5181	6	6
5905-00-686-3368	5		4	5950-00-937-2877	5	15
5905-00-686-3370	5		21	5821-00-971-6137	3	12
5905-00-686-3838	5		18	5935-00-982-0220	10	9
5905-00-686-9995	5		30	5935-00-982-0298	10	8
5940-00-688-2770	3		7	5305-00-983-6730	4	30
5940-00-688-2770	4		10	5305-00-984-4977	4	17
5935-00-715-2756	9		4	5975-00-984-5410	8	4
5935-00-723-6753	8		1	5935-00-984-8100	3	1
5935-00-724-7592	7		2	5305-00-989-7434	6	2
5935-00-725-7723	8		3	5905-00-994-7137	5	12

PART NUMBER	FSCM	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. NO.	TEM NO.
AN520-10R8	88044	6	2	MS35206220	96906	4	17
AN960-4L	88044	3	16	MS353373S	96906	4	25
AN960-4L	88044	4	4	MS3533839	96906	4	16
AN960PD616L	88044	4	29	MS3533840	96906	10	4
B1L153J	12406	5	27	MS9007824	96906	4	5
82L332J	12406	5	17	MX8096ASM338	80058	6	8
CP09A1KB153K	81349	5	8	NAS4300028	80205	4	3
CP10A1KI74K	81349	5	23	NAS6712	80205	4	20
CSR13F685MP	81349	5	11	NAS6714	80205	10	2
CSR13105MP	81349	5	3	NAS679A04	80205	3	17
CX10851U	80058	6	6	NAS679A04	80205	4	19
CX10852U	80058	6	4	RC07GF102J	81349	5	2
CX10853U	80058	6	5	RC07GF103J	81349	5	24
CX10854U	80058	6	7	RC07GF54J	81349	5	30
CY6470ASM338	80058	1	2	RC07GF202J	81349	5	21
HKP	71400	3	15	RC07GFZ03J	81349	5	4
MS25089-3G	96906	4	14	RC07GF273J	81349	5	18
MS2525-2-327	96906	3	6	RC07GF304J	81349	5	9
MS25256-4-327	96906	3	9	RC07GF563J	81349	5	28
MS25256-6-327	96906	3	10	RC07GF681J	81349	5	7
MS3110E10-6-P	96906	3	5	RC07GF822J	81349	5	20
MS3110E12-10S	96506	3	4	RC07GF823J	81349	5	25
MS3110E16-26S	96906	3	3	RC07GF912J	81349	5	13
MS3110820-41S	96906	3	1	RC20GF222J	81349	5	16
MS3120F16-26S	96906	8	1	RC20GF303J	81349	5	5
MS3126F10-6S	96906	9	4	RC32GF223J	81349	5	14
MS3126F16-26P	96906	8	3	RE60G250	81349	3	8
MS3126F20-41P	96906	7	1	RV4NAYS252A	81349	4	15
MS3126F20-41S	96906	7	2	RW69V360	81349	5	12
MS35058-22	96906	4	12	SKT103PC	98219	10	13
MS35059-22	96906	4	13	S900P20-13	19904	3	12
MS35206-203	96906	4	21	TS2676ASM338	80058	1	1
MS35206-215	96906	4	2	Tw9026T	02640	4	18
MS35206-215	96696	4	24	1MM655-2	99165	5	1
MS35206-217	96906	3	13	1N29848	01295	4	8
MS35206-218	96906	4	30	1N628	01295	5	26

SECTION IV

TM 11-6625-1704-24P

PART NUMBER	FSCM	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. NO.	TEM NO.
1N645	01295	5	22	143-018-03-1018	02660	10	12
1N758A	01295	5	19	2N910	01295	5	10
INS68B	01295	5	6	2223	83330	3	11
100-020-1M	57499	6	1	30-010-01	97499	8	4
111-102	74970	3	2	300-010-3	97499	7	4
111-102	74970	4	6	324-5D	70674	5	15
111-103	74970	3	7	324-6D	70674	5	29
111-103	74970	4	10	44M30-03-3-4N	81073	4	9
1200107	81073	3	18	44M30-03-4-3N	81073	4	11
120-017-10R8	97499	6	3	53210	79061	9	1
120-017S2R4	97499	4	22	570-091-0071	97499	2	2
120-01754R10	97499	10	5	570-091-0141	97499	4	23
120-01754R14	97499	4	1	570-091-0177	97499	3	19
120-017S4R5	97499	3	14	570-091-0183	97499	2	3
120-017S4R5	97499	4	26	570-091-0241	97499	10	1
120-017S4R8	97499	4	28	570-091-02555	97499	10	6
120-017S4R9	97499	10	3	570-091-0291	97499	2	1
133-018-03-1001	02660	10	7	7717-121DAP	13103	4	27
133-018-03-1017	02660	10	8	85T4-1-72	97499	9	3
133-018-03-1018	02660	10	9	85T4-375-36	97499	8	2
143-018-003-1001	02660	10	10	85T4-625-72	97499	7	3
143-018-01	02660	4	7	85T4-9-4	97499	9	Z
143-018-03-1017	02660	10	11				

LATEST NATIONAL STOCK NUMBER ASSIGNMENTS

NATIONAL STOCK NUMBER	FIG. NO.	ITEM NO.
5305-00-087-7108	10	3
5940-00-115-8632	9	1
5920-00-280-3144	3	15
6110-00-2199-1070	6	1
5310-00-515-8000	4	25
5961-00-578-1699	5	2-6
5930-00-814-7375	4	9
5960-00-850-9440	4	8
5305-00-880-6077	4	1
5960-00-894-0684	5	19
5305-00-983-7126	4	28
5961-00-993-8522	5	10

U.S. GOVERNMENT PRINTING OFFICE: 1984 O 421302 (10228)

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT... PIN-POINT WHERE IT IS

PAGE NO.

PARA-GRAPH

FIGURE NO.

TABLE NO.

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 2028-2
1 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

