

DEPARTMENT OF THE ARMY TECHNICAL MANUAL
GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND
SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS)
TEST SET, TELEPHONE TS-816/U
FSN 6625-542-6111

Headquarters, Department of the Army, Washington, DC
16 December 1974

Current as of 2 October 1974

		Paragraph	Page
SECTION I.	INTRODUCTION		
	Scope	1-1	2
	General	1-2	2
	Explanation of columns	1-3	2
	Special information	1-4	4
	Location of repair parts	1-5	4
	Abbreviations (Not applicable)	1-6	4
	Reporting of equipment publication improvements	1-7	5
II.	REPAIR PARTS LIST		6
III.	SPECIAL, TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
IV.	INDEX-FEDERAL, STOCK NUMBER AND REFERENCE NUMBER CROSS REFERENCE TO FIGURE AND ITEM NUNIBER		9

*This manual supersedes TM 11-6625-201-20P, 5 February 1962 and TM 11-6625-201-45P, 21 September 1962.

SECTION I INTRODUCTION

1-1. Scope

This manual lists repair parts and special tools required for the performance of general support and depot maintenance of the TS-816/U. The PCCN for the TS-816/U is GCWAMI for all models.

NOTE

No parts authorized for stockage at direct support.

1-2. General

This repair parts and special tools list is divided into the following sections:

a. *Repair Parts List -Section II.* A list of repair parts authorized for the performance of maintenance at the general support and depot level. This repair parts list is arranged in alphabetical order.

b. *Special Tools, Test and Support Equipment - Section III.* Not applicable.

c. *Index - Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number - Section IV.* A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphanumeric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

1-3. Explanation of Columns

The following provides an explanation of columns found in the tabular list.

a. *Source, Maintenance, and Recoverability Codes (SMR).*

(1) *Source code.* Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are:

Code	Explanation
------	-------------

PA - Item procured and stocked for anticipated or known usage.
 PB - Item procured and stocked for insurance purposes because essentially dictates that a minimum quantity be available in the supply systems.
 PC - Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
 PD - Support item, excluding support equipment, procured for initial issue or outfitting and

Code	Explanation
PE -	Stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PF -	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PG -	Support equipment which will not be stocked but which will be centrally procured on demand.
KD -	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KF -	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KB -	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.
MO -	Item to be manufactured or fabricated at organizational level.
MF -	Item to be manufactured or fabricated at direct support maintenance level.
MH -	Item to be manufactured or fabricated at general support maintenance level.
MD -	Item to be manufactured or fabricated at depot maintenance level.
AO -	Item to be assembled at organizational level.
AF -	Item to be assembled at direct support maintenance level.
AH -	Item to be assembled at general support maintenance level.
AD -	Item to be assembled at depot maintenance level.
XA -	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB -	Item is not procured or stocked. If not available through salvage, requisition.
XC -	Installation drawing, diagram instruction sheet, field service drawing, that is identified by manufacturers' part number.

<i>Code</i>	<i>Explanation</i>
XD -	Support items can be requisitioned with justification.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) *Use (third position).* The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position indicates one of the following levels of maintenance.

<i>Code</i>	<i>Application/Explanation</i>
O -	Support item is removed, replaced, used at the organizational level of maintenance.

NOTE

A code "C" may be used in this position to denote crew or operator maintenance performed within organizational maintenance.

F -	Support item is removed, replaced, used at the direct support maintenance level.
H -	Support item is removed, replaced, used at the general support maintenance.
D -	Support items that are removed, replaced, used at depot only.

(b) *Repair (fourth position).* The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used a dash (-) sign is entered. For multiservice equipment/systems or when a code is entered, this position will contain one of the following maintenance codes as assigned by the service(s) that require the code:

<i>Code</i>	<i>Application /Explanation</i>
O -	The lowest maintenance level capable of complete repair of the support item is the organizational level.
F -	The lowest maintenance level capable of complete repair of the support item is direct support.

<i>Code</i>	<i>Application/Explanation</i>
H -	The lowest maintenance level capable of complete repair of the support item is general support.
D -	The lowest maintenance level capable of complete repair of the support item is the depot level.
L -	Repair restricted to designated Specialized Repair Activity.
Z -	Nonrepairable. No repair is authorized.
B -	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Explanation</i>
Z -	Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in the first digit of the maintenance code.
O -	Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
F -	Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.
H -	Repairable item. When uneconomically repairable, condemn and dispose at the general support level.
D -	Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L -	Repairable item. Repair, condemnation, and disposal not authorized below depot/Specialized Repair Activity level.
A -	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material).

b. *Federal Stock Number.* Indicates the Federal stock number assigned to the item.

NOTE

For requisitioning purposes, the Federal stock number must be converted to the National stock number by adding "-00-" after the Federal stock classification (FSC)

code (first four digits). For example, FSN 6625553-0142 converts to NSN 6625-00-553-0142.

c. *Description*. Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc., and is identified in SB 70842.

d. *Unit of Measure (U/M)*. Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation; e.g., ea, in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

e. *Quantity Incorporated in Unit*. This column indicates the quantity of the item used in the equipment. Subsequent appearances of the same item in the same assembly are indicated by the letters "REF".

f: 30-Day DSIGS Maintenance Allowances.

NOTE

Allowances in GS column are for GS maintenance only.

(1) The repair parts indicated by asterisk entries in separate allowance columns for GS represent those authorized for use at that category of maintenance to be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Allowance quantities are indicated in the special tool lists section for special tools, TMDE, and other support equipment.

g. 1-Year Allowances Per 100 Equipment's/Contingency Planning Purposes. Column intentionally left blank.

h. *Depot Maintenance Allowance Per 100 Equipment's*. This column indicates opposite the first appearance of each item the total quantity authorized for depot maintenance of 100 equipment's.

i. *Illustration*. This column is divided as follows:

(1) *Figure number*. Indicates the figure number of the illustration on which the item is shown in TM 11-6625-201-12 and TM 11-6625-201-45.

(2) *Item number*. Indicates the item number or reference designation used to reference the item in the illustration.

1-4. Special Information

a. Usable on codes are included in column 3. Uncoded items are applicable to all models. Identification of the usable on codes used in this publication are:

Code	Used on
BWB	TS-816/U

b. The following publications pertain to the TS-816/U and its components:

TM 11-6625-201-12 Operator and Organizational Maintenance Manual: Test Set, Telephone TS-816/U.

TM 11-6625-201-45 Field (Fourth Echelon) and Depot Maintenance Manual: Test Set, Telephone TS-816/U.

1-5. Location of Repair Parts

a. This manual contains one cross-reference index (sec IV) to be used to locate a repair part when either the Federal stock number or reference number (manufacturer's part number) is known. The first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacturer's part numbers) are listed immediately following the last listed Federal stock number in the index of Federal stock numbers.

b. When the Federal stock number or reference number is known, follow the procedures given in (1) and (2) below.

(1) Refer to the index of Federal stock numbers (sec IV) and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable figure and item number or reference designation.

(2) Refer to the repair parts list (sec II) and locate the figure number (col 10a) and item number or reference designation (col 10b) as noted in the FSN index.

c. When the figure and item number or reference designation are known, scrutinize columns 10a and 10b of the repair parts list (sec II) until the item is located.

d. When the FSN, reference number, figure number, item number and reference designation are not known, scrutinize column 3 of the repair parts list (sec II), which is arranged in alphabetical order.

1-6. Abbreviations

Not applicable.

1-7. Reporting of Equipment Publication Improvements

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on

DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forwarded direct to Commander, US Army Electronics Command, ATTN: AMSELMA-CW, Fort Monmouth, NJ 07703.

SECTION II

TM 11-6625-201-40P

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REF. NUMBER & MFR CODE	(4) UNIT OF MEAS	(5) QTY INC IN UNIT	(6) 30-DAY DS MAINT ALLOWANCE			(7) 30-DAY GS MAINT ALLOWANCE			(8) 1-YR ALW PER 100 EQUIP CNTGCY	(9) DEPOT MAINT ALW PER 100 EQUIP	(10) ILLUSTRATION	
					(a) 1-20	(b) 21-50	(c) 51-100	(a) 1-20	(b) 21-50	(c) 51-100			(a) FIGURE NO.	(b) ITEM NO.
PAFZZ	6350-262-7253	BULZER BZ1..... SM8189498 (80063)	EA	1	*	*	*	*	*	*		4	5	BZ1
PAFZZ	6415-244-8152	CABLE, POWER, ELECTRICAL W3 2 COND NO..... 18 AWG JC580 (81348)	FT	33	*	*	*	*	*	*		5		W3
PAFZZ	5999-244-5150	CAP. ELECTRICAL NO-REC-DESIG..... F/FUSEHULUER 9435-1-2 (71400)	EA	1	*	*	*	*	*	*		3		
PAFLZ	5910-112-74U8	CAPACITOR, FIXED, PAPER DIELECTRIC C1..... CPS3BIEF5U4V (81349)	EA	2	*	*	*	*	*	*		3	3	CL
PAFZZ	5910-112-1408	CAPACITOR, FIXEO, PAPER DIELECTRIC C2..... CP53BLEF5U4 (813491)	EA	REF	*	*	*	*	*	*		3	3	C3
XDFZZ		CLIP, ELECTRICAL EIO BATTERY TYPE..... 21 (7654)-	EA	2	*	*	*	*	*	*				E10
XDFZZ		CLIP, ELECTRICAL EII BATTERY TYPE..... 21 (7654)	EA	REF	*	*	*	*	*	*				E11
XDFZZ		CONNECTOR, PLUG, ELECTRICAL P17..... PZI02CCE (71785)	EA	2	*	*	*	*	*	*				P17
XDFZZ		CONNECTOR, PLUG, ELECTRICAL F18..... PZ402CLE (17185)	EA	REF	*	*	*	*	*	*				P18
PAFZZ	5935-201-8514	CONNECTOR, PLUG, ELECTRICAL P1..... 7364TYPE1J (72825)	EA	16	*	*	*	*	*	*		3		P1
PAFZZ	5935-201-8514	CONNECTCR, PLUG, ELECTRICAL P2	EA	REF	*	*	*	*	*	*		3		P2
PAFZZ	5935-201-8514	CONNECTOR, PLUG, ELECTRICAL P3..... 7364TYPE3U (72825)	EA	REF	*	*	*	*	*	*		3		P3
PAFZZ	5935-201-8514	CONNECTOR, PLUG, ELECTRICAL P4..... 7364TYPE1O (72825)	EA	REF	*	*	*	*	*	*		3		P4
PAFZZ	5935-201-8514	CONNECTOR, PLUG, ELECTRICAL F5..... 7364TYPE30 (72825)	EA	REF	*	*	*	*	*	*		3		P5
PAFZZ	5935-201-8514	CONNECTOR, PLUG, ELECTRICAL P6..... 7364TYPE40 (728251)	EA	REF	*	*	*	*	*	*		3		P6
PAFZZ	5935-201-8514	CONNECTOA, PLUG, ELECTRICAL P7..... 7364TYPE30 (72825)	EA	REF	*	*	*	*	*	*		3		P7
PAFZZ	5935-201-8514	CONNECTOR, PLUG, ELECTRICAL P8..... 7364TYPE-O 172825)	EA	REF	*	*	*	*	*	*		3		P8
PAFZZ	5935-201-8514	CONNECTOR, PLUG, ELECTRICAL P9..... 7364TYPE30 (172825)	EA	REF	*	*	*	*	*	*		3		P9
PAFZZ	5935-201-8514	CONNECTOR, PLUG, ELECTRICAL P10..... 7364TYPE30 (728251)	EA	REF	*	*	*	*	*	*		3		P10
PAFZZ	5935-201-8514	CONNECTOR, PLUG, ELECTRICAL P11..... 7364TYPE30 (72825)	EA	REF	*	*	*	*	*	*		3		P11
PAFZZ	5935-201-8514	CONNECTOR, PLUG, ELECTRICAL P12..... 7364TYPE30 172825)	EA	REF	*	*	*	*	*	*		3		P12
PAFZZ	5935-201-8514	CONNECTOR, PLUG, ELECTRICAL P13..... 7364TYPE1O (72825)	EA	REF	*	*	*	*	*	*		3		P13
PAFZZ	5935-201-8514	CONNECTOR, PLUG, ELECTRICAL F14..... 73b4TYPEJU (728251)	EA	REF	*	*	*	*	*	*		3		P14
PAFZZ	5935-201-8514	CONNECTOR, PLUG, ELECTRICAL P15..... 7364TYPE3U (728251)	EA	REF	*	*	*	*	*	*		3		P15
PAFZZ	5935-201-8514	CONNECTOR, PLUG, ELECTRICAL P16..... 7364TYPE30 (172825)	EA	REF	*	*	*	*	*	*		3		P16

SECTION II

TM 11-6625-201-40P

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REF. NUMBER & MFR CODE	(4) UNIT OF MEAS	(5) QTY INC IN UNIT	(6) 30-DAY DS MAINT ALLOWANCE			(7) 30-DAY GS MAINT ALLOWANCE			(8) 1-YR ALW PER 100 EQUIP CNTGCY	(9) DEPOT MAINT ALW PER 100 EQUIP	(10) ILLUSTRATION		
					(a) 1-20	(b) 21-50	(c) 51-100	(a) 1-20	(b) 21-50	(c) 51-100			(a) FIGURE NO.	(b) ITEM NO.	
PAFZZ	5935-259-2035	CONNECTOR RECEPTACLE, ELECTRICAL JI S2402SB (71785)	EA	1				*	*	*			3	3	J1
XDFZZ		FASTENER, LATCH NO-REF-DESIG..... 4444N (21992)	EA	2				*	*	*					
PACZZ	5920-232-3703	FUSE, CARTRIDGE FL 0.031 AMP, 250V	EA	1				*	*	*			5	3	F1
XDFZZ		FUSEHOLDER XFL	EA	1				*	*	*					XF1
PAFZZ	5920-221-5678	HJM (71400) FUSEHOLDER XF2 BLOCK TYPE F/SPARE FUSE.....	EA	1				*	*	*			3		XF2
PAFZZ	5355-160-5920	KNOB NO-REF-DESIG FOR RESISTOR RD	EA	1				*	*	*			3		
PAFZZ	5355-160-6850	PLASTIC 5/8 IN DIA X 1/16 IN THK 6126 (80375)	EA	1				*	*	*			3		
PAFZZ		KNOB NO-REF-DESIG FOR ROTARY SWITCH BAR..... SHAPE PHENOLIC WHITE LINE MARKING FOR 1/4 IN DIA SHAFT 1-1/2 IN LG X 3/4 IN W X 5/8 IN H LP482899 (64959)	EA	1				*	*	*					
XDFZZ		KNJB NU-REF-DESIG FOR OHM SWITCH	EA	1				*	*	*					
		RECTANGULAR SHAPE PHENOLIC 25/32 IN LG X 5/8 IN W X 3/8 IN THK KS10011L5-1191 (56175)													
PAFZZ	6625-545-7939	MULTINETER, REPLACEMENT MA1	EA	1				*	*	*			5	4	MAL
XDFZZ		SMD189420-1 (80063) NIPPLE, CABLE, ELECTRICAL NO-REF-DESIG	EA	1				*	*	*					
PAFZZ	5975-233-6301	NIPPLE, CABLE, ELECTRICAL NO-REF-DESIG..... TEST CLIP INSULATOR 29BLACK (76545)	EA	1				*	*	*			5		
PAFZZ	5940-194-7717	POST, BINDING TM-152 TS1 (USED W/ORDER..... NO. 38270-PH-53) TM152 (80058)	EA	2				*	*	*			2	3	TS1
PAFZZ	5940-194-7717	POST, BINDING TM-152 TS2 (USED W/ORDER..... NJ. 38270-PH-53) TM152 (80058)	EA	REF				*	*	*			2	3	TS2
PAFZZ	5905-256-3361	RESISTOR, FIXED, COMPOSITION R1..... RC42GF102J (81349)	EA	2				*	*	*			3	3	R1
PAFZZ	5905-253-3361	RESISTOR, FIXED, COMPOSITION R2..... RC42GF102J (81349)	EA	REF				*	*	*			3	3	R2
PAFZZ	5905-279-1979	RESISTOR, FIXED, COMPOSITION R4..... RC42GF101J (81349)	EA	1				*	*	*			3	5	R4
PAFZZ	5905-279-1747	RESISTOR, FIXED, COMPOSITION R6..... RC42GF870J (81349)	EA	1				*	*	*			3	3	R6
XDFZZ		RESISTOR, FIXED, COMPOSITION R7..... RC42GF560J (81349)	EA	1				*	*	*			3		R7
PAFZZ	5905-257-0937	RESISTOR, FIXED, COMPOSITION R12..... KC42GF472J (81349)	EA	1				*	*	*			3	5	R12
PAFZZ	5905-279-2633	RESISTOR, FIXED, COMPOSITION R8..... RC42GF820J (81349)	EA	1				*	*	*			3	3	R8
PAFZZ	5905-299-2003	RESISTOR, FIXED, COMPOSITION R13..... KC32GFL04J (81349)	EA	1				*	*	*			3	5	R13

SECTION II

TM 11-6625-201-40P

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REF. NUMBER & MFR CODE	(4) UNIT OF MEAS	(5) QTY INC IN UNIT	(6) 30-DAY DS MAINT ALLOWANCE			(7) 30-DAY GS MAINT ALLOWANCE			(8) 1-YR ALW PER 100 EQUIP CNTGCY	(9) DEPOT MAINT ALW PER 100 EQUIP	(10) ILLUSTRATION	
					(a) 1-20	(b) 21-50	(c) 51-100	(a) 1-20	(b) 21-50	(c) 51-100			(a) FIGURE NO.	(b) ITEM NO.
XDFZZ		RESISTOR, VARIABLE P1 COMP 2,500 OHM..... PORMIOPCT 2W OPTION 4 W/AP2040 SHAFT JU2521 (01121)	EA	1				*	*	*				P1
XDFZZ		RESISTOR, VARIABLE P1 COMP 2,000 OHMS..... PORM10PCT ZW (USED W/ORDER 38270-PH-53) J2U202KP3048 (01121)	EA	1				*	*	*				P1
PAFZZ	5905-259-3511	RESISTOR, FIXED, WIRE OUND R11	EA	1				*	*	*		3	3	R11
PAFZZ	5905-258-0083	RESISTOR, FIXED, WIRE WOUND R10..... PWS029 (48615)	EA	1				*	*	*		3	5	R10
PAFZZ	5905-537-6751	RESISTOR, FIXED, WIRE WOUND R9..... RV1045 (48615)	EA	1				*	*	*		3	3	R9
PAFZZ	5905-295-4078	RESISTOR, FIXED, WIRE WOUND R5..... RV200 (48615)	EA	1				*	*	*		3	3	R5S
PAFZZ	5905-295-4091	RESISTOR, FIXED, WLRE WOUND R3..... RV6988 (48615)	EA	1				*	*	*		3	5	R3
XDFZZ		STUD, CONTINUOUS THREAD NO-REF-DESIG MTG..... FOR RESISTOR ASSY SMD189420-25 (80063)	EA	1				*	*	*				
PAFZZ	5930-201-3586	SWITCH, LEVER K4	EA	1				*	*	*		5	4	K4
PAFZZ	5930-636-0454	SWITCH, LEVER K3 METER SWITCH	EA	1				*	*	*		5	3	K3
PAFZZ	5930-201-3587	SWITCH, LEVER KS LINE SHORT SWITCH..... SMD189*20-21 (80063)	EA	1				*	*	*		5	4	KS
PAFZZ	5930-253-1646	SWITCH, PUSH K2..... D16189*BTYPESS78 (64959)	EA	1				*	*	*		5	3	K2
PAFZZ	5930-669-9966	SWITCH, ROTARY D1..... SM8189427 (80063)	EA	1				*	*	*		5	4	DI
PAFZZ	5930-235-9764	SWITCH, ROTARY K	EA	1				*	*	*		5	3	KL
XDFZZ		SWITCH. TOUGLE D2..... AS35059-16TYPEST* 5ZP (96906)	EA	1				*	*	*			3	D2
PAFZZ	5940-234-7484	TERMINAL BOARD TB3 PLASTIC 2 BINDING..... POST TYPE TERM INCL 2 IN LG X 11/16 IN W X 3/26 IN THK ONE 6-3THD STUD 7186 (72825)	EA	1				*	*	*		3	3	TB3
XDFZZ		THUMBSCREW NO-REF-OESIG .. SBM189461 (80063)	EA	1				*	*	*				
PAFZZ	6645-663-7942	TINER, INTERVAL MOI..... A83L1Z (82227)	EA	1				*	*	*		3	5	M01

**INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER
CROSS-REFERENCE TO FIGURE AND ITEM NUMBER**

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
5355-160-9200			5930-669-9966	4	D1
5355-160-6850			5935-201-8514		P10
			5935-201-8514		P11
			5935-201-8514		P12
			5935-201-8514		P13
			5935-201-8514		P14
			5935-201-8514		P15
5905-256-3361	3	R1	5935-201-8514		P16
5905-256-3361	3	R2	5935-201-8514		P1
5905-257-0937	S	R12	5935-201-8514		P2
5905-258-0083	5	R10	5935-201-8514		P3
5905-219-3511	3	R11	5935-201-8514		P4
5905-279-1747	3	R6	5935-201-8514		P5
5905-279-1979	5	R4	5935-201-8514		P6
5905-279-2633	3	R8	5935-201-8514		P7
5905-29S-4078	3	R5	5935-201-8514		P8
5905-295-4091	5	R3	5935-201-8514		P9
5905-299-2003	5	R13	5935-259-2035	3	J1
5905-537-0751	3	R9			
			5940-194-7717	3	TS1
5910-112-7408	3	C1	5940-194-7717	3	TS2
5910-112-7408	3	C2			
5920-221-5678		XF2			
5920-232-3703	3	F1	5940-234-7484	3	TB3
			5975-233-6301		
5930-201-3586	4	K4	5999-244-5150		
5905-201-3587	4	K5	6145-244-8152		W3
5930-235-9764	3	K1	6350-262-7253	5	BZ1
5930-253-1646	3	K2	6625-545-7939	4	MA1
5930-636-0454	3	K3	6645-663-7942	5	M01
REFERENCE NO.	MFR CODE	FIG. NO.	ITEM NO.	REFERENCE NO.	MFR CODE
A831Z2	82227	5	M01	SMD189420-17	80063
CP53B1EF504V	81349	3	C11	SMD189420-18	80063
CP53B1EF504V	f1349	3	C2	SM0189420-21	80063
D161892ATYPE552A	64959	3	K1	SM0189420-25	60063
D161894BTYPE5418	64959	3	K2	S2402SB	71785
F01GR031A	81349	3	F1	TM152	80058
HJM	71400		XF1	TM152	80058
JC580	81348		W3	27	16545
JU2521	01121		P1	27	76545
J2U202KP3048	01121		P1	29BLACK	76545
KS10011L5-1191	56175			29RED	76545
LP482899	64959			387001	75915
MS3505-L6TYPEST52P	96906	3	D2	4444N	21992
PWS029	48615	5	R10	6126	80375
P2402CCE	71785		P17	7186	72825
P2402CCE	71785		P18	7364TYPE30	72825
RC32GF104J	81349	5	R13	7364TYPE30	72825
RC42SF101J	81349	5	R4	7364TYPE30	72d25
RC42GFL10J	81349	3	R1	7364TYPE30	72825
RC42GF102J	81349	3	R3	7364TYPE30	72825
RC42GF27JJ	81349	3	R6	7364TYPE30	72825
RC42GF47JJ	81349	5	R12	7364TYPE30	72825
RC42GF560J	81349	3	R7	7364TYPE30	72825
KC42GF820J	81349	3	R8	73o4TYPE30	72825
RV1045	48615	3	R9	7364TYPE30	72825
RV200	48615	3	R5	7364TYPE30	72825
RV6988J	48615	5	R3	7364TYPE30	72825
RV74-5	48615	3	R11	7364TYPE30	72825
SM1BL9421	80063	4	DI	7364TYPE30	7282S
SMB18942b	80063	5	BLI	7364TYPE30	72825
SMBld9461	80063			7364TYPE30	72825
SM018942U-I	80063	4	MAI	9435-1-2	71400

By Order of the Secretary of the Army:

FRED C. WEYAND
General, United States Army
Chief of Staff

Official:

VERNE L. BOWERS
Major General, United States Army
The Adjutant General

Distribution:

Active Army:

USASA (2)	USAIS (2)
CNGB (1)	USAES (2)
ACSCE (2)	AD (1) except
Dir of Trans (1)	SAAD (30)
COE (1)	LBAD (14)
TSG (1)	TOAD (14)
USAARENBD (1)	USA Dep (2)
AMC (1)	Sig Sec USA Dep (2)
MICOM (2)	Sig Dep (2)
TECOM (2)	ATS (1)
TRADOC (2)	MAAG (1)
ARADCOM (2)	WRAMC (1)
ARADCOM Rgn (2)	USARMIS (1)
OS Maj Comd (4)	USAERDAA (1)
LOGCOMD (3)	USAERDAW (1)
USACC (4)	Sig FLDMS (1)
MDW (1)	Ft Richardson (ECOM Ofc) (2)
Armies (2)	Units org under fol TOE (1 ea.):
Corps (2)	11-15
HISA (Ft Monmouth) (18)	11-16
Ft Gordon (10)	11-18
Ft Huachuca (10)	11-27
Ft Carson (5)	11-37
WSMR (1)	11-45
Svc Colleges (1)	1146
USASESS (5)	1147
USAINTCS(3)	11-87
USAADS (2)	11-500(AA-AC)
USAFAS (2)	29134
USAARMS (2)	29-136

ARNG & USAR: None.

For explanation of abbreviations used, see AR 310-50.

* U.S. GOVERNMENT PRINTING OFFICE: 1974-665136/391

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

SOMETHING WRONG WITH PUBLICATION



THEN...JOT DOWN THE
DOPE ABOUT IT ON THIS FORM.
CAREFULLY TEAR IT OUT, FOLD IT
AND DROP IT IN THE MAIL.

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT PIN-POINT WHERE IT IS

PAGE
NO.

PARA-
GRAPH

FIGURE
NO.

TABLE
NO.

IN THIS SPACE, TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT.

PRINTED NAME, GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

DA FORM 1 JUL 79 2028-2

PREVIOUS EDITIONS
ARE OBSOLETE.

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR
RECOMMENDATION MAKE A CARBON COPY OF THIS
AND GIVE IT TO YOUR HEADQUARTERS.

PIN: 019407