

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

**ORGANIZATIONAL; DIRECT SUPPORT, AND GENERAL
SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL
TOOLS LISTS (INCLUDING DEPOT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS)
TEST SETS TS-261/TSM, TS-26A/TSM,
AND TS-26B/TSM (FSN 6625-244-0502)**

**Headquarters, Department of the Army, Washington, D.C.
15 August 1973**

Current as of February 1973

SECTION		Paragraph	Page
I.	INTRODUCTION		
	Scope	1-1	2
	General.....	1-2	2
	Explanation of columns	1-3	2
	Special information.....	1-4	4
	Location of repair parts.....	1-5	4
	Abbreviations (Not applicable)	1-6	4
	Reporting of equipment publication improvements	1-7	5
II.	PRESCRIBED LOAD ALLOWANCE (Not applicable)		
III.	REPAIR PARTS LIST		6
IV.	SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
V.	REPAIR PARTS LIST		7
VI.	SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
VII.	INDEX-FEDERAL STOCK NUMBER AND REFERENCE-NUMBER CROSS-REFERENCE TO FIGURE AND ITEM NUMBER		10

*This manual supersedes so much of TM 11-2017. 24 March 1955, including all changes, as pertains to repair parts and special tools.

SECTION I INTRODUCTION

1-1. Scope

This manual lists repair parts and special tools required for the performance of organizational, direct support, general support, and depot maintenance of the TS-26ATSM, TS-26BTSiLM and TS-26rTSM. The PCCN for the equipment is GCMABI for all models.

1-2. General

This repair parts and special tools list is divided into the following sections:

a. *Prescribed Load Allowance (PLA)-Section II.* Not applicable.

b. *Repair Parts List-Section III.* A list of repair parts authorized for the performance of maintenance at the organizational level. This repair parts list is arranged in alphabetical order.

c. *Special Tools, Test and Support Equipment-Section IV.* Not applicable.

d. *Repair Parts List-Section V.* A list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot level.

e. *Special Tools, Test and Support Equipment-Section VI.* Not applicable.

f. *Index-Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number-Section VII.* A list, in ascending Numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphabetic sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

1-3. Explanation of Columns

The following provides an explanation of columns found in the tabular list.

a. *Source, Maintenance, and Recoverability Codes (SMR).*

(1) Source code. Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are-

<i>Code</i>	<i>Explanation</i>
PA-	Item procured and stocked for anticipated or known usage.
PB-	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.
PC-	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.

<i>Code</i>	<i>Explanation</i>
PD-	Support item, excluding -support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings Not subject to automatic replenishment.
PF-	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF-	Support equipment which will not be stocked but which will be centrally procured on demand.
PG-	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD-	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that., provides items required at the time of overhaul or repair.
KF-	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.
KB-	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO-	Item to be manufactured or fabricated at organizational level.
MF-	Item to be manufactured or fabricated at direct support maintenance level.
MH-	Item to be manufactured or fabricated at general support maintenance level.
MD-	Item to be manufactured or fabricated at depot maintenance level.
AO-	Item to be assembled at organizational level.
AF-	Item to be assembled at direct support maintenance level.
AH-	Item to be assembled at general support maintenance level.
AD-	Item to be assembled at depot maintenance level.
XA-	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB-	Item is not procured or stocked. If not available through salvage, requisition.
XC-	Installation drawing, diagram instruction sheet, field service drawing, that is identified by manufacturers' part number.
XD-	Support items can be requisitioned with justification.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code Format as follows-

(a) *Use (third position).* The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position indicates one of the following levels of maintenance.

Code	Application/Explanation
O-	Support item is removed, replaced, used at the organizational level of maintenance.

NOTE

A code "C" may be used in this position to denote crew or operator maintenance performed within organizational maintenance.

Code	Application/Explanation
F-	Support item is removed, replaced, used at the direct support maintenance level.
H-	Support item is removed, replaced, used at the general support maintenance.
D-	Support items that are removed, replaced, used at depot only.

(b) *Repair (fourth position).* The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used a dash (-) sign is entered. For multi-service equipment/systems or when a code is entered, this position will contain one of the following maintenance codes as assigned by the service(s) that require the code-

Code	Application/Explanation
O-	The lowest maintenance level capable of complete repair of the support item is the organizational level.
F-	The lowest maintenance level capable of complete repair of the support item is direct support.
H-	The lowest maintenance level capable of complete repair of the support item is general support.

Code	Application/Explanation
D-	The lowest maintenance level capable of complete repair of the support item is the depot level.
L-	Repair restricted to designed -Specialized Repair Activity.
Z-	Non-repairable. No repair is authorized.
B-	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the uniform SMR Code Format as follows-

Code	Explanation
Z-	Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in the first digit of the maintenance code.
O-	Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
F-	Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.
H-	Repairable item. When uneconomically repairable, condemn and dispose at the general support level.
D-	Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L-	Repairable item. Repair, condemnation, and disposal not authorized below depot/Specialized Repair Activity level.
A-	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material).

b. *Federal Stock Number.* Indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

c. *Description* Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc., and is identified in SB 708-42.

d. *Unit of Measure (U/M).* Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This meas-

ure is expressed by a two-character alphabetical abbreviation; e.g., ea, in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

e. *Quantity Incorporated in Unit.* This column indicates the quantity of the item used in the equipment. Subsequent appearances of the same item in the same assembly are indicated by the letters "REF".

f. *15-Day Organizational Maintenance Allowance*

(1) The repair parts indicated by an asterisk in the allowance column represent those authorized for use at the organizational category, and will be requisitioned on as "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Major Army commanders are authorized to approve reduction in the range of support items authorized for use in units within their commands. Recommendations for increase in range of items authorized for use will be forwarded to Commander, US Army Electronics Command, A'ITN: AMSEL-MA-CW, Fort Monmouth, N.J., 07703.

(3) Allowance quantities are indicated in the special tools list section for special tools, TMDE, and other support equipment.

g. *30-Day D, S/GS Maintenance Allowances.*

NOTE

Allowances in GS column are for GS maintenance only.

(1) The repair parts indicated by asterisk entries in separate allowance columns for DS and GS represent those authorized for use at that category of maintenance to be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Allowance quantities are indicated in the special tool lists section for special tools, TMDE, and other support equipment.

h. *1-Year Allowances Per 100 Equipments/Contingency Planning Purposes.* Column intentionally left blank.,

i. *Depot Maintenance Allowance Per 100 Equipment.* This column indicates opposite the first appearance of each item, the total quantity authorized for depot-maintenance of 100 equipments.

j. *Illustration*

(1) Figure number. Indicates the figure number of the illustration on which the item is shown in TM 11-2017.

(2) Item number. Indicates the item number or reference designation used to reference the item in the illustration.

1-4. Special Information

a. Usable on codes are included in column 3. Uncoded items are applicable to all models. Identification of the usable on codes used in this publication are-

Code	Used on
AFI	TS-26/PSM
AFJ	TS-26A/TSM
AFK	TS-26BrPSM

b. The following publication pertains to the equipment and its components:

TM 11-2017 Test Sets TS-26/PSM, TS-26A/TSM, and TS-26BrPSM.

1-5. Location of Repair Parts

a. This manual contains one cross-reference index (sec VII) to be used to locate a repair part when either the Federal stock-number or reference number (manufacturer's part number) is known. The, first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacturer's part numbers) are listed immediately following the last, listed Federal stock number in the index of Federal stock numbers

b. When the Federal stock number or reference number is known, follow the procedures given in (1) and (2) below.

(1) Refer to the index of Federal stock numbers (sec VII), and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable figure and item number or reference designation.

(2) Refer to the repair parts list (sec III and V) and locate the figure number (col 7a-20P,10a-34P) and item number or reference designation (col 7b-20P, 10b--34P) as noted in the FSN index.

c. When the figure and item number or reference designation are known, scrutinize columns 7a and 7b-20P and 10a and 10b-34P, of the repair parts list (sec III and V) until the item is located.

d. When the FSN, reference number-figure number, and item number are not known; scrutinize column 3 of the repair parts list (sec III and V), which is arranged in alphabetical order.

1-6. Abbreviations

Not applicable.

1-7. Reporting of Equipment Publication Improvements

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be sub-

mitted on DA Form 2028 (Recommended Changes to Publications) and forwarded direct to Commander, US Army Electronics Command, AITN: AMSEL-MA-CW, Fort Monmouth, N.J., 07703.

SECTION III

TM 11-6625-223-24P

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REF NUMBER & MFR CODE	USABLE ON CODE	(4) UNIT OF MEAS	(5) QTY INC IN UNIT	(6) 15-DAY ORGANIZATIONAL MAINTENANCE ALW				(7) ILLUS- TRATION	
						(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM NO. OR REFERENCE DESGINATION
PAOZZ	5940-151-4043	CLIP, ELECTRICAL 02..... 60HSRED (76545)	EA	1	*	*	*	*	*	47	02
PAOZZ	5910-260-0461	CLIP, ELECTRICAL 01..... 60HSBLACK (76545)	EA	1	*	*	*	*	*	47	01
PAOZZ	5935-665-4746	CONNECTOR, PLUG ELECTRICAL P2..... 868 (11242)	EA	2	*	*	*	*	*	53	P2
PAOZZ	5935-258-6314	CONNECTOR, PLUG ELECTRICAL P1	EA	2	*	*	*	*	*	53	P1
PAOZZ	9320-408-3055	GASKET NO-REF-DESIG INDIA RUBBER	FT	3	*	*	*	*	*		
PAOZZ	5330-408-3056	X248 (70485) GASKET NO-REF-DESIG INDIA RUBBER	EA	3	*	*	*	*	*		
PAOZZ	5355-162-9097	X308 (70485) KNOB OZA NOTE (WHEN REPLACING CHECK TYPE OF. MTG OF..... ORIGINAL ITEM. IF INTERNAL SCREW TYPE, RESISTOR R6 SHOULD BE REPLACED) 1114 (72653)	EA	1	*	*	*	*	*	40	OZA
PAOZZ	6625-141-5301	LABEL NO-REF-DESIG	EA	1	*	*	*	*	*	2	
PAOZZ	6625-584-3128	SCB7897G (80063) LABEL NO-REF-DESIG	EA	1	*	*	*	*	*	2	
PAOZZ	6625-141-5302	SCB7898G (80063) LABEL NO-REF-DESIG	EA	1	*	*	*	*	*	2	
PAOZZ	6625-324-9420	SCB7896G (80063) STRAP, CARRYING H1	EA	1	*	*	*	*	*	3	H1

SECTION V

TM 11-6625-223-24P

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REF. NUMBER & MFR. CODE	USABLE ON CODE	(4) U N I T O F M E A S	(5) QTY INC IN UNIT	(6) 30-DAY DS MAINT ALLOWANCE			(7) 30-DAY GS MAINT ALLOWANCE			(8) 1-YR ALW PER 100	(9) DEPOT MAINT ALW PER 100	(10) ILLUS- TRATION		
						(A)	(B)	(C)	(A)	(B)	(C)			(A)	(B)	
						1-20	21-50	51-100	1-20	21-50	51-100			EQUIP CNTGY	EQUIP NO.	FIG ITEM NO.
PAOZZ	5940-151-4043	CLIP, ELECTRICAL 02..... 60HSRED (76545)	EA	1	*	*	*	*	*	*	*			3	47	02
PAOZZ	5910-260-0461	CLIP, ELECTRICAL 01..... 60HSBLACK (76545)	EA	1	*	*	*	*	*	*	*			3	47	01
PAOZZ	5935-665-4746	CONNECTOR, PLUG ELECTRICAL P2..... 868 (11242)	EA	2	*	*	*	*	*	*	*			3	53	P2
PAOZZ	5935-258-6314	CONNECTOR, PLUG ELECTRICAL P1..... 869 (11242)	EA	2	*	*	*	*	*	*	*			3	53	P1
PAHZZ	5935-351-3715	CONNECTOR, PLUG, ELECTRICAL P3..... 701 (73899)	EA	1					*	*	*			3	53	P3
PAHZZ	5935-280-2249	CONNECTOR, RECEPTACLE, ELECTRICAL J1.. 105-1 (74970)	EA	10					*	*	*			3	52	J1
PAHZZ	5935-280-2249	CONNECTOR, RECEPTACLE, ELECTRICAL J2.. 105-1 (74970)	EA	REF					*	*	*			3	52	J2
PAHZZ	5935-280-2249	CONNECTOR, RECEPTACLE, ELECTRICAL J3.. 105-1 (74970)	EA	REF					*	*	*			3	52	J3
PAHZZ	5935-280-2249	CONNECTOR, RECEPTACLE, ELECTRICAL J4.. 105-1 (74970)	EA	REF					*	*	*			3	52	J4
PAHZZ	5935-280-2249	CONNECTOR, RECEPTACLE, ELECTRICAL J5.. 105-1 (74970)	EA	REF					*	*	*			3	52	J5
PAHZZ	5935-280-2249	CONNECTOR, RECEPTACLE, ELECTRICAL J6.. 105-1 (74970)	EA	REF					*	*	*			3	52	J6
PAHZZ	5935-280-2249	CONNECTOR, RECEPTACLE, ELECTRICAL J7.. 105-1 (74970)	EA	REF					*	*	*			3	52	J7
PAHZZ	5935-280-2249	CONNECTOR, RECEPTACLE, ELECTRICAL J8.. 105-1 (74970)	EA	REF					*	*	*			3	52	J8
PAHZZ	5935-280-2249	CONNECTOR, RECEPTACLE, ELECTRICAL J9.. 105-1 (74970)	EA	REF					*	*	*			3	52	J9
PAHZZ	5935-280-2249	CONNECTOR, RECEPTACLE, ELECTRICAL J10	EA	REF					*	*	*			3	52	J10
PAHZZ	5935-196-0462	CONNECTOR, RECEPTACLE, ELECTRICAL J11 137 (83330)	EA	2					*	*	*			3	53	J11
PAHZZ	5935-196-0462	CONNECTOR, RECEPTACLE, ELECTRICAL J12 137 (83330)	EA	REF					*	*	*			3	53	J12
PAOZZ	9320-408-3055	GASKET NO-REF-DESIG INDIA RUBBER..... X248 (70485)	FT	3	*	*	*	*	*	*	*			12		
PAOZZ	5330-408-3056	GASKET NO-REF-DESIG INDIA RUBBER..... X308 (70485)	EA	3	*	*	*	*	*	*	*			5		
PAOZZ	5355-162-9097	KNOB OZA NOTE (WHEN REPLACING CHECK.. TYPE OF MTG OF ORIGINAL ITEM. IF INTERNAL SCREW TYPE, RESISTOR R6 SHOULD BE REPLACED) 1114 (72653)	EA	1	*	*	*	*	*	*	*			3	40	OZA
PAOZZ	6625-141-5301	LABEL NO-REF-DESIG..... SCB7897G (80063)	EA	1	*	*	*	*	*	*	*			4	2	
PAOZZ	6625-584-3128	LABEL NO-REF-DESIG..... SCB7898G (80063)	EA	1	*	*	*	*	*	*	*			4	2	
PAOZZ	6625-141-5302	LABEL NO-REF-DESIG..... SCB7896G (80063)	EA	1	*	*	*	*	*	*	*			4	2	
PAHZZ	6625-404-6582	METER, REPLACEMENT M1..... 28 (55026)	EA	1					*	*	*			3	40	M1
PAHZZ	6625-921-5569	METER, REPLACEMENT M1..... 564-3C1 (65092)	EA	1					*	*	*			3	41	M1

SECTION V

TM 11-6625-223-24P

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	USABLE ON CODE	(4) U N I T O F M E A S	(5) QTY INC IN UNIT	(6) 30-DAY DS MAINT ALLOWANCE			(7) 30-DAY GS MAINT ALLOWANCE			(8) 1-YR ALW PER 100	(9) DEPOT MAINT ALW PER	(10) ILLUS- TRATION		
						(A)	(B)	(C)	(A)	(B)	(C)			(A)	(B)	
						1-20	21-50	51-100	1-20	21-50	51-100			EQUIP CNTGY	EQUIP NO.	FIG ITEM NO.
PAHZZ	6625-782-5866	METER, REPLACEMENT M1..... HM3 (88947) AFK	EA	1		*	*	*						3	41	M1
PAHZZ	5905-059-6208	RESISTOR, FIXED WIREWOUND R15..... RB15AE19R00FM (81349) AFJ, AFK	EA	1		*	*	*						3	50	R15
PAHZZ	5905-577-0411	RESISTOR, FIXED, WIREWOUND R12..... RB16AE33R20F (81349) AFJ, AFK	EA	1		*	*	*						3	51	R12
PAHZZ	5905-235-6616	RESISTOR, FIXED, WIREWOUND R7	EA	1		*	*	*						3	48	R7
PAHZZ	5905-059-8033	RESISTOR, FIXED, WIREWOUND R11	EA	1		*	*	*						3	52	R11
PAHZZ	5905-196-2783	RB15AE299R0F (81349) AFJ, AFK	EA	1		*	*	*						3	49	R12
PAHZZ	5905-196-2782	RESISTOR, FIXED, WIREWOUND R12	EA	1		*	*	*						3	48	R13
PAHZZ	5905-235-6615	RESISTOR, FIXED, WIREWOUND R10..... 1290 (55036) AFI	EA	1		*	*	*						3	48	R10
PAHZZ	5905-636-9976	RESISTOR, FIXED, WIREWOUND R14	EA	1		*	*	*						3	52	R14
PAHZZ	5905-190-8887	RESISTOR, FIXED, COMPOSITION R8	EA	1		*	*	*						3	50	R8
PAHZZ	5905-060-3688	RC20GF202J (81349) AFJ, AFK	EA	1		*	*	*						3	51	R10
PAHZZ	5905-196-2781	RESISTOR, FIXED, WIREWOUND R11	EA	1		*	*	*						3	48	R11
PAHZZ	5905-814-8333	1313 (55026) AFI	EA	1		*	*	*						3	49	R4
PAHZZ	5905-556-6685	RESISTOR, FIXED, WIREWOUND R4	EA	1		*	*	*						3	48	R3
PAHZZ	5905-556-6685	RB15AE3330F (81349)	EA	1		*	*	*						3	50	
PAHZZ	5905-250-5413	RESISTOR, FIXED, WIREWOUND R8	EA	1		*	*	*						3	49	R8
PAHZZ	5905-524-0066	0-006917 (55026) AFI	EA	1		*	*	*						3	49	R5
PAHZZ	5905-577-0408	RESISTOR, FIXED, WIREWOUND R5..... RB15AE27001F (81349) AFI, AFK	EA	1		*	*	*						3	50	R5
PAHZZ	5905-577-0409	RESISTOR, FIXED, WIREWOUND R9	EA	1		*	*	*						3	50	R9
PAHZZ	5905-196-2780	RB15AE29881F (81349) AFJ, AFK	EA	1		*	*	*						3	49	R9
PAHZZ	5905-815-3369	RESISTOR, FIXED, WIREWOUND R9	EA	1		*	*	*						3	52	R13
PAHZZ	5905-502-3499	RB16AE27002F (81349) AFI	EA	1		*	*	*						3	48	R2
PAHZZ	5905-612-4534	RESISTOR, FIXED, WIREWOUND R1	EA	1		*	*	*						3	48	R1
PAHZZ	5905-577-0412	RB16AE30002F (81349)	EA	1		*	*	*						3	50	R15
PAHZZ	5905-577-0412	RESISTOR, FIXED, WIREWOUND R15	EA	1		*	*	*						3	48	R7
PAHZZ	5905-583-7586	RB16AE31502F (81349) AFJ	EA	REF		*	*	*						3	52	R6
		RB16AE31502F (81349) AFJ	EA	1		*	*	*								
		RB16AE31502F (81349) AFJ	EA	REF		*	*	*								
		BQ6646-10K (22331) AFJ, AFK	EA	1		*	*	*								

SECTION V

TM 11-6625-223-24P

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REF. NUMBER & MFR. CODE	USABLE ON CODE	(4) U N I T O F M E A S	(5) QTY INC I N U N I T	(6) 30-DAY DS MAINT ALLOWANCE			(7) 30-DAY GS MAINT ALLOWANCE			(8) 1-YR ALW PER 100	(9) DEPOT MAINT ALW PER	(10) ILLUS- TRATION		
						(A)	(B)	(C)	(A)	(B)	(C)			(A)	(B)	
						1-20	21-50	51-100	1-20	21-50	51-100			CNTGY	EQUIP	FIG NO.
PAHZZ	5905-284-3442	RESISTOR, VARIABLE R6	EA	1		*	*	*						3	48	R6
PAOZZ	6625-324-9420	C15MR (90201) AFI	EA	1	*	*	*	*	*	*	*			2	3	H1
PAHZZ	5930-669-7317	STRAP, CARRYING H1	SC7893 (80063)	EA	2				*	*	*			5	49	S1
PAHZZ	5930-669-7317	SWITCH, TOGGLE S1	MS35058-15 (81349)	EA	REF				*	*	*			5	52	S2
PAHZZ	5930-255-5764	SWITCH, TOGGLE S2	MS35058-15 (81349)	EA	1				*	*	*			5	53	S3
PAHZZ	6145-160-5027	SWITCH, TOGGLE S3	CH8282K14 (15605)	FT	6				*	*	*			4	8	
PAHZZ	6145-164-6952	WIRE, ELECTRICAL WS-16/U NO REF DESIG ...	BLACK STRANDED COPPER NO 18 AWG.	FT	6				*	*	*			4	8	
		WS16U *0058)	RED COPPER STANDARD NO 18 AWG.													
		WS17U (80058)														

**INDEX - FEDERAL STOCK NUMBER AND REFERENCE-NUMBER
CROSS REFERENCE TO FIGURE AND ITEM NUMBER**

STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5330-408-3056			5930-255-5764	53	S3
5355-162-9097	40	OZA	5930-669-7317	49	S1
5905-059-6208	50	R15	5933-669-7317	52	S2
5905-059-8033	52	R11	5935-196-0462	53	J11
5905-060-3688	51	R10	5935-196-0462	53	J12
5905-190-8807	50	R8	5935-258-6314	53	P1
5905-196-2780	49	R9	5935-280-2249	52	J1
5905-196-2781	48	R11	5935-280-2249	52	J2
5905-196-2782	49	R13	5935-280-2249	52	J3
5905-196-2783	49	R12	5935-280-2249	52	J4
5905-235-6615	49	R10	5935-280-2249	52	J5
5905-235-6616	48	R7	5935-280-2249	52	J6
5905-250-5413	49	R8	5935-280-2249	52	J7
5905-284-3442	48	R6	5935-233-2249	52	J8
5905-502-3499	48	R2	5935-280-2249	52	J9
5905-524-0066	49	R5	5935-280-2249	52	J10
5905-556-6685	49	R3	5935-351-3715	53	P3
5905-556-6685	50		5935-665-4746	53	P2
5905-577-0408	50	R5	5940-151-4043	47	O2
5905-577-0409	50	R9	6145-160-5027	8	
5905-577-0411	51	R12	6145-164-6952	8	
5905-577-0412	48	R7	6625-141-5301	2	
5905-577-0412	50	R15	6625-141-5302	2	
5905-583-7586	52	R6	6625-324-9420	3	H1
5905-612-4534	48	R1	6625-404-6582	40	M1
5905-636-9976	52	R14	6625-584-3128	2	
5905-814-8333	49	R4	6625-782-5866	41	M1
5905-815-3369	52	R13	6625-921-5569	41	M1
5910-260-0461	47	O1	9320-403-3055		

REFERENCE NO.	MFR CODE	FIG. NO.	ITEM NO.	REFERENCE NO.	MFR CODE	FIG. NO.	ITEM. NO
BQ6646-10K	22331	52	R6	X308	70485		
CH8282K14	15605	53	S3	0-006854	55026	48	R7
C15MR	90201	48	R6	0-006915	55026	49	R9
HM3	88947	41	M1	0-006915	55026	49	R5
M535058-15	81349	49	S1	0-006917	55026	49	R5
MS35058-15	81349	52	S2	0-008098	55026	49	R13
RB15AE19R03F	81349	50	R15	105-1	74970	52	J1
RB15AE27001F	81349	48	R3	105-1	74970	52	J2
RB15AE27001F	81349	50		105-1	74970	52	J3
RB15AE29241F	81349	50	R5	105-1	74970	52	J4
RB15AE29880F	81349	51	R10	105-1	74970	52	J5
RB15AE29881F	81349	50	R9	105-1	74970	52	J6
RB15AE299ROF	81349	52	R11	105-1	74970	52	J7
RB15AF33330F	81349	49	R4	105-1	74970	52	J8
RB15AE34351F	81349	52	R13	105-1	74970	52	J9
RB15AE500ROF	81349	52	R14	105-1	74970	52	J10
RB16AF27002F	81349	46	R2	1114	72653	40	OZA
RB16AF30002F	81349	48	R1	1246	55026	49	R12
RB16AE31502F	81-349	48	R7	1290	55326	48	R10
RB16AE31502F	81349	50	R15	1313	55026	48	R11
RB16AE33R20F	81349	51	R12	137	83330	53	J11
RC20GF202J	81349	50	R8	137	83330	53	J12
SCB7896G	80063	2		28	55026	40	M1
SCB7897G	80063	2		564-3C1	65092	41	M1
SCB7898G	80063	2		60HSBLACK	76545	47	01
SC7893	83003	3	H1	60HSRED	76545	47	02
WS16U	80058	8		701	73899	53	P3
WS17U	80058	8		868	11242	53	P2
X248	70485			869	11242	53	P1

By Order of the Secretary of the Army:

CREIGHTON W. ABRAMS
General, United States Army
Chief of Staff

Official:

VERNE L. BOWERS
Major General United States Army
The Adjutant General

Distribution:

Active Army:

USASA (2)	Instl (2) except
CNGB (1)	Fort Gordon (10)
ACSC-E (2)	Fort Huachuca (10)
USAARENBD (2)	Fort Carson (10)
USAMB (10)	WSMR (2)
AMC (1)	Army Dep (2) except
CONARC (5)	LBAD (14)
ARADCOM (2)	SAAD (30)
ARADCOM Rgn (2)	TOAD (14)
OS Maj Comd (4)	LEAD (7)
LOGCOMDS (5)	ATAD (10)
MICOM (2)	USA Dep (2)
TECOM (2)	Sig Sec USA Dep (2)
USASTRATCOM (4)	Sig Dep (5)
HISA (ECOM) (18)	Sig FLDMS (1)
MDW (1)	USAERDAA (1)
Armies (2)	UJSAERDAW (1)
Corps (2)	MAAG (1)
Svc Colleges (2)	USARMIS (1)
USASESS (5)	Ft. Richardson (ECOM Ofc) (2)
USAADS (2)	WRAMC (1)
USAFAS (2)	Units org under fol TOE: (1 copy each)
USAARMS (2)	11-158
USAIS (2)	29-134
USAES (2)	29-136
USAINTS (3)	
USACDCEC (5)	

NG: None.

USAR: None.

For explanation of abbreviations used, see AR 310-50.

* U.S. GOVERNMENT PRINTING OFFICE: 1992-311-831/60052

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



SOMETHING WRONG WITH THIS PUBLICATION?

**THEN. . JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM, CAREFULLY TEAR IT
OUT, FOLD IT AND DROP IT
IN THE MAIL.**

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE BENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT...PIN-POINT WHERE IT IS

**IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:**

1

PARA
GRAPH

FIGUR
NO

**TABLE
NO.**

INTER ALIOLANG PARROQUETINE

PRINTER NAME, GRADE OR TITLE, AND THE REMOTE NUMBER

SIGN HERE

DA FORM 1 JUL 79 2028-2

**PREVIOUS EDITIONS
• ARE OBSOLETE.**

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR
RECOMMENDATION MAKE A CARBON COPY OF THIS
AND GIVE IT TO YOUR HEADQUARTERS.

PIN # 019461-000