

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

---

ORGANIZATIONAL MAINTENANCE REPAIR PARTS  
AND SPECIAL TOOLS LISTS  
SIGNAL GENERATORS AN/URM-49 (FSN 6625-669-5131),  
AN/URM-49A (FSN 6625-553-7386), AN/URM-49B,  
AND AN/URM-49C

---

Headquarters, Department of the Army, Washington, D.C.  
22 November 1974

---

*Current as of 17 September 1974*

		Paragraph	Page
SECTION	I.	INTRODUCTION	
		Scope .....	1-1 2
		General .....	1-2 2
		Explanation of columns .....	1-3 2
		Special information.....	1-4 4
		Location of repair parts .....	1-5 4
		Abbreviations (Not applicable) .....	1-6 4
		Reporting of equipment publication improvements.....	1-7 4
	II.	PRESCRIBED LOAD ALLOWANCE (Not applicable)	
	III.	REPAIR PARTS LIST .....	6
	IV.	SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT .....	8
	V.	INDEX -FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS- REFERENCE TO FIGURE AND ITEM NUMBER .....	9

---

\*This manual supersedes TM 11-6625-280-20P, 19 July 1961, including all changes.

**SECTION I  
INTRODUCTION**

**1-1. Scope**

This manual lists repair parts and special tools required for the performance of organizational maintenance of the AN/URM49, AN/URM49A, AN/URM49B, and AN/URM-49C. The PCCN for the equipment is GTEAFI for all models.

**1-2. General**

This repair parts and special tools list is divided into the following sections:

- a. *Prescribed Load Allowance (PLA)* - Section II. Not applicable.
- b. *Repair Parts List -Section III.* A list of repair parts authorized for the performance of maintenance at the organizational level. This repair parts list is arranged in alphabetical order.
- c. *Special Tools, Test and Support Equipment-Section IV.* A list of special tools, test and support equipment authorized for the performance of maintenance at the organizational level.
- d. *Index. -Federal Stock Number and Reference .Number Cross-Reference to Figure and Item Number -Section V.* A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphanumeric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

**1-3. Explanation of Columns**

The following provides an explanation of columns in the tabular lists -

a. *Source, Maintenance, and Recoverability Codes (SMR).*

(1) *Source code.* Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are -

<i>Code</i>	<i>Explanation</i>
PA -	Item procured and stocked for anticipated or known usage.
PB -	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.
PC -	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD -	Support item, excluding support equipment, procured for initial issue or outfitting and

Code	Explanation
	stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE -	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF -	Support equipment which will not be stocked but which will be centrally procured on demand.
PG -	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD -	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF -	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.
KB -	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO -	Item to be manufactured or fabricated at organizational level.
MF -	Item to be manufactured or fabricated at direct support maintenance level.
MH -	Item to be manufactured or fabricated at general support maintenance level.
MD -	Item to be manufactured or fabricated at depot maintenance level.
AO -	Item to be assembled at organizational level.
AF -	Item to be assembled at direct support maintenance level.
AH -	Item to be assembled at general support maintenance level.
AD -	Item to be assembled at depot maintenance level.
XA -	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB -	Item is not procured or stocked. If not available through salvage, requisition.
XC -	Installation drawing, diagram instruction

<i>Code</i>	<i>Explanation</i>
	sheet, field service drawing, that is identified by manufacturers' part number.
XD -	Support items can be requisitioned with justification.

**NOTE**

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code Format as follows -

(a) *Use (third position).* The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position indicates one of the following levels of maintenance.

<i>Code</i>	<i>Application/Explanation</i>
O -	Support item is removed, replaced, used at the organizational level of maintenance.

**NOTE**

A code "C" may be used in this position to denote crew or operator maintenance performed within organizational maintenance.

- F - Support item is removed, replaced, used at the direct support maintenance level.
- H - Support item is removed, replaced, used at the general support maintenance.
- D - Support items that are removed, replaced, used at depot only.

(b) *Repair (fourth position).* The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used a dash (-) sign is entered. For multi-service equipment/systems or when a code is entered, this position will contain one of the following maintenance codes as assigned by the service(s) that require the code -

<i>Code</i>	<i>Application/Explanation</i>
O -	The lowest maintenance level capable of complete repair of the support item is the organizational level.
F -	The lowest maintenance level capable of complete repair of the support item is direct support.

<i>Code</i>	<i>Application/Explanation</i>
H -	The lowest maintenance level capable of complete repair of the support item is general support.
D -	The lowest maintenance level capable of complete repair of the support item is the depot level.
L -	Repair restricted to designated Specialized Repair Activity.
Z -	Non-repairable. No repair is authorized.
B -	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the uniform SMR Code Format as follows -

<i>Code</i>	<i>Explanation</i>
Z -	Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in the first digit of the maintenance code.
O -	Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
F -	Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.
H -	Repairable item. When uneconomically repairable, condemn and dispose at the general support level.
D -	Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L -	Repairable item. Repair, condemnation, and disposal not authorized below depot/ Specialized Repair Activity level.
A -	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material).

b. *Federal Stock Number.* Indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

c. *Description.* Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification to designate

manufacturer or distributor or Government agency, etc., and is identified in SB 708-42.

d. *Unit of Measure (U/M)*. Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation; e.g., ea, in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

e. *Quantity Incorporated in Unit*. This column indicates the quantity of the item used in the equipment. Subsequent appearances of the same item in the same assembly are indicated by the letters "REF".

f. *15-Day Organizational Maintenance Allowance*.

(1) The repair parts indicated by an asterisk in the allowance column represent those authorized for use at the organizational category, and will be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Major Army commanders are authorized to approve reduction in the range of support items authorized for use in units within their commands. Recommendations for increase in range of items authorized for use will be forwarded to Commander, US Army Electronics Command, ATTN: AMSEL-MA-TMDE, Fort Monmouth, NJ 07703. Any changes approved will be reflected in a revision to the RPSTL.

(3) Allowance quantities are indicated in the special tools list section for special tools, TMDE, and other equipment.

g. *Illustration*. This column is divided as follows:

(1) *Figure number*. Indicates the figure number of the illustration on which the item is shown in TM 11-6625280-15.

(2) *Item number*. Indicates the item number or reference designation used to reference the item in the illustration.

**1-4. Special Information**

a. Usable on codes are included in column 3. Uncoded items are applicable to all models. Identification of the usable on codes used in this publication are -

<i>Code</i>	<i>Used on</i>
BBA	AN/URM-49
BBB	AN/URM49A
BBC	AN/URM-49B
BBD	AN/URM49C

b. The basis of issue for authorized special tools, test and support equipment is the number of end

items of equipment supported and the number of maintenance personnel allocated to perform the required maintenance operations.

c. The following publication pertains to the equipment and its components:

TM 11-6625280-15 Organizational, Field and Depot Maintenance Manual: Signal Generators AN/URM-49, AN/URM-49A, AN/URM-49B, and AN/URM49C.

**1-5. Location of Repair Parts**

a. This manual contains one cross-reference index (sec V) to be used to locate a repair part when either the Federal stock number or reference number (manufacturer's part number) is known. The first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacturer's part numbers) are listed immediately following the last listed Federal stock number in the index of Federal stock numbers.

b. When the Federal stock number or reference number is known, follow the procedures given in (1) and (2) below.

(1) Refer to the index of Federal stock numbers (sec V) and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable figure and item number or reference designation.

(2) Refer to the repair parts list (sec III) and locate the figure number (col 7a) and item number or reference designation (col 7b) as noted in the FSN index.

c. When the figure and item number or reference designation are known, scrutinize columns 7a and 7b of the repair parts list (sec III) until the item is located.

d. When the FSN, reference number, figure number, item number and reference designation are not known, scrutinize column 3 of the repair parts list (sec III), which is arranged in alphabetical order.

**1-6. Abbreviations**

Not applicable.

**1-7. Reporting of Equipment Publication Improvements**

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forwarded direct to Commander, US Army Electronics Command, ATTN: AMSEL-MA-TMDE, Monmouth, NJ., 07703.

(Next printed page is 6)

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION  REF NUMBER & MFR CODE	(4) UNIT OF MEAS	(5) QTY INC IN UNIT	(6) 15-DAY ORGANIZATIONAL MAINTENANCE ALW				(7) ILLUS- TRATION	
					(A)	(B)	(C)	(D)	(A)	(B)
					1-5	6-20	21-50	51-100	FIG. NO.	ITEM NO.
PAOZZ	6145-284-0579	CABLE, POWER, ELECTRICAL W101 ..... CO-03MGF8-18J0330 (81349)	FT	8	*	*	*	*	1-1	W101
XDOZZ		CONNECTOR, ADAPTER, ELECTRICAL E208..... UG201AU (81349)	EA	3	*	*	*	*	1-1	E208
XDOZZ		CONNECTOR, ADAPTER, ELECTRICAL E209..... UG201AU (81349)	EA	REF	*	*	*	*	1-1	E209
XDOZZ		CONNECTOR, ADAPTER, ELECTRICAL E210..... UG201AU (81349)	EA	REF	*	*	*	*	1-1	E210
XDOZZ		CONNECTOR, ADAPTER, ELECTRICAL E211..... UG255U (81349)	EA	3	*	*	*	*	1-1	E211
XDOZZ		CONNECTOR, ADAPTER, ELECTRICAL E212..... UG255U (81349)	EA	REF	*	*	*	*	1-1	E212
XDOZZ		CONNECTOR, ADAPTER ELECTRICAL E213..... UG255U (81349)	EA	REF	*	*	*	*	1-1	E213
PAOZZ	5935-149-3534	CONNECTOR, ADAPTER, ELECTRICAL E205..... UG273U (81349)	EA	3	*	*	*	*	1-1	E205
PAOZZ	5935-149-3534	CONNECTOR, ADAPTER, ELECTRICAL E206..... UG273U (81349)	EA	REF	*	*	*	*	1-1	E206
PAOZZ	5935-149-3534	CONNECTOR, ADAPTER ELECTRICAL E207..... UG273U (81349)	EA	REF	*	*	*	*	1-1	E213
XDOZZ		CONNECTOR, PLUG, ELECTRICAL P101..... 7084 (74545).....BBA	EA	1	*	*	*	*		P101
PAOZZ	5935-149-4013	CONNECTOR, PLUG, ELECTRICAL P102..... 7054 (74545).....BBA	EA	1	*	*	*	*		P102
PAOZZ	5935-539-2650	CONNECTOR, PLUG, ELECTRICAL NO-REF-DESIG AN3106A10SL35 (88044).....BBB	EA	1	*	*	*	*		
PAOZZ	5935-636-7145	CONNECTOR, PLUG, ELECTRICAL NO-REF-DESIGN UP121m (81349).....BBB	EA	1	*	*	*	*		
PAOZZ	5960-624-4718	ELECTRON TUBE V106..... OB2WA (81349)	EA	2	*	*	*	*	5-1	V106
PAOZZ	5960-624-4718	ELECTRON TUBE V107..... OB2WA (81349)	EA	REF	*	*	*	*	5-1	V107
PAOZZ	5960-166-7686	ELECTRON TUBE V201..... 2036 (81349)	EA	1	*	*	*	*	7-10	V201
XDOZZ		ELECTRON TUBE V102..... 5R4WGA (81349)	EA	1	*	*	*	*	5-1	V102
PAOZZ	5960-816-4654	ELECTRON TUBE V101..... 5V3 (81349)	EA	1	*	*	*	*	5-1	V101
PAOZZ	5960-188-8565	ELECTRON TUBE V104..... 6AG7Y (81349)	EA	2	*	*	*	*	5-1	V104
PAOZZ	5960-188-8565	ELECTRON TUBE V306..... 6AG7Y (81349)	EA	REF	*	*	*	*	5-1	V306
PAOZZ	5960-188-3545	ELECTRON TUBE V105..... 6AK5 (81349)	EA	1	*	*	*	*	5-1	V105
PAOZZ	5960-188-3967	ELECTRON TUBE V103..... 6J6 (81349)	EA	4	*	*	*	*	5-1	V103
PAOZZ	5960-188-3967	ELECTRON TUBE V303..... 6J6 (81349)	EA	REF	*	*	*	*	5-1	V303
PAOZZ	5960-188-3967	ELECTRON TUBE V305..... 6J6 (81349)	EA	REF	*	*	*	*	5-1	V305
PAOZZ	5960-188-3967	ELECTRON TUBE V307..... 6J6 (81349)	EA	REF	*	*	*	*	5-1	V307
PAOZZ	5960-262-0167	ELECTRON TUBE V302..... 12AT7WA (81349)	EA	2	*	*	*	*	5-1	V302
PAOZZ	5960-262-0167	ELECTRON TUBE V304..... 12AT7WA (81349)	EA	REF	*	*	*	*	5-1	V304
PAOZZ	5960-166-7664	ELECTRON TUBE V301..... 12AZ7 (81349)	EA	1	*	*	*	*	5-1	V301
PAOZZ	5355-644-2206	KNOB NO-REF-DESIG 1 5/8 IN DIA X 3/4 IN H..... S309-64BBB (75376).....BBA	EA	1	*	*	*	*		
XDOZZ		KNOB E202 1/58 IN OD X 1/2 IN THK..... A1367018 (35225)	EA	1	*	*	*	*	8-15	E202
XDOZZ		KNOB NO-REF-DESIG 1 5/8 IN DIA X 1 1/4 IN THK..... S309-61BBBF18898B (75376)	EA	1	*	*	*	*		
PAOZZ	5355-160-5964	KNOB E311 WITH POINTER..... S308-64BB40269 (75376)	EA	2	*	*	*	*	8-15	E311
PAOZZ	5355-160-5964	KNOB E312 WITH POINTER..... S308-64BB40269 (75376).....BBA	EA	REF	*	*	*	*	8-15	E312
XDOZZ		KNOB E309 1 1/2 IN OD X 0.705 IN THK..... 6400 (80375).....BBA	EA	2	*	*	*	*	8-15	E309
XDOZZ		KNOB E310 1 1/2 IN OD X 0.705 IN THK..... 6400 (80375)	EA	REF	*	*	*	*	8-15	E310
PAOZZ	5355-667-9217	KNOB E201 1 1/2 IN OD X 0.023 IN THK..... A1410015 (35225)	EA	1	*	*	*	*	4-5	E201
PAOZZ	5355-644-2206	KNOB NO-REF-DESIG ADJUSTS ATTENUATION OF RF..... SIGNAL 4100 (72512).....BBB	EA	1	*	*	*	*		
PAOZZ	5355-667-6013	KNOB NO-REF-DESIG DIAL LOCK KNOB..... M45000120 (35225)	EA	2	*	*	*	*		

SECTION III

\*TM 11-6625-280-20P

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION  REF NUMBER & MFR CODE	(4) UNIT OF MEAS  USABLE ON CODE	(5) QTY INC IN UNIT	(6) 15-DAY ORGANIZATIONAL MAINTENANCE ALW				(7) ILLUS- TRATION	
					(A)	(B)	(C)	(D)	(A)	(B)
					1-5	6-20	21-50	51-100	FIG. NO.	ITEM NO.
PAOZZ	5355-284-5164	KNOW NO-REF-DESIG DIAL CONTROL KNOB ..... 4100B (72512) .....BBB	EA	3	*	*	*	*		
PAOZZ	5355-511-4323	KNOB NO-REF-DESIG FREQ CONTROL KNOB ..... 4100B135 (72512) .....BBB	EA	2	*	*	*	*		
XDOZZ		LENS, INDICATOR LIGHT NO-REF-DESIG RED ..... 83-111 (72619)	EA	1	*	*	*	*		
PAOZZ	6210-299-5773	LENS, INDICATOR LIGHT NO-REF-DESIG WHITE ..... 83-177 (72619)	EA	1	*	*	*	*		
XDOZZ		RETAINER, ELECTRON TUBE 0203 ..... 756-3280 (46859)	EA	1	*	*	*	*	4-18	0203
PAOZZ	5960-151-7562	RETAINER, ELECTRON TUBE 0206 ..... 926B (74370)	EA	1	*	*	*	*	4-18	0206
PAOZZ	5960-249-4973	RETAINER, ELECTRON TUBE 0101 ..... 926C (74370)	EA	3	*	*	*	*		0101
PAOZZ	5960-249-4973	RETAINER, ELECTRON TUBE 0103 ..... 926C (74370)	EA	REF	*	*	*	*		0103
PAOZZ	5960-249-4973	RETAINER, ELECTRON TUBE 0105 ..... 926C (74370)	EA	REF	*	*	*	*		0105
XDOZZ		SHIELD, ELECTRON TUBE E106 FOR 6AG7Y ..... A1367324 (3525)	EA	2	*	*	*	*		E106
XDOZZ		SHIELD, ELECTRON TUBE E113 FOR 6AG7Y ..... A1367324 (35225)	EA	REF	*	*	*	*		E113
XDOZZ		SHIELD, ELECTRON TUBE E314 ..... TS102U03 (81349)	EA	3	*	*	*	*		E314
XDOZZ		SHIELD, ELECTRON TUBE E315 ..... TS102U03 (81349)	EA	REF	*	*	*	*		E315
XDOZZ		SHIELD, ELECTRON TUBE E317 ..... TS102U03 (81349)	EA	REF	*	*	*	*		E317
XDOZZ		SHIELD, ELECTRON TUBE E104 ..... TS102U02 (81349)	EA	4	*	*	*	*		E104
XDOZZ		SHIELD, ELECTRON TUBE E316 ..... TS102U02 (81349)	EA	REF	*	*	*	*		E316
XDOZZ		SHIELD, ELECTRON TUBE E318 ..... TS102U02 (81349)	EA	REF	*	*	*	*		E318
XDOZZ		SHIELD, ELECTRON TUBE E319 ..... TS102U02 (81349)	EA	REF	*	*	*	*		E319
PAOZZ	5960-264-3004	SHIELD, ELECTRON TUBE NO-REF-DESIG ..... TS103U02 (81349)	EA	3	*	*	*	*		
PAOZZ	5960-686-811	SHIELD, ELECTRON TUBE E105 ..... TS102U01 (81349)	EA	1	*	*	*	*		E105

SECTION IV

\*TM 11-6625-280-20P

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION  REF NUMBER & MFR CODE	(4) UNIT OF MEAS  USABLE ON CODE	(5) QTY INC IN UNIT	(6) 15-DAY ORGANIZATIONAL MAINTENANCE ALW				(7) ILLUS- TRATION	
					(A) 1-5	(B) 6-20	(C) 21-50	(D) 51-100	(A) FIG. NO.	(B) ITEM NO.
XDOZZ		WRENCH, SPANNER NO-REF-DESIG 1 9/16 IN W ..... OPENING 1410155 (35225).....BBA	EA	1						
XDOZZ		WRENCH, SPANNER NO-REF-DESIGN ..... A109-00276 (12065)	EA	1						
<b>8</b>										

**SECTION V**

**INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER \*TM 11-6625-280-20P  
CROSS-REFERENCE TO FIGURE AND ITEM NUMBER**

**NOTE: LATEST FEDERAL STOCK NUMBER ASSIGNMENTS ARE INCLUDED AT END OF INDEX**

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
			5960-188-3967	5-1	V103
			5960-188-3967	5-1	V303
5355-160-5964	8-15	E311	5960-188-3967	5-1	V305
5355-160-5964	8-15	E312	5960-188-3967	5-1	V307
			5960-188-8565	5-1	V104
5355-284-5164			5960-188-8565	5-1	V306
5355-511-4323			5960-249-4973		0101
			5960-249-4973		0103
			5960-249-4973		0105
5355-667-6013					
5355-667-9217	4-5	E201			
			5960-262-0167	5-1	VJ02
			5960-262-0167	5-1	V304
5935-149-3534	1-1	E205	5960-264-3004		
5935-149-3534	1-1	E206			
5935-149-3534	1-1	E207			
5935-149-4013		P102			
5935-539-2650			5960-624-4718	5-1	V106
5935-636-7145			5960-624-4718	5-1	V107
5960-151-7562	4-18	0206	5960-816-4654	5-1	V107
5960-166-7664	5-1	V301	6145-2840579	1-1	W101
5960-166-7686	7-10	V201			
5960-188-3545	5-1	V105	6210-299-5773		

  

REFERENCE NO.	MFR CODE	FIG. NO.	ITEM NO.	REFERENCE NO.	MFR CODE	FIG. NO.	ITEM NO.
AN3106A10SL35	88044			OB2WA	81349	5-1	V106
A109-00276	12065			OB2WA	81349	5-1	V107
A1367018	35225	8-15	E202	12AT7WA	81349	5-1	V302
A1367324	35225		E106	12AT7WA	81349	5-1	V304
A1367324	35225		E113	12AX7	81349	5-1	V301
A1410015	35225	4-5	E201	1410155	35225		
CO-03MGF8-18J0330	81349	1-1	W101	2C36	81349	7-10	V201
M45000120	35225			4100	72512		
S308-64B840269	75376	8-15	E311	41008	72512		
S308-648840269	75376	8-15	E312	41008135	72512		
S309-618BBF1889B	75376			5R4WGA	81349	5-1	V102
S309-64888	75376			5V3	81349	5-1	V101
TS102U01	81349		E105	6AG7Y	81349	5-1	V104
TS102U02	81349		E104	6AG7Y	81349	5-1	V306
TS102U02	81349		E316	6AK5	81349	5-1	V105
TS102U02	81349		E318	6J6	81349	5-1	V103
TS102U02	81349		E319	6J6	81349	5-1	V303
TS102U03	81349		E314	6J6	81349	5-1	V305
TS102U03	81349		E315	6J6	81349	5-1	V307
TS102U03	81349		E317	6400	80375	8-15	E309
TS103U02	81349			6400	80375	8-15	E310
UG201AU	81349	1-1	E208	7057	74545		P102
UG201AU	81349	1-1	E209	7084	74545		P101
UG201AU	81349	1-1	E210	756-3280	46859	4-18	0203
UG255U	81349	1-1	E211	83-111	72619		
UG255U	81349	1-1	E212	83-177	72619		
UG255U	81349	1-1	E213	9268	74370	4-18	0206
UG273U	81349	1-1	E205	926C	74370		0101
UG273U	81349	1-1	E206	926C	74370		0103
UG273U	81349	1-1	E207	926C	74370		0105
UP121M	81349						

**LATEST FEDERAL STOCK NUMBER ASSIGNMENTS**

STOCK NUMBER	FIGURE NO.	ITEM NO.
5355-644-2206		
5960-686-8119		E105



By Order of the Secretary of the Army:

FRED C. WEYAND  
General, United States Army  
Chief of Staff

Official:

VERNE L. BOWERS  
Major General, United States Army  
The Adjutant General

Distribution:

Active Army:

USASA (2)	USAADS (2)
CNGB (1)	USAFAS (2)
ACSC-E (2)	USAARMS (2)
Dir of Trans (1)	USAIS (2)
COE (1)	USAES (2)
TSG (1)	AD (1) except
USAARENBD (1)	SAAD (30)
USAMB (10)	LBAD (14)
AMC (1)	TOAD (14)
MICOM (2)	ATAD (10)
TECOM (2)	USA Dep (2)
HISA (Ft Monmouth) (18)	Sig Sec USA Dep (2)
USACC (4)	Sig Dep (2)
TRADOC (2)	ATS (1)
ARADCOM (2)	MAAG (1)
ARADCOM Rgn (2)	WRAMC (1)
OS Maj Comd (4)	USARMIS (1)
LOGCOMD (3)	USAERDAA (1)
MDW (1)	USAERDAW (1)
Armies (2)	Sig FLDMS (1)
Corps (2)	Ft Richardson (ECOM Ofc) (2)
Ft Gordon (10)	Units org under fol TOE: 1 ea.
Ft Huachuca (10)	11-16
Ft Carson (5)	11-97
WSMR (1)	11-98
Svc Colleges (1)	11-117
USASESS (5)	11-500 (AA-AC)
USAINTCS (3)	32-57

ARNG & USAR: None.

For explanation of abbreviations used, see AR 310-50.

☆U.S. GOVERNMENT PRINTING OFFICE: 1974-665135/308

GPO 936-789

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

# SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT... PIN-POINT WHERE IT IS

PAGE NO.

PARA-GRAPH

FIGURE NO.

TABLE NO.

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 2028-2  
1 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

