# TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT, AND
GENERAL SUPPORT MAINTENANCE REPAIR
PARTS AND SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR
PARTS AND SPECIAL TOOLS)
FOR
WATTMETER ME-497/U
(NSN 6625-01-064-3555)

# ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

**FOR** 

# **WATTMETER ME-497/U**

(NSN 6625-01-064-3555)

**Current as of 15 October 1982** 

### REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DRSEL-ME-MP, Fort Monmouth, NJ 07703.

In either case, a reply will be furnished direct to you.

### **Table of Contents**

			Page	Figure
a			1	riguic
S ECTION	1.	Introduction	1	
	II.	Repair Parts List	5	
GROUP	00	Wattmeter ME-497/U	5	1
	01	Meter Housing	7	2
		0101 Switch Assembly	9	3
	02	Radiator Assembly	11	4
		Radiator Pre-Assembly	13	5
	03	Block Assembly, Voltmeter (See Group 00 for parts)		
SECTION	III.	Special Tools List (Nonapplicable)		
	IV.	National Stock Number and Part Number Index Index	14	

# SECTION I

# INTRODUCTION

#### 1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the ME-497/U. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

#### 2. General

This Repair Parts and Special Tools List is divided into the following sections:

- a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.
  - b. Section III. Special Tools List. Not applicable.
- c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

### 3. Explanation of Columns

- a. Illustration. This column is divided as follows:
- (1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.
- (2) *Item number.* The number used to identify item called out in the illustration.
- b. Source, Maintenance, and Recoverability (SMR) Codes.
- (1) Source code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code Definition

- PA-Item procured and stocked for anticipated or known usage.
- XA-Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
- XB-Item is not procured or stocked. If not available through salvage, requisition.
- XD-A support item that is not stocked. When required, item will be procured through normal supply channels.

#### **NOTE**

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

- (2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:
- (a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code Application/Explanation

- H-Support item is removed, replaced, used at the general support level.
- (b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

  \*\*Code\*\* Application/Explanation\*\*
- H-The lowest maintenance level capable of complete repair of the support item is the general support level.
- Z—Nonreparable. No repair is authorized.
  - (3) Recoverability code. Recoverability codes

1

are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability

codes

Definition

- Z—Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
- H-Reparable item. When uneconomically reparable, condemn and dispose at the general support level.
- c. National Stock Number. Indicates the National stock number assigned to the item and will be used for requisitioning purposes.
- d. Federal Supply Code for Manufacturer (FSCM). The FSCM is a 5-digit numeric code listed in SB 708-41/42 which is used to identify the manufacturer, distributor, or Government agency, etc.
- e. Part Number. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

#### NOTE

When a stock numbered item is requisitioned the repair part received may have a different part number than the part being replaced.

- f. Description. Indicates the Federal item name and, if required, a minimum description to identify the item.
- g. *Unit of Measure (U/M)*. Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.
- h. Quantity Incorporated in Unit. Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column in lieu of a quantity indicates that no specific quantity is applicable, (e.g., shims, spacers, etc).

# 4. Special Information

a. The following publication pertains to the ME-497/U and its components:

TM 11-6625-3018-14,-Wattmeter ME-497/U

b. National stock numbers (NSN'S) that are missing from P source coded items have been applied for and will be added to this TM by future change/revision when they are entered in the Army Master Data File (AMDF). Until the NSN's are established and published, submit exception requisitions to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DRSEL-MM, Fort Monmouth, NJ 07703 for the part required to support your equipment.

# 5. How to Locate Repair Parts

- a. When National stock number or part number is unknown.
- (1) *First.* Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.
- (2) Second. Find the illustration covering the functional group to which the item belongs.
- (3) Third. Identify the item on the illustration and note the illustration figure and item number of the item.
- (4) Fourth. Using the Repair Parts Listing, find the figure and item number noted on the illustration.
- *b.* When National stock number or part number is known.
- (1) First. Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphameric sequence, cross-referenced to the illustration figure number and item number.
- (2) *Second.* After finding the figure and item number, locate the figure and item number in the repair parts list.

#### 6. Abbreviations

Not applicable.




Figure 1. Wattmeter ME-497/U.

SECTION 11 TM 11-6625-3018-24P (3) (7) (8) ILLUSTRATION DESCRIPTION QTY (b) ITEM NO NATIONAL SMR STOCK PART FSCM NUMBER USABLE ON CODE GRUUP DO MATIMETER ME-497/U XDHZZ 70998 1118-1501-00 SCREW MACH RNU HO..... PAHZZ 5340-01-108-2911 70998 7500-047 LA 1 3 PAHZZ 6625-00-401-5366 70998 2400-050 CAP, DIAPHRAGM RETAL.... PAHZZ 6625-00-401-5365 70998 2400-015 1 DIAPHRAGM.TEST SET.... 1 6625-01-122-4509 70998 2400-058 PAHHH RADITOR ASSEMBLY XBHZZ 96169 2V999P2B1000PC4 PACKING PREFORMED..... 7 PAHHH 6625-01-122-4508 70998 6104-002 BLOCK ASSEMBLY VUL.... PAH 7.7 5305-30-193-1118 70998 1120-0301-12 SCREW-MACHINE----1 PAHZZ 5330-00-350-9694 70998 7500-153 GASKET PAHZZ 6625-00-401-5368 10 70998 7500-029 LATCH ASSEMBLY, TEST ..... 11 PAHZZ 1 6625-00-401-5369 70998 7500-032 12 PAHZZ 5985-00-762-8502 70998 7500-223 MIXER, CRYSTAL, CÚAXI.... 13 XBH22 70998 5-092 1 1 14 PAHHH 5930-01-122-4588 70998 6154-012 SWITCH ASSEMBLY ı 15 PAHZZ 5340-00-431-1114 73485 513A -HOUSING METER ASSY.... ı 16 XAHHH 70998 6104-003 1 17 PAHZZ 5961-00-961-7819 70998 7500-147 SEMICONDUCTOR DEVIL.... 18 XAHZZ 70998 7500-152 1 END KING bEAD CHAIN-----FΔ 1 1 19 XAHZZ 70998 7500-145 CAP, ELECTRICAL.... i E A XAHZZ 02690 568-011 PACKING PREFURMED.... 1 21 XAHZZ 70998 7500-180 SEMICONDUCTUR DEVI. EA 22 XAHZZ 70498 7500-144 HOLDER.CRYSTAL UNII 1 23 XAHZZ 81168 11-009 ì PACKING PREFURMED.... ŁA 1 24 XBHZZ 73998 1120-0504-00 1 25 PAH 27 6625-00-401-5371 70998 7500-046 HULDER CASE METER ..... 26 XBHZZ 70998 1116-0505-00 SCREW MACHINE FLH 1 27 PAHZZ 5935-00-479-6465 70998 8180-036 SOCKET, ELECTRICAL.... 5




Figure 2. Meter housing.

		SECT ION				TM 11-6625-3018-24P	(7)	(e)
(1		(2)	(3)	(4)	(5)	(6)	"	(8)
(a) FIG NO	(b) ITEM NO	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION  UBABLE ON CODE	U/M	QTY INC IN UNIT
						GROUP OI METER HOUSING	Ì	
2	1	PAHZZ	5995-00-932-0443	70998	4220-097-2	CABLE ASSEMBLY, SPEC	EA	1
2	. 2	PAHZZ	6625-00-531-4273	70998	4220-087	SHOCK MOUNT ASSEMBL	EA	4
2	3	XBHZZ		70998	5-1066	STRIP SHOCK	EA	1
2	4	PAHZZ	6625-01-108-6611	70998	2080-034	WATTMETER	EA	1
2	5	XBHZZ	:	70998	7500-037	HINGE	EA	2
2		XBHZZ		70998	5-1319	LKWASH 17 15/32 S5T	EA	2
2	1	XBmZZ	i	70998	1120-0505-00	SCR MACH FLH	EA	4
2	6	XBHZZ		70998	6154-004	HUUSING METER	EA	1
2	9	XBHZZ		70998	5-256-2	RIVET	ŁA	2
2		XBHZZ		70998	6154-011	COVER METER	EA	1
2		XBHZZ		70498	1112-0130-00	SCR MACH PHD SST	EA	1
2	12	PAHZZ	5340-00-411-9214	70998	7500-038	CLIP, SPRING TENSIUN	EA	1
2		XBHZZ	I 1		5-1320	SCR MACH PHD NU 2 B	EA	4
2		XBHZZ			6104-004	PLATE IDENI	EA	1
2			5340-00-255-0273	70998	4220-098	BUMPER, PUBBER	EA	3
•	• •							
			i					
		İ	ļ					
							İ	
		i !			†			
		!						
								1
		i I	i					
			1					
			i					
			!					
			i					
								'
1							1	
!		i						
1							1	
1			1					
		İ						
	i	1						
1								
						7	1	




Figure 3. Switch Assembly

		SECTION	11			TM 11-6625-3018-24P			
(1	)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	_
ILLUSTF						DESCRIPTION		QTY	
(a) FIG	(b)	SMR	NATIONAL STOCK		PART			INC	
NO	NO	CODE	NUMBER	FSCM	NUMBER	USABLE ON CODE	U/ <b>M</b>	UNIT	
						GROUP OLOL SWITCH ASSEMBLY			
3	ı	XBHZZ		70998	6154-015	TERMINAL STRIP ELEC	LA	1	
3	2	PAHZZ	5930-00-542-9436	27193	329UK27C	SWITCH, TOGGLE	ŁA	1	L
3	3	PAHZZ	5310-01-006-5022	27193	15-1049-3	NUT, PLAIN, RCUND	EA	1	1
3	4	XBHZZ		14514	2 98	WIRE CUPPER TINNED	EA		,
3	5	PAHZZ	5905-01-107-6579	54869	P115L02.5K	RESISTUR, VARIABLE, N	EA	1	
İ									
							1		
							İ		
!									
1									
1				•					
1									
	! !								
							İ		
									i
İ									
									ĺ
	İ								ļ
1									
1									
									I
						9			
									1




Figure 4. Radiator Assembly.

TM 11-6625-3018-24P SECTION 11 (6) (8) (1) (3) (4) (5) ILLUSTRATION DESCRIPTION QTY INC IN UNIT (a) FIG NO PART NUMBER SMR CODE ITEM NO. FSCM USABLE ON CODE GROUP 02 RADIATOR ASSEMBLY 5330-00-297-6308 PACKING, PREFURMED..... 1 PAHZZ 81168 11-012 5365-00-194-5570 70998 7500-040 PLUG. MACHINE THREAD. PAH 7.7 70998 7500-271 SLV AND PRUBE ASSY..... XBH77 4 XBHZZ 70998 7500-115 70998 7500-112 SLEEVE HIGH RANGE..... XBHZZ 70998 7500-111 SPACER SLEEVE ŁA 4 6 XBHZZ 70998 7500-113 7 XBHZZ SPACER KING..... 8 XBHZZ 70998 7500-110 FA 70998 7500-119 SCREW SEAL PRURE EΔ 4 XBHZZ 70998 8180-013 WASHER SEAL PROBE..... 10 XBHZZ PAH22 6625-01-107-5439 70998 7500-126 COVER.IEST PRUD..... £٨ 12 XBHZZ 70998 1118-0607-00 SCREW MACH HEX HU...... ŁΑ LKWASH NU 8 SST..... 13 XBHZZ 70998 5-1318 X BHZZ 70998 6700-021 CH AND FSTNR ASSY..... 4 14 FND RINGS BEAG CHAIN EA 15 PAHZZ 4030-00-585-2110 70998 7500-152 1 7500-108 CHAIN HULDER 70998 16 XBHZZ 17 XBHZZ 96169 54-66-2114 PACKING. PREFORMED..... EA ENSULATOR CONNECTOR 7500-139 EA 18 XAHZZ 70998 70998 7500-138 CONN BODY RCPT ELEC..... 19 XAH22 20 XBHZZ 70998 7500-141 70998 5-1321 SCR DR NU 00 1/8 (Nacconstance) EA ZI XBHZZ 22 XAH 22 70998 7500-143 CONTACT SPRING. EA 70998 7500-104 23 XAHZZ 24 XAHZZ 70998 7500-101 CASE CRYSTAL VM..... EΔ 70998 5-028-1 INSUL SLYG ELEC EA 25 XBHZZ 70998 5-097-2 RESISTUR FIXED CUM..... 26 PAHZZ 5910-01-107-4633 70998 7500-116 CAPACITOR . FIXED. MIC..... EA 1 27 PAHZZ CONTACT ASSY FLEC EA 28 XAHZZ 70998 7500-232 CUNTACT ELECTRICAL.... ΕA 70998 7500-121 29 XAHZZ INSULATOR, BUSHING..... EA 30 PAHZZ 5970-01-106-8242 70998 7500-123 CASE VM AND RES..... ı XBHZZ 70998 7500-216 EA 31 79136 5100-62 RING, RETAINING..... EΑ 32 PAHZZ 5365-00-298-6563 33 XBHZZ 70998 7500-257 FITTING ASSY RES..... PLATE CAPACITOR 34 XAHZZ 70998 7500-128 EA 70998 7500-130 SLEEVE CUNTACT..... EA 35 XAHZZ 36 XAHZZ 70998 7500-256 RESISTOR FIXED FILM 1 PAHZZ 5905-01-107-8715 70998 8130-008-1 11




Figure 5. Radiator Pre-assembly.

TM 11-6625-3018-24P SECTION II (3) (5) (6) (7) (8) (1) ILLUSTRATION DESCRIPTION QTY INC IN NATIONAL (a) FIG (b) łTEM SMR CODE PART NUMBER STOCK UNIT U/M NO NO FSCM USABLE ON CODE RADIATOR PRE-ASSEMBLY EA 1 2400-001 RADIATOR PRE-ASSY..... 70998 5 ! 1 XAHZZ EA 1 2400-008 70998 5 XAHZZ ΕA 1 3 XAHZ7 70998 2400-007 FIN RADIATING..... 2400-005 ΕA XAHZZ 70998 EA 1 2400-006 70998 XAHZZ 1 2400-002 EΑ 70998 XAHZZ EA 1 70998 2400-004 XAH77 ΕA 1 70998 2400-003 XAHZZ RAIL CORNER..... EA 2 2400-009 XAHZZ 70998 ΕA 2 2400-010 RIB SPACING..... 5 10 XAHZZ 70998 EA 8 1120-0506-00 SCR MACH PH TRH..... 70998 5 11 XAHZZ EA 4 PACKING, PREFORMED..... PAHZZ 5330-01-074-0265 70485 12 SCR MACH PH TRH.... EA 1 13 XBHZZ 70998 1120-1206-00 SPACER SUPPORT..... EA 14 XBHZZ 70998 2400-069 1 HANDLE, BAIL..... EA 2400-017 PAHZZ 5340-00-224-1565 70998 5 15 FA 4 SCREW, CAP, SOCKET HE..... PAHZZ 5305-00-224-1311 70998 7500-071 5 16 EA 4 PAHZZ 5365-00-224-9379 70998 7500-070 SPACER, SLEEVE..... 17 5 13

SECTION IV	NAT IUNAL	STOCK NUMBER AN	D PART NUMBER INJEX	TM 11-6625-30	18-24P
STUCK NUMBER	FIGURE NU.	ITEM NO.	STUCK NUMBER	FIGURE NU.	ITEM NO.
5305-00-193-1118	1	8	5930-00-542-9436	j	2
5365-00-194-5570	4	2	4030-00-505-2110	4	15
5305-00-224-1311	5	16	5985-00-762-8502	1	12
5340-00-224-1565	5	15	5995-00-932-0443	2	1
5365-00-224-9379	5	17	5961-03-961-7819	1	17
5340-00-255-0273	2	15	5310-01-006-5022	3	3
5330-00-297-6308	4	1	5330-01-074-0265	5	12
5365-00-298-6563	4	32	5970-01-106-8242	4	30
5330-00-350-9694	1	9	5910-01-107-4633	4	21
6625-00-401-5365	1	4	6625-01-137-5439	4	11
6625-00-401-5366	1	3	5905-01-107-6579	3	5
6625-00-401-5368	1	10	5905-01-107-8715	4	7د
6625-00-401-5369	1	11	5340-01-108-2911	1	2
6625-00-401-5371	1	25	6625-01-138-6611	2	4
5340-00-411-9214	2	12	6625-01-122-4508	1	7
5340-00-431-1114	1	15	6625-01-122-4509	ī	5
5935-00-479-6465	1	27	5930-01-122-4588	1	14
6625-00-531-4273	2	2			
FSCM PART NUMBER	R	FIGURE ITEM NG. NO.	FSCM PART NUMBER	F	IGURE ITEM Nú. Nú.
54869 PT15LD2.5K		3 5	70998 6154-004		2 B
81168 11-009		1 23	7J998 6154-J11		2 10
81168 11-012		4 1	70998 6154-012		1 14
70998 1112-0100-0	00	2 11	70998 6154-015		3 1
70998 1116-0505-0	00	1 26	70998 6700-021		4 14
70998 1118-0607-0		4 12	70998 7500-029		1 10
70998 1118-1501-0	00	1 1	70998 7500-032		1 11
70998 1120-0301-	12	1 8	70998 7500 <del>-</del> 037		2 5
70998 1120-0504-0		1 24	70998 7500-038		2 12
70998 1120-0505-0		2 7	70998 7500-040		4 2
70998 1120-0506-0		5 11	70998 7500-046		l 25
70998 1120-1206-0	00	5 13	70998 7500-047		1 2
27193 15-1049-3		3 3	70998 7500 <b>-</b> 070		5 17
96169 2V999P2B10	OOPC4	1 6	70998 7500-071		5 10
70998 2080-034		2 4	70998 7500-101		4 24
70485 225		5 12	70998 7500-104		4 23
70998 2400-001		5 1	70998 7500-108		4 16
70000 2400 002		E 1	70000 7500 110		

14

2400-002 2400-003

2400-004

2400-005

2400-006

2400-007

2400-008

2400-009

2400-010

2400-015

2400-017

2400-050

2400-058

2400-069

4220-087

4220-098

5-028-1

5-097-2

5-1066

5-1318

5-1319

5-1320

5-1321

5-256-2

5100-62

54-66-2114 568-011

6104-002 6104-003

6104-004

513A

5-092

4220-097-2

02690 70998

70998 70998

70998

7500-110

7500-111

7500-112 7500-113

7500-115 7500-116

7500-119

7500-121

7500-123

7500-126

7500-128

7500-130

7500-138

7500-139

7500-141

7500-143

7500-144

7500-145

7500-147

7500-152

7500-152

7500-153

7500-180

7500-216

7500-223

7500-232

7500-256

7500-257

7500-271

8180-013

8180-036

8290K27C

8130-008-1

15

# RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



#### SOMETHING WRONG WITH THIS PUBLICATION?

THEN. . JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

(PRINT YOUR UNIT'S COMPLETE ADDRESS) Commander Stateside Army Depot ATTN: AMSTA-US 07703 Stateside, N.J.

**DATE SENT** 

10 July 1975

**PUBLICATION NUMBER** 

TEAR ALONG PERFORATED LINE

PUBLICATION DATE

PUBLICATION TITLE

TM 11-5840-340-20P				-20P		23 Jan 78	Radar Set AN/PRC-76				
	BE EXACT. PIN-POINT WHERE IT IS					IN THIS SPACE TELL WHAT IS WRONG					
ı	PAGE NO	PARA- GRAPH	FIGURE NO	TABLE NO	AND WHAT SHOULD BE DONE ABOUT IT:						
I	33					For item 2, change the NSN to read: 5835-00-134-9186.					
					Reaso	Reason: Accuracy.					
ı	44		19		Ident	Identify the cover on the junction box (item no. 5).					
					Reaso	Reason: It is a separate item and s not called out on figure 19.					
	45				Add t	dd the cover of the junction box as an item in the					
					listi	ng for figure 19 n: Same as abov	). <b>A</b>				
					Reaso	. Same as abov					
							,				
ı		: :					•				
		;				A					
						Mary 1					
					L	V					
			i								

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER 999-1776 SSG I. M. DeSpirit of

DA 1 JUL 79 2028-2

PREVIOUS EDITIONS ARE OBSOLETE.

PS -- IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COP OF THIS AND GIVE IT TO YOUR HEADQUARTERS

# RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

	_ \							
/					SOMET	WING	WRONG WITH THIS PUBLICATION?	
	. <b>.</b> )	) (	THEN	JOT D	OWN THE	FROM	: (PRINT YOUR UNIT'S COMPLETE ADDRESS)	
6		1	DOPE A	BOUT I	T ON THIS			
M	N.				ULLY TEAR O IT AND	<b> </b>		
DROP IT IN THE MAIL.  DATE SENT								
1	PUBLICATION NUMBER PUBLICATION DATE PUBLICATION TITLE							
TM 1	TM 11-6625-3018-24P							
BE EXA		NW TAIO	T		SPACE TELL WI			
PAGE NO.	PARA- GRAPH	FIGURF NO.	TABLE NO.	AND WI	HAT SHOULD B	E DONE A	ABOUT IT:	
			}					
			ļ					
			[					
	İ							
		i						
i								
ļ								
}								
	•							
PRINTED NA	ME GRADE O	R TITLE AND	TELEPHONE NU	MRED	<del></del>	SIGN HE	DE.	
FRINTED NA	THE GRADE U	A MILE AND	TEEFHONE NU	WIDER.		JIGN HE	nt.	

DA 150RM 2028-2

TEAR ALONG PERFORATED LINE

PREVIOUS EDITIONS
ARE OBSOLETE

P.S.-IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADOUARTERS.

FILL IN YOUR UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

POSTAGE AND FEES PAID DEPARTMENT OF THE ARMY DOD 314



OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

Commander

US Army Communications-Electronics Command and Fort Monmouth

ATTN: DRSEL-ME-MP

Fort Monmouth, New Jersey 07703

### RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

7		
7		
	入 入	

# SOMETHING WRONG WITH THIS PUBLICATION?

THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL.

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

**DATE SENT** 

PUBLICATION NUMBER

TEAR ALONG PERFORATED LINE

TM 11-6625-3018-24P

PUBLICATION DATE 28 MAR 1983

**PUBLICATION TITLE** 

Wattmeter ME-497/U

							Ha delire del Tie 1977	
BE EXACT PIN-POINT WHERE IT IS			S SPACE TELL WHAT IS WRONG					
PAGE NO.	PARA- GRAPH	FIGURE NO.	TABLE NO.	AND WHA	AT SHOULD B	E DONE A	ABOUT IT:	
	<u> </u>	ļ						
		ŀ	ļ					
	:							
								<u></u>
PRINTED NA	ME GRADE O	R TITLE AND T	ELEPHONE NU	MBER	. —	SIGN HE	RE	-
İ								

DA 150 2028-2

PREVIOUS EDITIONS ARE OBSOLETE

P.S.-IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADOUARTERS.

FILL IN YOUR UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

POSTAGE AND FEES PAID DEPARTMENT OF THE ARMY DOD 314



OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

Commander
US Army Communications-Electronics Command
and Fort Monmouth
ATTN: DRSEL-ME-MP
Fort Monmouth, New Jersey 07703

## RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

CATION?			
ss)			
WHERE IT IS IN THIS SPACE TELL WHAT IS WRONG			

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

DA | FORM 2028-2

PREVIOUS EDITIONS ARE OBSOLETE

P.S.-IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADOUARTERS.

FILL IN YOUR UNIT'S ADDRESS	

FOLD BACK

DEPARTMENT OF THE ARMY

\_\_\_\_\_

POSTAGE AND FEES PAID DEPARTMENT OF THE ARMY DOD 314



OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

Commander
US Army Communications-Electronics Command
and Fort Monmouth
ATTN: DRSEL-ME-MP
Fort Monmouth, New Jersey 07703

By Order of the Secretary of the Army:

E. C. MEYER
General, United States Army
Chief of Staff

Official:

Robert M. Joyce
Major General, United States Army
The Adjutant General

# DISTRIBUTION:

To be distributed in accordance with Special Mailing List.

U.S. GOVERNMENT PRINTING OFFICE: 1983−605-040/26

PIN: 052583-000