ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS) PROCESSING UNIT, PHOTOGRAPHIC PRINT AN/TFQ-9 FSN 6740-406-5611

Headquarters, Department of the Army, Washington, D.C. 28 June 1974

Current as of October 1973 Paragraph Page SECTION I. INTRODUCTION 2 1-5 1-7 Reporting of equipment publication improvements PRESCRIBED LOAD ALLOWANCE (Not applicable) III. REPAIR PARTS LIST IV. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable) REPAIR PARTS LIST..... VI. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable) VII. - FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS-REFERENCE TO FIGURE AND ITEM NUMBER

^{*}This manual supercedes TM 11-6740-230-20P, 22 September 1961, and TM 11-6740-230-35P, 22 September 1961.

SECTION I

1-1. Scope

This manual lists repair parts and special tools required for the performance of organizational, direct support, general support, and depot maintenance of the AN/TFQ-9. The PCCN for the AN/TFQ-9 is GRNACG for all models.

1-2. General

This repair parts and special tools list is divided into the following sections:

- a. Prescribed Load Allowance (PLA) Section II. Not applicable.
- b. Repair Parts List Section III. A list of repair parts authorized for the performance of maintenance at the organizational level. This repair parts list is arranged in alphabetical order.
- c. Special Tools, Test and Support Equipment Section IV. Not applicable.
- d. Repair Parts List Section V. A list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot level.
- e. Special *Tools, Test and Support Equipment Section VI.* Not applicable.
- f. Index Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number Section VII. A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

1-3. Explanation of Columns

The following provides an explanation of columns found in the tabular list.

- a. Source, Maintenance, and Recoverability Codes (SMR).
- (1) *Source code.* Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are -

Code Exlanation

- P A Item procured and stocked for anticipated or known usage.
- P B Item procured and stocked for insurance purposes because essentiality dictates

- that a minimum quantity be available in the supply systems.
- PC Item procured and stocked and white otherwise would be coded PA except that it is deteriorative in nature.
- PD Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
- PE Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
- PF Support equipment which will not be stocked but which will be centrally procured on demand.
- PG Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
- KD An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
- KF An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.
- KB Item included in both a depot overhaul/repair kit and a maintenance kit.
- MO Item to be manufactured or fabricated at organizational level.
- MF Item to be manufactured or fabricated at direct support maintenance level.
- MH Item to be manufactured or fabricated at general support maintenance level.
- MD Item to be manufactured or fabricated at depot maintenance level.
- AO Item to be assembled at organizational level.
- AF Item to be assembled at direct support maintenance level.
- AH Item to be assembled at general support maintenance level.

- AD Item to be assembled at depot maintenance level.
- XA Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
- XB Item is not procured or stocked. If not available through salvage, requisition.
- XC Installation drawing, diagram instruction sheet, field service drawing, that is identified by manufacturers' part number.
- XD Support items can be requisitioned with justification.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

- (2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code Format as follows
- (a) Use (third position). The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position indicates one of the following levels of maintenance.

Code Application/Explanation

O - Support item is removed, replaced, used at the organizational level of maintenance.

NOTE

A code "C" may be used in this position to denote crew or operator maintenance performed within organizational maintenance.

- $F \quad \text{-} \quad \text{Support item is removed, replaced, used at} \\ \quad \text{the direct support maintenance level.}$
- H Support item is removed, replaced, used at the general support maintenance.
- D Support items that are removed, replaced, used at depot only.

(b) Repair (fourth position). The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used a dash (-) sign is entered. For multi-service equipment/systems or when a code is entered, this

position will contain one of the following maintenance codes as assigned by the service(s) that require the code $\,$

Code Application/Exrplanation

- O The lowest maintenance level capable of complete repair of the support item is the organizational level.
- F The lowest maintenance level capable of complete repair of the support item is direct support.
- H The lowest maintenance level capable of complete repair of the support item is general support.
- D The lowest maintenance level capable of complete repair of the support item is the depot level.
- L Repair restricted to designated Specialized Repair Activity.
- Z Non-repairable. No repair is authorized.
- B No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.
- (3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the uniform SMR Code Format as follows -

Code Explanation

- Z Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in the first digit of the maintenance code.
- O Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
- F Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.
- Repairable item. When uneconomically repairable, condemn and dispose at the general support level.
- D Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
- L Repairable item. Repair, condemnation, and disposal not authorized below depot/Specialized Repair Activity level.
- A Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high

dollar value, critical material or hazardous material).

- b. Federal Stock Number. Indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.
- c. Description. Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc., and is identified in SB 708-42.
- d. Unit of Measure (U/M). Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviations; e.g., ea, in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.
- e. Quantity Incorporated in Unit. This column indicates the quantity of the item used in the equipment.
 - f. 15-Day Organizational Maintenance Allowances.
- (1) The repair parts indicated by an asterisk in the allowance column represent those authorized for use at the organizational category, and will be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.
- (2) Major Army commanders are authorized to approve reduction in the range of support items authorized for use in units within their commands. Recommendations for increase in range of items authorized for use will be forwarded to Commander, US Army Electronics Command, ATTN: AMSELMA-SNV, Fort Monmouth, N.J., 07703.
- (3) Allowance quantities are indicated in the special tools list section for special tools, TMDE, and other support equipment.
 - g. 30-Day DS/GS Maintenance Allowances.

NOTE

Allowances in GS column are for GS maintenance only.

(1) The repair parts indicated by asterisk entries in separate allowance columns for DS and GS represent those authorized for use at that category of maintenance to be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

- (2) Allowance quantities are indicated in the special tool lists section for special tools, TMDE, and other support equipment.
- h. 1-Year Allowances Per 100 Equipments/Contingency Planning Purposes. Column intentionally left blank.
- i. Depot Maintenance Allowance Per 100 Equipments. This column indicates opposite the first appearance of each item the total quantity authorized for depot maintenance of 100 equipments.
 - j. Illustration.
- (1) *Figure number.* Indicates the figure number of the illustration on which the item is shown in TM 11-404A.
 - (2) Item number. Not applicable.

1-4. Special Information

a. Usable on codes are included in column 3. Uncoded items are applicable to all models. Identification of the usable on codes used in this publication are -

Code Used On

AØK AN/TFQ-9

b. The following publication pertains to the AN/TFQ-9 and its components:

TM 11-404A

Photographic Print Processing Unit AN/TFQ-9.

1-5. Location of Repair Parts

- a. This manual contains one cross-reference index (sec VII) to be used to locate a repair part when either the Federal stock number or reference number (manufacturer's part number) is known. The first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacturer's part numbers) are listed immediately following the last listed Federal stock number in the index of Federal stock numbers.
- *b.* When the Federal stock number or reference number is known, follow the procedures given in (1) and (2) below.
- (1) Refer to the index of Federal stock numbers (sec VII), and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable figure and item number or reference designation.
- (2) Refer to the repair parts list (sec III and V) and locate the figure number (c ol 7a 20P, 10a 34P) and item number or reference designation (col 7b 20P, 10b 34P) as noted in the FSN index.

- c. When the figure and item number or reference designation are known, scrutinize columns 7a and 7b 20P and 10a and 10b 34P, of the repair parts list (sec III and V) until the item is located.
- d. When the FSN, reference number, figure number, and item number are not known, scrutinize column 3 of the repair parts list (sec III and V), which is arranged in alphabetical order.

1-6. Abbreviations

Not applicable.

1-7. Reporting of Equipment Publication Improvements

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications) and forwarded direct to Commander, US Army Electronics Command, ATTN: AMSEL-MA-SNV, Fort Monmouth, N.J., 07703.

	1-6740 TION :	0-230-24P									
(1)		(2)	(3)		(4)	(5) QTY	(6) 15-DAY	ORGANI	ZATIONAL		(7) ILLUSTRATION
SMR		FEDERAL STOCK	DESCRIPTION		UNIT OF	INC	MAINTE (A)	NANCE A	LW (C)	(D)	(A) (B) FIGURE ITEM
COD		NUMBER	REFERENCE NUMBER & MFR CODE USABLE O CODE	N CODE		UNIT	1-5	6-20		51-100	
			GROUP 0001 PROCESSING UNIT, PHOTOGRAPHIC PRINT AN/TFO-9								
PAO	ZZ	6145-284-0063	CABLE POWER ELECTRICAL NO-REF-DESIG TWO NO 16 AWG STRANDED COND, 3/8 IN DIA, 25 FEET LONG C002HgF2-16-0405 (81349)		EA	1	*	*	*	*	4-1
PAO	ZZ	6760-498-9873	CABLE ASSEMBLY, POWER ELECTRICAL NO-REF-DESIG 10 FT LG EXCLUDING TERMS, FEED THRU SWITCH 1 FT FROM LAMPHOLDER		EA	1	*	*	*	*	
PAO	ZZ	5935-027-7334	POSJ (81345) CONNECTOR, ADAPTER NO-REF-DESIG		EA	1	*	*	*	*	
PAO	ZZ	5935-149-4013	207 (74545) CONNECTOR, PLUG, ELECTRICAL NO-REF-DESIG 2 PARALLEL MALE CONT		EA	2	*	*	*	*	
XBO	ZZ		7057 (74545) CONNECTOR, PLUG, ELECTRICAL NO-REF-DESIG 2 PUL SOCKET TYPE CONT 5917 (74545)		EA	1					
PAO	ZZ	5935-187-7099	CONNECTOR, PLUG, ELECTRICAL NO-REF-DESIG APPROX 1-5/16 IN LG X 1-5/16 IN W X 1-1/8 IN THK 469 (74545)		EA	1	*	*	*	*	
PAO	ZZ	6740-356-5486	FILTER, PHOTOGRAPHIC NO-REF-DESIG 2-5/8 IN (67.9 MM) DIA X 3/16 IN THK, (P/O SAFELIGHT PH-566/UF)		EA	1	*	*	*	*	14
PAO	ZZ	6740-392-8765	OA (19139) FILTER, PHOTOGRAPHIC NO-REF-DESIG 3-1/4 IN WD X 4-3/4 IN LG X 3/16 IN THK, (P/O SAFELIGHT PH- 566/UF)		EA	1	*	*	*	*	14
PAO	ZZ	6740-356-5489	OA (19139) FILTER, PHOTOGRAPHIC NO-REF-DESIG 2-1/2 IN (63.5 MM) DIA, (P/O SAFELIGHT PH-566/UE) 3 (19139)		EA	1	*	*	*	*	14
PAO	ZZ	6760-030-0531	FILTER, PHOTOGRAPHIC NO-REF-DESIG 3-1/4 IN WD X 4-3/4 IN LG X 3/16 IN THK, (P/O SAFELIGHT PH-566/UF)		EA	1	*	*	*	*	14
PAO	ZZ	6740-356-5487	KODAKWRATTEN3 (19139) FILTER, PHOTOGRAPHIC NO-REF-DESIG 2-9/16 IN DIA X 3/16 IN THK, (P/O SAFELIGHT PH-566/UF)		EA	1	*	*	*	*	14
XBO.	ZZ		2 (19139) FILTER, PHOTOGRAPHIC NO-REF-DESIG 3-1/4 IN WD X 4-3/4 IN LG X 3/16 IN THK, (P/O SAFELIGHT PH-566/UF) 2 (19139)		EA	1					14
PAO	ZZ	6740-392-8764	FILTER, PHOTOGRAPHIC NO-REF-DESIG 2-1/4 LG X 3 IN DIA, (P/O EKCO BROWNIE DARKROOM LAMP MODEL B MODIFIED) BROWNIESERIESOSA*		EA	1	*	*	*	*	14
XBO	ZZ		FELIGHTCUP (19139) FILTER, PHOTOGRAPHIC NO-REF-DESIG 2-1/4 IN LG X 3 IN DIA, (P/O EKCO BROWNIE DARKROOM LAMP MODEL B MODIFIED) BROWNIESERIES2SA* AFELIGHTCUP (19139)		EA	1					14
PAO	ZZ	6740-226-6052	FILTER, LIGHT NO-REF-DESIG 2-1/4 IN LG X 3 IN DIA, (P/O EKCO BROWNIE DARKROOM LAMP.MODEL B MODIFIED) BROWNIESERIES3SAF*		EA	1	*	*	*	*	14
PAO	FD	5930-244-3599	ELIGHTCUP (19139) FOOT SWITCH NO-REF-DESIG		EA	1	*	*	*	*	4-1
PAO	ZZ	6240-155-8709	PH424 (06400) LAMP, INCANDESCENT NO-REF-DESIG 6.5V 6.5W, 1- 3.8 IN LG O/A, (P/O EKCO BROWNIE DARKROOM LAMP MODEL B MODIFIED)		EA	1	*	*	*	*	
PAO	ZZ	6240-238-8507	81K (08108) LAMP, INCANDESCENT NO-REF-DESIG 6V,110W, 3-1/2 IN LG 0/A (P/O SAFELIGHT PH-566/UF) 10514-6V (08108)		EA	1	*	*	*	*	
PAO	ZZ	6240-143-7433	LAMP, INCANDESCENT NO-REF-DESIG 120V, 7W, (P/O EKCO BROWNIE DARKROOM LAMP MODELB MODIFIED) 7C7W115-125V (08108)		EA	1	*	*	*	*	
PAO	ZZ	6240-797-8730	LAMP, INCANDESCENT NO-REF-DESIG 115V, 10W (P/O SAFELIGHT PH-566/UF)		EA	1	*	*	*	*	
PAO	ZZ	6250-196-8876	10S14-1F115V (03350) LAMPHOLDER NO-REF-DESIG 1-9/16 IN DIA X 2-3/4 IN LG O/A, (P/O SAFELIGHT PH-566/UF) 3986W3982 (74545)		EA	1	*	*	*	*	
PAO	ZZ	6740-200-3912	PADDLE NO-REF-DESIG PRINTPADDLE (19139)		EA	1	*	*	*	*	3
PAO	FD	6740-247-1730	FRINIPADDE (1919) FILTER, PHOTOGRAPHIC NO-REF-DESIG PH566UF (80058)		EA	1	*	*	*	*	4

TM11-6740-230-24P SECTION III

SECTION	III										
(1)	(2)	(3)		(4)	(5)	(6)				(7)	
					QTY	15-DAY	ORGANIZ	ZATIONAL		ILLUSTE	RATION
	FEDERAL	DESCRIPTION		UNIT	INC	MAINTE	NANCE AI	LW.		(A)	(B)
SMR	STOCK			OF	IN	(A)	(B)	(C)	(D)	FIGURE	ITEM
CODE	NUMBER	REFERENCE NUMBER & MFR CODE	USABLE ON CODE	MEAS	UNIT	1-5	6-20	21-50	51-100	NO	NO
			CODE								
PAOFD	6740-224-9612	SIPHON, PHOTOGRAPHIC NO-REF-DESIG		EA	1	*	*	*	*	13	
		PH244 (06400)									
PAOZZ	5930-263-2358	SWITCH, TOGGLE NO-REF-DESIG 2-5/8 IN LG X 1-		EA	1	*	*	*	*	1	
		1/16 IN WD X 13/16 IN THK									
		520 (73768)									
PAOFD	6685-521-0656	THERMOMETER, SELFINDICATOR NO-REF-DESIG		EA	1	*	*	*	*	4	
		PH660U (80058)									
PAOFD	6645-223-8018	TIMER, INTERVAL NO-REF-DESIG		EA	1	*	*	*	*	4-1	
		M59MASTERMODEL (30703)									

TM11-67 SECTION	740-230-24P V														
(1)	(2)	(3)		(4)	(5)		Y DS MA	INT		Y GS MA:	INT	(8) 1-YR	(9) DEPOT	(10) ILLUST	RATION
	FEDERAL	DESCRIPTION		UNIT	QTY	ALLOWA (A)	ANCE (B)	(C)	ALLOW.	ANCE (B)	(C)	ALW PER	ALW PER		(B)
SMR CODE	STOCK NUMBER	REFERENCE NUMBER & MFR CODE	USABLE ON CODE	OF MEAS	IN UNIT	1-20	21-50	51-100	1-20	21-50	51-100	EQUIP CNTGCY	100 EQUIP	FIGURE NO	ITEM NO
PAOZZ	6145-284-0063	CABLE POWER ELECTRICAL NO-REF-DESIG TWO NO. 16 AWG STRANDED COND, 3/8 IN DIA, 25 FEET LONG		EA	1	*	*	*	*	*	*		10	4-1	
PAOZZ	6760-498-9873	COOZEGF2-16-0405 (81349) CABLE ASSEMBLY, POWER ELECTRICAL NO-REF DESIG 10 FT LG EXCLUDING TERMS, FEED THRU SWITCH 1 FT FROM LAMPHOLDER POSJ (81345)		EA	1	*	*	*	*	*	*		5		
PAOZZ	5935-027-7334	CONNECTOR, ADAPTER NO-REF-DESIG 207 (74545)		EA	1	*	*	*	*	*	*		3		
PAOZZ	5935-149-4013	CONNECTOR, PLUG, ELECTRICAL NO-REF-DESIG 2 PARALLEL MALE CONT 7057 (74545)		EA	2	*	*	*	*	*	*		3		
XBOZZ		CONNECTOR, PLUG, ELECTRICAL NO-REF-DESIG 2 POL SOCKET TYPE CONT 5917 (74545)		EA	1										
PAOZZ	5935-187-7099	CONNECTOR, PLUG, ELECTRICAL NO-REF-DESIG APPROX 1-5/16 IN LG X 1-5/16 IN W X 1-1/8 IN THK 469 (74545)		EA	1	*	*	*	*	*	*		3		
PAOZZ	6740-356-5486	TILTER, PHOTOGRAPHIC NO-REF-DESIG 2-5/8 IN (67.9 MM) DIA X 3/16 IN THK, (P/O SAFELIGHT PH-566/UF) 0A (19139)		EA	1	*	*	*	*	*	*		3	14	
PAOZZ	6740-392-8765	FILTER, PHOTOGRAPHIC NO-REF-DESIG 3-1/4 IN WD X 4-3/4 IN LG X 3/16 IN THK, (P/O SAFELIGHT PH-566/UF)		EA	1	*	*	*	*	*	*		3	14	
PAOZZ	6740-356-5489	OA (19139) FILTER, PHOTOGRAPHIC NO-REF-DESIG 2-1/2 IN (63.5 MM) DIA, (P/O SAFELIGHT PH- 566/UE)		EA	1	*	*	*	*	*	*		3	14	
PAOZZ	6760-030-0531	3 (19139) FILTER, PHOTOGRAPHIC NO-REF-DESIG 3-1/4 IN WD X 4-3/4 IN LG X 3/16 IN THK, (P/O SAFELIGHT PH-566/UF)		EA	1	*	*	*	*	*	*		3	14	
PAOZZ	6740-356-5487	KODAKWRATTEN3 (19139) FILTER, PHOTOGRAPHIC NO-REF-DESIG 2-9/16 IN DIA X 3/16 IN THK, (P/O SAFELIGHT PH- 566/UF)		EA	1	*	*	*	*	*	*		3	14	
XBOZZ		2 (19139) FILTER, PHOTOGRAPHIC NO-REF-DESIG 3-1/4 IN WD X 4-3/4 IN LG X 3/16 IN THK, (P/O SAFELIGHT PH-566/UF)		EA	1									14	
PAOZZ	6740-392-8764	2 (19139) FILTER, PHOTOGRAPHIC NO-REF-DESIG 2-1/4 LG X 3 IN DIA, (P/O EKCO BROWNIE DARKROOM LAMP MODEL B MODIFIED) BROWNIESERIESOSA*		EA	1	*	*	*	*	*	*		3	14	
XBOZZ		FELIGHTCUP (19139) FILTER, PHOTOGRAPHIC NO-REF-DESIG 2-1/4 IN LG X 3 IN DIA, (P/O EKCO BROWNIE DARKROOM LAMP MODEL B MODIFIED) CONTINUED		EA	1									14	

TM11-67	740-230-24P														
(1)		(3)		(4)	(5)	(6)	7 DS MA	INT	(7)	GS MA:	INT	(8) 1-YR	(9) DEPOT	(10) ILLUSTR	MOTTA
Char	FEDERAL STOCK	DESCRIPTION		UNIT	QTY INC	ALLOWA (A)		(C)	ALLOWA (A)	NCE		ALW PER			(B)
SMR CODE	NUMBER	REFERENCE NUMBER & MFR CODE	USABLE ON CODE	MEAS	IN UNIT	1-20	21-50	51-100	1-20	21-50	51-100	CNTGCY		NO NO	NO
PAOZZ	6740-226-6052	CONTINUED BROWNIESERIES2SA* AFELIGHTCUP (19139) FILTER, LIGHT NO-REF-DESIG 2-1/4 IN LG X 3 IN DIA, (P/O EKCO BROWNIE DARKROOM LAMP.MODEL B MODIFIED) BRONIESERIES3SAF* ELIGHTCUP (19139)		EA	1	*	*	*	*	*	*		3	14	
PAOFD	5930-244-3599	FOOT SWITCH NO-REF-DESIG PH424 (06400)		EA	1	*	*	*	*	*	*		3	4-1	
PAOZZ	6240-155-8709	LAMP, INCANDESCENT NO-REF-DESIG 6.5V 6.5W, 1-3.8 IN LG O/A, (P/O EKCO BROWNIE DARKROOM LAMP MODEL B MODIFIED)		EA	1	*	*	*	*	*	*		50		
PAOZZ	6240-238-8507	81K (08108) LMMP, INCANDESCENT NO-REF-DESIG 6V,110W, 3-1/2 IN LG O/A (P/O SAFELIGHT PH- 566/UF) 10S14-6V (08108)		EA	1	*	*	*	*	*	*		50		
PAOZZ	6240-143-7433	LAMP, INCANDESCENT NO-REF-DESIG 120V 7W, (P/O EKCO BROWNIE DARKROOM LAMP MODELB MODIFIED) 7C7W115-125V (08108)		EA	1	*	*	*	*	*	*		50		
PAOZZ	6240-797-8730	LAMP, INCANDESCENT NO-REF-DESIG 115V 10W, (P/O SAFELIGHT PH-566/UF) 10S14-1F115V (03350)		EA	1	*	*	*	*	*	*		50		
PAOZZ	6250-196-8876	LAMPHOLDER NO-REF-DESIG 1-9/16 IN DIA X 2-3/4 IN LG O/A, (P/O SAFELIGHT PH-566/UF) 3986W3982 (74545)		EA	1	*	*	*	*	*	*		5		
PAOZZ	6740-200-3912	PADDLE NO-REF-DESIG PRINTPADDLE (19139)		EA	1	*	*	*	*	*	*		3	3	
PAOFD	6740-247-1730	FILTER, PHOTOGRAPHIC NO-REF-DESIG PH566UF (80058)		EA	1	*	*	*	*	*	*		3	4	
PAOFD	6740-224-9612	SIPHON, PHOTOGRAPHIC NO-REF-DESIG PH244 (06400)		EA	1	*	*	*	*	*	*		3	13	
PAOZZ	5930-263-2358	SWITCH, TOGGLE NO-REF-DESIG 2-5/8 IN LG X 1-1/16 IN WD X 13/16 IN THK 520 (73768)		EA	1	*	*	*	*	*	*		5	1	
PAOFD	6685-521-0656	THERMOMETER, SELFINDICATOR NO-REF-DESIG PH660U (80058)		EA	1	*	*	*	*	*	*		3	4	
PAOFD	6645-223-8018	TIMER, INTERVAL NO-REF-DESIG M59MASTERMODEL (30703)		EA	1	*	*	*	*	*	*		3	4-1	

INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS-REFERENCE TO FIGURE AND ITEM NUMBER

STOCK NUMBER	FIGURE NO	ITEM NO	STOCK NUMBER	FIGURE NO	ITEM NO		
5930-244-3599 5930-263-2358 5935-027-7334 5935-149-4013	4-1	6740-224-9612	6685-521-0656 6740-200-3912 13 6740-226-6052	4 3 14			
5935-187-7099 6145-284-0063 6240-143-7433 6240-155-8709 6240-238-8507 6240-797-8730 6250-196-8876 6645-223-8018	4-1	6740-356-5486	6740-247-1730 14 6740-356-5487 6740-356-5489 6740-392-8764 6740-392-8765 6760-030-0531 6760-498-9873	14 14 14 14 14			
REFERENCE NO	MFR CODE	FIG NO	ITEM NO	REFERENCE NO	MFR CODE	FIG NO	ITEM NO
BRONIESERIES3SAFELIGHTCUP BROWNIESERIES0SAFELIGHTCUP BROWNIESERIES2SAAFELIGHTCUP	19139 19139 19139	14 14 14		10S14-1F115V 10S14-6V 2	03350 08108 19139	14	
C002HGF2-16-0405 KODAKWRATTEN3 M59MASTERMODEL PH244	81349 19139 30703 06400	4-1 14 4-1 13		207 3 3986W3982 469	74545 19139 74545 74545	14	
PH424 PH566UF PH660U PRINTPADDLE	06400 80058 80058 19139	4-1 4 4 3	7057	520 5917 7C7W115-125V 74545	73768 74545 08108	1	
POSJ 0A	81345 19139	14		81K	08108		

CREIGHTON W. ABRAMS

Official:

VERNE L. BOWERS

Major General, United States Army The Adjutant General General, United States Army Chief of Staff

Distribution: Fort Carson (5) USAERDAA (1) Active Army: USAERDAW (1) CNGB (1) Army Dep (1) except TSG (1) LBAD (10) ACSC-E (2) **SAAD (30)** USAMB (10) TOAD (14) USAARENBD (1) ATAD (10) USASA (2) USA Dep (1) TRADOC (2) Sig Sec USA Dep (2) AMC (1) Sig Dep (2) Sig FLDMS (1) MICOM (1) TECOM (2) Ft Richardson (ECOM Ofc) (1) Units org under fol TOE: ARADCOM (2) ARADCOM Rgn (1) (1 Copy each unit) 11-37 OS Maj Comd (2) USACC (2) 11-95 HISA (Ft Monmouth) (18) 11-96 11-500(AA-AC) Armies (1) USAESS (5) 19-237 Svc Colleges (1) 19-256 Fort Huachuca (5) 29-134 WSMR (1) 29-136

NG: None USAR: None

For explanations of abbreviations used, see AR 310-50.

☆U.S. GOVERNMENT PRINTING OFFICE: 1974-768118/1838